



OPERATOR'S MANUAL

SV-8045/8045A

FANUC



Machine ☐ SV-8045
Type: ☐ SV-8045A

Machine
Number:
機 號

Approve:
確認者

Drawn	Approve	Date	Edition	Note
陳嘉珮	林明宏 邱文輝	12,AUG.2005	D07	SV-8045/8045A OPERATOR'S MANUAL (FANUC) Part No: 2000-7713-102

Sharp Industries, Inc.

3501 Challenger Street Torrance, California 90503

Tel : (310) 370-5990 Fax : (310) 542-6162

<http://www.sharp-industries.com>

CONTENS

1. SAFETYTY INTRODUCTION.....	1
1.1 FOREWORD	1
1.2 USING RESTRICTION	2
1.2.1 THE FORESEEN USE OF THE MACHINE	2
1.2.2 THE FORESEEN OTHER REASONABLE USE OF THE MACHINE	2
1.2.3 THE FORESEEN UNREASONABLE USE OF THE MACHINE.....	2
1.3 SAFETY INSTRUCTIONS	3
1.3.1 REACTION WITH EMERGENCY SITUATION:	3
1.3.2 SETTING UP THE MACHINE AND POWER.....	3
1.3.3 WHEN OPERATING.....	4
1.3.4 LUBRICATION, AIR AND COOLANT	6
1.3.5 HEALTHY AND SAFETY PROTECTION.....	8
1.3.6 MAINTENANCE AND CHECK.....	8
1.3.7 RESCUE THE PERSON WHO TRAPPED INTO MACHINE	8
1.4 WARNING LABEL AND POSITION.....	9
1.5 OPERATION AREA.....	19
1.6 DISPOSE OF WASTE	20
1.7 OTHER NOTICES	21
2. GENERAL INFORMATION	22
2.1 GENERAL DESCRIPTION OF THE MACHINE	22
2.2 DETAILS OF PRINCIPAL COMPONENT	24
2.2.1 SPINDLE HEAD	24
2.2.2 COLUMN	24
2.2.3 BED	24
2.2.4 TABLE	24
2.2.5 ATC (AUTOMATIC TOOL CHANGER).....	25
2.2.6 OPERATION PANEL	25
2.2.7 NC SYSTEM.....	25
2.2.8 ELECTRIC CABINET.....	25
2.2.9 PNEUMATIC UNIT	25
2.3 MACHINE SPECIFICATIONS.....	26
2.4 MACHINING AREA.....	28
2.4.1 MACHINING AREA.....	28
2.5 TOOL SHANK AND STUD	30
3. TRANSFER AND INSTALLATION OF MACHINE	33
3.1 HANGING OF MACHINE.....	33
3.2 REFERANCE DIMENTIONS FOR HANGING	35
3.3 MACHINE TRANSPORT BY FORK LIFT	36
3.4 HANGING OF PARTS AND ACCESSORIES	37
3.4.1 FRONT COOLANT TANK.....	37
3.4.2 SIDE COOLANT TANK.....	38
3.4.3 CHIP CONVEY	39
3.4.4 COOLANT SYSTEM.....	39

3.4.5 OTHER ACCESSORIES	39
3.5 INSTALLATION SPACE	40
3.6 INSTALLATION	41
3.6.1 FOUNDATION	41
3.6.2 INSTALLATION	41
3.7 INSTALLATION ENVIRONMENT	43
4. ASSEMBLY PROCEDURE AND TEST RUN	44
4.1 CLEANING OF MACHINE	45
4.2 REMOVAL OF LOCKING DEVICES	46
4.3 LUBRICATION AND AIR PIPING	47
4.3.1 LUBRICATION	47
4.3.2 AIR PIPING	48
4.4 SWITCHING ON THE POWER SOURCE AND CHECKING	49
4.4.1 WIRING CABLE AND PLACE SEE FIG 4.4.1	49
4.4.2 TO CONNECT THE POWER CABLE	49
4.5 TAKE OFF SPINDLE HEAD SUPPORT DEVICE	52
4.5.1 OPERATE IN DOOR OPEN STATUS WITH NON CE DOOR INTERLOCK SWITCH (OPTION)	52
4.5.2 OPERATE IN DOOR OPEN STATUS WITH CE DOOR INTERLOCK SWITCH (OPTION)	52
4.5.3 PROCEDURE TO TAKE OFF	53
4.5.4 MOVE AXIS TO REFERENCE POINT	53
4.6 LEVELING CHECK	55
4.7 ASSEMBLE OF PARTS AND DEVICES	57
4.7.1 MOTORS	58
4.7.2 CABLE CHAIN	59
4.7.3 SIDE COOLANT TANK AND MOTORS	60
4.7.4 CHIP CONVEYOR (OPTION)	61
4.7.5 CHIP CONVEYOR (OPTION)	62
4.7.6 SPINDLE CHILLER (OPTION)	63
4.7.7 EXHAUST (VACUUM) SYSTEM (OPTION)	64
4.7.8 OTHER OPTIONS	65
4.8 DEVICE PIPING INSTRUCTION	66
4.8.1 PIPE LIST	66
4.8.2 PIPING ON TOP OF THE MACHINE	67
4.8.3 PIPING ON DEVICES	68
4.8.4 POWER CONNECTOR ON ELECTRIC CABINET	69
4.9 COOLANT	70
4.9.1 QUANTITY OF COOLANT	70
4.9.2 TYPE OF COOLANT	70
4.9.3 SAFETY NOTICE	70
5. OPERATION OF MACHINE	71
5.1 SWITCHING ON THE POWER SOURCE TO MACHINE	71
5.1.1 APPLY THE POWER SOURCE TO THE MACHINE ITSELF AS FOLLOWS:	71
5.1.2 MOVE AXIS TO REFERENCE POINT (MANUALLY)	71
5.2 SWITCHING OFF THE POWER SOURCE	72
5.3 EMERGENCY STOP	72
5.4 EXPLANATION FOR USE OF OPERATION PANEL	74

5.5 OTHER SWITCHES AND SIGNAL.....	85
5.6 OPERATE IN DOOR OPEN STATUS	87
5.6.1 OPERATE IN DOOR OPEN STATUS WITH NON CE DOOR INTERLOCK SWITCH (OPTION)....	87
5.6.2 OPERATE IN DOOR OPEN STATUS WITH CE DOOR INTERLOCK SWITCH (OPTION).....	87
5.7 WHEN TOOL CHANGE MOVEMENT IS INTERRUPTED BY EMERGENCY STOP OR RESET	89
5.7.1 20 TOOLS ATC	89
5.7.2 24 / 32 TOOLS ATC	90
5.8 WHEN INSTALL OR REMOVE THE TOOL MANUALLY	91
5.9 WHEN OVERTRAVEL IS DETECTED BY 2ND LIMIT SWITCH	92
5.10 FANUC OPERATION PANEL.....	93
5.10.1 MD1 KEYBOARD AND CRT.....	93
5.10.2 LIST OF OPERATION	94
5.10.3 MDI KEYBOARD FUNCTIONS.....	96
5.11 M CODE LIST.....	98
5.12 S (SPINDLE) FUNCTION	104
5.13 T (TOOL) FUNCTION.....	105
5.14 SPECIAL TOOL ASSIGNMENT STEPS (M16/M61).....	106
5.14.1 DESCRIPTION	106
5.14.2 EXAMPLE.....	106
5.15 OTHER FUNCTION.....	107
6. CHECKING AND MAINTENANCE OF MACHINE	108
6.1 DAILY CHECKING	109
6.1.1 SAFETY CIRCUIT AND DVICE CHECK	109
6.1.2 MACHINE DAILY CHECKING SCHEDULE.....	111
6.2 6 MONTH CHECKING.....	112
6.3 YEARLY CHECKING.....	113
6.4 LUBRICATION OF MACHINE	114
6.4.1 LUBRICATION.....	114
6.4.2 REOILING.....	114
6.5 LUBRICATION TABLE	117
6.5.1 APPLICABLE LUBRICANTS	117
6.5.2 CAUTIONS ON OILING.....	117
6.5.3 MAINTENANCE AND ADJUSTMENT OF LUBRICATION PUMP	118
6.6 MAINTENANCE AND ADJUSTMENT OF AIR SOURCE AND PNEUMATIC UNITS...119	
6.6.1 AIR SOURCE	119
6.6.2 AIR LINE LUBRICATOR (FIG. 6.6.2)	121
6.6.3 AIR TANK.....	122
6.6.4 JOINT AND HOSE.....	122
6.6.5 CIRCUIT DIAGRAM OF AIR SYSTEM.....	123
6.7 PARAMETER FOR LUBRICATION	129
6.8 ADJUSTMENT OF SLIDEWAY GIBS.....	130
7. TROUBLE SHOOTING	131

1. ATC	131
1.1 WRONG TOOL NUMBER (ARM TYPE)	131
1.2 WRONG TOOL NUMBER (ARMLESS TYPE)	131
1.3 ATC ARM NOT IN POSITION (ARM TYPE)	131
1.4 ATC NOT IN POSITION (ARMLESS TYPE)	132
1.5 ATC HOME NOT IN POSITION (ARM TYPE)	132
1.6 ATC MAGAZINE CAN NOT ROTATE OR NOT SMOOTH (ARMLESS TYPE)	132
2. AIR SYSTEM	133
2.1 AIR PRESSURE LOW	133
3. SPINDLE COOLANT SYSTEM	133
3.1 CAN NOT REACH THE SETTING TEMPERATURE	133
3.2 FUNCTION FAILED	133
4. CHIP FLUSH AND COOLANT	133
4.1 COOLANT FLOW RATE TO LOW	133
4.2 FUNCTION FAILED	134
5. COOLANT THROUGH SPINDLE	134
5.1 COOLANT FLOW RATE TO LOW	134
5.2 FUNCTION FAILED	134
6. CHIP CONVEYOR	135
6.1 NOISE OR RUNNING NOT SMOOTH	135
6.2 FUNCTION FAILED	135
7. VACUUM DUST COLLECTOR	135
7.1 WEAK VACUUM POWER	135
7.2 FUNCTION FAILED	135
8. ALARM MESSAGE	136

MODIFICATION RECORDS

DATE	PAGE	ORIGINAL	MODIFIED	ED	MEMO
2005/06/27	24	NONE	CAT50	D02	
2005/08/12	9-14		ADD LABEL	D03	
	30		ADD 3.3		
	98-112		6.1-6.8		
	113-123		ADD 7,8		
2005/10/11	104-105	NONE	6.1.1 SAFETY CIRCUIT AND DVICE	D04	
			CHECK		
	35	3.3 OF 6 kN	3.3 OF 20 kN		
	THEN 1800mm.THEN 2400mm.		
	49	4.4.1	4.4.1		
	119-124	NONE	6.6.4 CIRCUIT DIAGRAM OF AIR SYSTEM		
	98	NONE	M80-M87		
	9-18	1.4	1.4 ADD LABEL		
2006/06/12	26		FIG.2.3.1	D06	
	52		SUPPLY.....VOLTAGE		
	115		6.6.1 A. e IT ISTURE.		
	116		FIG.6.6.1		
	117		FIG.6.6.2		
	118		6.6.3 AIR TANK		
2007/09/06			Chp4.5,5,6,7,8	D07	

1. SAFETY INTRODUCTION

**WARNING: FAILURE TO FOLLOW THESE RULES MAY CAUSE
RESULT IN SERIOUS PERSONAL INJURY**

- IN ORDER TO MAINTAIN THE INITIAL MACHINING ACCURACY AND PERFORMANCE, THE MACHINE MUST BE CORRECTLY USED UNDER THE FAVORABLE ENVIRONMENTAL CONDITIONS.
- INADEQUATE OPERATION MAY CAUSE DAMAGES TO THE MACHINE ITSELF AND EXTREME CAUSE SERIOUS ACCIDENT TO OPERATOR.
- TO PREVENT SUCH TROUBLES, PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY UNTIL YOU REACH COMPLETE UNDERSTANDING AND THEN OPERATE THE MACHINE.
- THE FOLLOWING CAUTIONS ARE PARTICULARLY IMPORTANT TO BE OBSERVED FOR SAFE OPERATION.

1.1 FOREWORD

- SV-8045/8045A
- THE SV-8045A MACHINING CENTER IS IN THE RANGE OF PROFESSIONAL MACHINERY FOR WORKING OF METAL CUTTING, MADE BY LONG CHANG MACHINERY CO., LTD.
- SINCE THE MODEL DESIGN IS NOT ONLY FOR THE DOMESTIC MARKET BUT ALSO THE EUROPEAN MARKET. DURING DESIGN & CONSTRUCTION OF THIS MACHINE, THE ADDITIONAL RELATIVE EUROPEAN STANDARD, FOR THE SAFETY REGULATION HAS BEEN TAKING INTO ACCOUNT BEFORE THE APPLICATION OF CERTIFICATION.

1.2 USING RESTRICTION

1.2.1 THE FORESEEN USE OF THE MACHINE

A. THE PERSON TO USE THIS MACHINE:

ONLY THE TECHNICIAN WHO HAVE BEEN TRAINE TO USE THE MILLING MACHINE AND TO USE THE CNC CONTROL SYSTEM AND ELDER THEN 18 YEARS OLD CAN USE THIS MACHINE.

B. MACHINING MATERIAL:

CASTING, CARBON STEEL, STANDLESS STEEL, COPPER, AND ALUMINUM.

C. MACHINING METHOD :

a. MACHINING BY PROGRAM:

1. MILLING: FACE, OBLIQUE, END, SIDE MILLING, ETC.
2. DRILLING: FRONT AND OBLIQUE DRILLINGS.
3. BORING: FRONT AND OBLIQUE BORINGS BY CUTTERS INSTALLED.
4. MOLDING: PROCESSING OF IRREGULAR CURVES AND MOLD REMOVING ANGLES.
5. POLISHING: SURFACE POLISH ON METALLIC PARTS.

1.2.2 THE FORESEEN OTHER REASONABLE USE OF THE MACHINE

A. THE PERSON TO USE THIS MACHINE:

THE PERSON WHO HAS JUST TRAINED SOME SIMPLE FUNCTIONS (CYCLE START, FEED HOLD, EMERGENCY STOP ...) ----- MUST DIRECT BY TECHNICIAN PERSON DESCRIBED ABOVE.

B. MACHINING MATERIAL:

WOOD ----- THE WOOD DUST MIGHT RUNS INTO BEARING, SIDEWAYS AND CAUSE SOME DAMAGE.

C. MACHINING METHOD: MACHINING BY MANUAL. ----- SHOULD WEAR THE GOGGLES AND ONLY TECHNICIAN PERSON DESCRIBED IN 1.1.1 CAN OPERATE.

1.2.3 THE FORESEEN UNREASONABLE USE OF THE MACHINE

A. THE PERSON TO USE THIS MACHINE :

THE PERSON WHO HAVE NOT BEEN TRAINED OR UNDER 18 YEARS OLD.

1.3 SAFETY INSTRUCTIONS

1.3.1 REACTION WITH EMERGENCY SITUATION:

- A. IN CASE OF ANY EMERGENCY, PUSH THE EMERGENCY STOP BUTTON TO STOP ALL THE MOVEMENT AND THE POWER.
- B. ALL OF THE EMERGENCY STOP BUTTONS ARE COLORED RED, AND YELLOW BACKGROUND.
- C. THE STANDAR MACHINE PROVIDES ONE EMERGENCY STOP BUTTON IN THE OPERATION PANEL.
- D. FOR DIFFERENT OPTIONS THERE COULD BE MORE EMERGENCY STOP BUTTONS SUCH AS:
 - a. 24 / 32 TOOL CHANGER
 - b. FLAP TYPE CHIP CONVEYOR.
 - c. REMOVEABLE HANDWHEEL (MPG.)
- E. AFTER EMERGENCY STOP, FOLLOW THE NORMAL START UP PROCEDURE AND SUITABLE OPERATION.

1.3.2 SETTING UP THE MACHINE AND POWER

- A. THE ENVIRONMENT TO SET UP THE MACHINE
 - a. THAT THIS MACHINE CANNOT BE USED IN THE POTENTIAL EXPLOSIVE ENVIROMENT. GENERALLY, THIS MACHINE WILL BE INSTALLED ON THE FOLLOWING CONDITION.
 - 1. AMBIENT TEMPERTURE:5°~40°C
 - 2. RELATIVE HUMIDITY: NOT EXCEED 50% AT 40°C
(HIGHER RELATIVE HUMIDITY MAY BE PERMITTED AT LOWER TEMPERTURE, E.G. 90% AT 20°C)
 - 3. ATMOSPHERE: FREE FROM EXCESSIVE DUST, ACID FUME, CORROSIVE GASES AND SALT.
 - 4. AVOID ECPOSING TO DIRECT SUNLIGHT HEAT RAYS WHICH CAN CHANGE THE ENVIRONMENTAL TEMPERTURE.
 - 5. AVOID EXPOSING TO ABNORMAL VIBRATION.
 - 6. HAVE TO CONNECT TO EARTH.
(A TERMINAL FOR THE CONNECTION IF THE EXTENAL GROUND CONDUCTOR IS PROVIDED IN THE VICINITY OF THE ASSOCIATED PHASE CONDUCT TERMINAL WITH MARKED " PE". IT SHOULD MAKE SURE THE "PE" TERMINAL BEING CONNECTION BEFORE MACHINE OPERATE)
 - 7. THE LIMITE OF ATTITUDE: 0-1000 METER.
 - 8. ELECTRICAL EQUIPMENT SHALL WITHSTAND THE EFFERTS OF TRANSPORTATION AND STORAGE TEMPERTURE WITHIN A RANGE OF -25°C TO 55°C.
- B. CONNECTION AND DISCONNECTION OF POWER CABLE

- a. SUPPLY VOLTAGE: 0.9 - 1.1 NOMINAL SUPPLY VOLTAGE
- b. SOURCE FREQUENCY: 0.99 - 1.01 NOMINAL FREQUENCY
- c. WHEN THE POWER CABLE IS DISCONNECTED AND CONNECTED AGAIN, CARE SHOULD BE EXERCISED TO CONNECT EACH TERMINAL IN THE CORRECT PHASE (L1, L2, L3 PHASES).

FOR DETAILS OF THE CONNECTION OF THE POWER CABLE, REFER TO CHAPTER 4.4 SWITCHING ON THE POWER SOURCE AND CHECKING."

1.3.3 WHEN OPERATING

- A. THE OPERATOR SHOULD WEAR SAFETY SHOES AND GOGGLES.
- B. WARM THE MACHINE 15 - 30 min. DAILY, BEFORE OPERATION.
- C. CHECK IF THE WORKPIECE IS SECURELY LOCKED ON THE TABLE BEFORE MACHINING.
- D. MOVE THE TOOLS AWAY FROM WORKPIECE BEFORE STARTS THE SPINDLE.
- E. MANUAL REFERENCE POINT RETURN AFTER TURNING ON THE POWER SWITCH.

AFTER THE POWER SWITCH IS TURNED ON, DO NOT FORGET TO RETURN THE SPINDLE HEAD, SADDLE AND TABLE TO THE REFERENCE POINT IN MANUAL OPERATION MODE.

- F. INSTALL PULL STUD TIGHTLY
 - a. THE PULL STUD SHOULD BE SECURELY INSTALLED TO THE GIVEN TOOL SHANK.
 - b. IF THE PULL STUD IS LOOSE DURING CUTTING, THE TOOL CANNOT BE SECURELY CLAMPED IN THE SPINDLE. SINCE LOOSENED TOOL IS VERY DANGEROUS, BE SURE TO CHECK THE PULL STUD BEFORE STARTING THE OPERATION.
- G. USE OF SPECIFIED PULL STUD
 - a. DO NOT USE A PULL STUD NOT SPECIFIED BY US, OTHERWISE THE TOOL CANNOT BE SECURELY CLAMPED IN THE SPINDLE.
 - b. THEREFORE, ALWAYS USE ONLY THE PULL STUD CONFORMED TO THE STANDARD.
 - c. DO NOT USE A PULL STUD MADE IN YOUR FACTORY.
- H. INSTALLATION AND REMOVAL OF TOOL TO AND FROM SPINDLE BY HAND
 - a. WHEN TOOL IS INSTALLED TO THE SPINDLE, CARE SHOULD BE TAKEN AS FOLLOWS:
 - 1. THE TOOL AND SPINDLE BORE TAPERS SHOULD BE CLEAN.
 - 2. DO NOT RELEASE HAND FROM THE TOOL UNTIL IT IS ASSURED THAT THE TOOL IS SECURELY CLAMPED IN THE SPINDLE.
 - 3. INSTALL THE TOOL UPRIGHT, BUT DO NOT TILT.

NOTICE: SINCE AIR FOR CLEANING OF THE SPINDLE BORE AND TOOL TAPER BLOWS FROM THE SPINDLE BORE WHEN THE UNCLAMP SWITCH ON THE OPERATION PANEL IS PRESSED, CAREFULLY AND SECURELY HOLD THE TOOL BY HAND AND PREVENT FROM DROPPING OF THE TOOL.

- I. WHEN THE TOOL IS REMOVED FROM THE SPINDLE BY HAND, CARE SHOULD BE TAKEN AS FOLLOWS:
 - a. AT THE SAME TIME AS THE UNCLAMP SWITCH ON THE OPERATION PANEL IS PRESSED, THE PULL STUD IS PRESSED DOWN AND THE TOOL GOES DOWN APPROXIMATELY 0.5mm (0.02 inch). SINCE AIR BLOW PRESSURE ENHANCES PRESSING DOWN MOVEMENT OF THE TOOL, SECURELY HOLD THE TOOL BY HAND.
 - b. AS MENTIONED ABOVE, THE TOOL GOES DOWN WHEN IT IS REMOVED, BE SURE TO RAISE THE SPINDLE HAND AT A POSITION HIGH ENOUGH TO PREVENT CONTACT OF THE TOOL WITH THE WORK OR TABLE.
- J. DO NOT ALLOW HAND TO GAIN ACCESS WITHIN THE MOVABLE RANGE OF ATC UNIT.

IT IS VERY DANGEROUS TO ALLOW YOUR HAND TO GAIN ACCESS WITHIN THE MOVABLE RANGE OF THE ATC UNIT OR TO TOUCH THE PERIPHERY OF THE ATC UNIT.
- K. WHEN THE SPINDLE IS UNDER ORIENTATION, DO NOT INSTALL AND REMOVE THE TOOL, WHICH IS PROHIBITED FROM USING A HOLDER IN THE SPINDLE UNDER ORIENTATION, TOGETHER WITH TOOL HOLDER, OTHERWISE THE SPINDLE MIGHT BE DAMAGED.
- L. DO NOT USE A HEAVY TOOL.
 - a. THE MAXIMUM WEIGHT OF THE TOOLS APPLICABLE TO THE MACHINE IS 7kg (20 TOOLS ATC) AND 8 kg (24 / 32 TOOLS ATC) .
 - b. DO NOT USE TOOLS HEAVIER THAN 7 kg OR 8 kg.
 - c. REFER TO PAGE 2-8
- M. DO NOT USE A LARGE TOOL.
 - a. FOR 18 TOOLS ATC

THE MAXIMUM DIAMETER OF THE TOOLS APPLICABLE TO THE MACHINE IS 80 mm (3.1 inch) WHEN TOOLS ARE ADJACENTLY ACCOMMODATED IN THE MAGAZINE. HOWEVER, THE TOOL HAVING THE MAXIMUM DIAMETER OF 140 mm (5.5 inch) IS APPLICABLE WHEN IT IS PLACED IN A MAGAZINE TOOL POST, BOTH THE ADJACENT TOOL POSTS OF WHICH ARE VACANT. DO NOT USE TOOLS LARGER THAN THESE DIAMETERS.
 - b. FOR 24 / 32 TOOLS ATC

THE MAXIMUM DIAMETER OF THE TOOLS APPLICABLE TO THE MACHINE IS 100 mm (3.9 inch)
 - c. REFER TO PAGE 1-8
- N. THE FRONT DOOR PROTECTION

- a. NORMALLY OPERATOR SHOULD CLOSE THE DOOR BEFORE DOING ANY MOVMENT OF THE MACHINE.
- b. IF OPERATED BY OPENING THE FRONT DOOR AND MACHINING BY MANUAL, BE SURE TO WEAR THE GOGGLES, AND ONLY TECHNICIAN PERSON WHO HAS BEEN TRAINED CAN OPERATE IN THIS WAY.
- c. FOR MACHINE WITH CE MARK, THERE ARE SECURITY SWITCH FOR DOOR OPEN OPERATION, REFER TO CHPTER 5 FOR MORE INFORMATION.

O. CAUTION TO USE 10,000 /min SPINDLE

IN ORDER TO HAVE LONGER LIFE TIME OF THE HIGH PRECISION SPINDLE, WE RECOMMEND TO WARM UP THIS SPINDLE EVERYDAY BEFORE PUT INTO HIGH SPEED MACHINING. PLEASE RUN THE SPINDLE IN LOWER SPEED BETWEEN 1,000 TO 3,000 /min ABOUT 15 - 30 min. AFTER THAT YOU ARE FREE TO RUN THE MAX. SPEED 10,000 /min.

P. SPINDLE CHILLIER SETTING

THIS OPTIONAL SYSTEM IS TO KEEP THE HEAD STOCK MORE STABLE. WE RECOMMEND TO SET THE TEMPERATURE TO 0 - -1⁰ C DEGREE. THIS SYSTEM MAY OPERATE AUTOMATICALLY COMPARE WITH THE ROOM TEMPERATURE.

1.3.4 LUBRICATION, AIR AND COOLANT

A. LUBRICATING OIL SHORTAGE

- a. IF LUBRICATING OIL RUNS SHORT, THE SLIDE WAYS AND BALL SCREWS IN X, Y AND Z AXIS WILL BE RAPIDLY WORN AND THE MACHINE IS DEGRADED.
- b. BE SURE TO CHECK AMOUNT OF LUBRICATING OIL EVERYDAY AND REPLENISH IF NECESSARY.
- c. IF THE LAMP LUBRICATION LEVEL LIGHTS, IMMEDIATELY REPLENISH.

B. AIR SOURCE

- a. SINCE EACH PNEUMATIC UNIT AND DEVICE IS DESIGNED TO WORK ON THE AIR SOURCE AT 5.5 bar, ALWAYS SUPPLY COMPRESSED AIR AT 6 bar TO THEM.
- b. THE AIR SOURCE SHOULD BE AT CONSTANT PRESSURE. ALTHOUGH AIR FILTER IS INSTALLED AT THE AIR INTAKE TO PROTECT THE PNEUMATIC UNIT, THE SUPPLIED AIR SHOULD BE FREE FROM MOISTURE, OIL AND DUST, AND PURIFIED BY AIR FILTER OF 5 MICRONS MESH.

NOTICE: FOR LONG-TERM USAGE OF THE MACHINE, THE QUALITY OF THE AIR IS VERY IMPORTANT. BED QUALITY OF THE AIR MAY DAMAGE THE PNEUMATIC DEVICES AND CAUSE FAILURE OF MECHANICAL MOTION

- c. TOO HIGH OR LOW AIR PRESSURE

1. THE REQUIRED PRESSURE OF THE AIR SOURCE GIVEN TO THE MACHINE IS 5.5 bar.
2. TOO HIGH AIR PRESSURE CAN CAUSE TROUBLE WITH PNEUMATIC UNIT OR DEVICE.
3. WHILE TOO LOW AIR PRESSURE CAN RESULT IN UNSTABLE OPERATION OF PNEUMATIC UNIT OR DEVICE.
4. IF AIR PRESSURE GOES DOWN BELOW 4 bar, THE LAMP AIR PRESSURE ON THE OPERATION PANEL LIGHTS, THE ALARM BUZZER SOUNDS AND TOOL CHANGE BECOMES IMPOSSIBLE.
5. SEE CHAPTER 6 FOR MORE INFORMATION.

d. ADJUSTMENT OF AIR FLOW RATE TO EACH CYLINDER

THE AIR FLOW RATE TO EACH CYLINDER SHOULD BE ADJUSTED BY RESPECTIVE SPEED CONTROLLER TO THE FOLLOWING VALUE:

1. ATC CROSSWISE MOVEMENT (FORWARD / BACK) 1 sec. (18 TOOLS ATC)
2. ATC MAGAZINE VERTICAL MOVEMENT (DOWN) 1 sec. (18 TOOLS ATC)

C. COOLANT

- a. DO NOT TURN ON THE COOLANT PUMP, UNLESS THERE IS ENOUGH COOLANT IN THE TANK, OR THE COOLANT PUMP WILL BROKEN SHORTLY.
- b. WHEN CHANGE THE COOLANT, IT IS SUGGESTING OPERATED WITH PUMP EQUIPMENT TO FILL IN AND EMPTY THE LIQUID TO REACH THE LEVEL.
- c. IF THE LIQUID FLOW OVER TO GROUND, USE CLOTH TO CLEAN THE LIQUID IN ORDER TO PREVENT FORM ACCIDENT.
- d. IT IS SUGGEST USING COOLANT LIQUID WITH ENVIRONMENTAL PROTECTION APPROVAL.

D. PREVENT FROM FIRE

TO PREVENT FIRE, OBEY THE FOLLOWING INSTRUCTIONS FOR UN-MANNED OPERATION AT NIGHT OR FOR CASES WHEN OPERATOR HAS TO BE AWAY FROM THE MACHINE FOR A LONG TIME.

1. USE NON-FLAMMABLE COOLANT ONLY.
2. CHECK THAT LUBRICATION OIL AND COOLANT ARE SUFFICIENT AND ARE WORKING PROPERLY.
3. CHECK THE TOOL TIPS, CUTTING CONDITIONS, CYCLE TIME, TOOL LIFE, ECT.
4. NEVER PLACE FLAMMABLE ITEMS, SUCH AS WOODEN BLOCKS, PAPER, CLOTH, ECT., AROUND THE MACHINE.

1.3.5 HEALTHY AND SAFETY PROTECTION

A. NOISE OF THE MACHINE

a. CONDITIONS :

1. PLACEMENT/INSTALLATION : FLOOR-STANDING
2. HIGHT ABOVE THE FLOOR : STANDING OPERATOR.
3. MEASUREMENT DISTANCE $D = 1\text{M}$
4. MEASUREMENT TIME PER POSITION = 30S
5. MESUREMENT POSITION = 26 POSITIONS

b. SUMMERY

1. A WEIGHTED SOUND PRESSURE UNDER NO LOAD
2. $LP, EQ = 73.9 \text{ DB(A)}$.
3. A WEIGHTED SOUND PRESSURE UNDER LOAD
4. $LP, EQ = 79.4 \text{ DB(A)}$.

NOTICE: CUTTING DIFFERENT WORKPIECE MAY CAUSE LOUDER NOISE. WHEN WORKING LONG TIMES IN CUTTING WORKPIECE BE WARE TO WEAR EARPLUGS.

1.3.6 MAINTENANCE AND CHECK

A. MOVE THE TOOLS AWAY FROM WORKPIECE BEFORE MAINTENANCE OR ANY CHECK OF THE MACHINE OR WORKPIECE.

B. SWITCH OFF THE MAIN POWER BEFORE MAINTANCE.

1.3.7 RESCUE THE PERSON WHO TRAPPED INTO MACHINE

IF OPERATOR FALLS INTO MACHINE SHUT OFF THE EMERGENCY SWITCH IMMEDIATELY AND KEEP THE FRONT DOOR OPEN. THEN SAVE THE PERSON FROM FRONT DOOR OR SIDE WINDOWS.

1.4 WARNING LABEL AND POSITION




FIG. 1.4.1 WARNING LABEL POSITION




FIG. 1.4.2 WARNING LABEL POSITION






FIG. 1.4.3 WARNING LABEL POSITION



LABEL A



LABEL B



LABEL C


GENERAL SAFETY PRECAUTIONS

1. Before operating the machine, read intensively the Instruction Manual. In particular, read carefully the description for safety and maintenance, and follow its instruction.
 2. During operation, close the doors and covers, and avoid access to the rotating and moving parts of the machine.
 3. Do not operate the machine with protective covers. Inter locks and the other safety devices removed.
 4. Be sure to clamp the workpiece and cutting tools, and do not place a used tool on the moving parts. Also, for proper machining, select the optimum feedrate and spindle speed.
 5. Wear proper habiliments (working clothes, shoes, cap, protective glasses, etc.) to ensure safety work.
 6. Repair the machine only by the approved personnel following the Instruction Manual.
- in addition, turn the power switch OFF during repair.
- Execute safety work on user's own responsibility by observing the safety precautions provided on the Instruction Manual and the WARNING label attached on the machine. Negligence of warning could cause personal injury or machine damage.


Do not peel off or dirty this plate.

1000-C109B


LABEL D



LABEL E




LABEL F



LABEL G


MODEL: _____	Rated power: _____ kVA
MFG NO: _____	Power supply: 3~ _____ V _____ Hz
MFG Date: _____	Full load current: _____ A
	Machine weight: _____ kg
	Pneumatic pressure: _____ > 5.5 _____ bar
	Spindle speed range: Max. _____ /min




LONG CHANG MACHINERY CO., LTD.
 NO.52,CHARN AN EAST ROAD, TAIPING, TAICHUNG, TAIWAN,R.O.C.
 TEL: +886-4-2392-1001 FAX: +886-4-2392-1037 <http://www.first.com.tw>

18VH-C270E


LABEL H




LABEL I
(OPTION)




LABEL J



LABEL K



LABEL L



LABEL M

1.5 OPERATION AREA




FIG 1.5.1 OPERATOR POSITION

1.6 DISPOSE OF WASTE

- A. ALL THE WASTE SHOULD BE TAKING CARE BY THE RULE OF LOCAL GOVERNMENT.
- B. THE CUTTING CHIP WASTE IS ALWAYS SHARP, DO NOT TOUCH, OR CLEAN THE CHIPS DIRECTLY BY HAND.
- C. MOST OF THE CUTTING CHIP ARE RECYCLABLE IT IS SUGGESTED TO RECYCLE THE CUTTING CHIP BY LOCAL RECYCLE AGENT.
- D. DISPOSE OF LIQUID WASTE SUCH AS WASTE OIL AND COOLANT IS NECESSARY TO ASSOCIATE WITH LOCAL RECYCLE AGENT.

1.7 OTHER NOTICES

- A. IF THE WORK PIECE IS HEAVIER THAN 10 kg, PLEASE USE SHOP HANGING EQUIPMENT TO MOVE THE WORK PIECE.




FIG 1.7.1 HEAVY PART HANGING

- B. IN CASE OF MAINTENANCE, SERVICING, AND PARTS CHANGES, PLEASE CONTACT OUR SALES AGENCIES OR BUSINESS DEPARTMENT DIRECTLY.
- C. SUGGESTIONS FOR IMPROVEMENTS OF THE MACHINE STRUCTURE AND / OR INQUIRIES, INCLUDING PLANT VISITATIONS, ARE CORDIALLY WELCOME.
- D. THE MANUFACTURER REVERSES THE RIGHT TO MODIFY THE DESIGN, OPERATIONS, STRUCTURE ETC. ALL OF THE MACHINE WITHOUT ANY PRIOR NOTICE.

2. GENERAL INFORMATION

2.1 GENERAL DESCRIPTION OF THE MACHINE

- A. THE MODEL MCV600/800/1000 IS THE VERTICAL SPINDLE MACHINING CENTER FEATURING ELECTRONIC CONTROL EQUIPMENT BUILT-IN COMPACT DESIGN, PERFORMANCE, ACCURACY AND RELIABILITY.
- B. THE MODEL BASICALLY CONSISTS OF THE FOLLOWINGS:
 - a. MACHINE BODY (INCLUDING SPINDLE HEAD, SPINDLE, COLUMN, BED, SADDLE AND ATC)
 - b. OPERATION PANEL
 - c. NC SYSTEM
 - d. ELECTRIC (POWER SUPPLY) CABINET
 - e. PNEUMATIC UNIT
- C. THE APPEARANCE AND PRINCIPAL DIMENSIONS OF THE MACHINE AND THE NAME OF EACH PRINCIPAL COMPONENT ARE AS SHOWN IN FIG. 2.1.1 AND 2.1.2




FIG. 2.1.1 PRINCIPAL COMPONENT NAME




FIG. 2.1.2 APPEARANCE AND PRINCIPAL DIMENSION OF THE MACHINE

2.2 DETAILS OF PRINCIPAL COMPONENT

2.2.1 SPINDLE HEAD

- A. THE SPINDLE HEAD IS MOUNTING ON THE SQUARE SLIDE WAYS, WHICH IN TURN ARE VERTICALLY INSTALLING ON THE COLUMN FRONT.
- B. THE SPINDLE HEAD IS VERTICALLY (IN Z AXIS) MOVES ALONG THE SLIDE WAYS.
- C. A PRACTICALLY MAINTENANCE-FREE AC BRUSHLESS MOTOR IS USED TO DRIVE THE SPINDLE ASSURING IN ASSOCIATION WITH LARGE DIAMETER BEARING SYSTEM, EXTREMELY HIGH PERFORMANCE.
- D. CARTRIDGE SPINDLE IS SUPPORTING BY ACCURATE AND GREASED PACKED BEARINGS.
- E. TOOL HOLDER RETAINER AND AIR BLOW THAT REMOVES CHIPS FROM THE SPINDLE AND TOOL TAPER ARE INCORPORATE IN THE SPINDLE.
- F. THE SPINDLE HEAD FEATURES SIMPLE STRUCTURE AND RELIABLE PERFORMANCE.

2.2.2 COLUMN

- A. THE COLUMN IS FIRMLY BOLTED TO THE BED, AND DESIGNED TO HAVE PARTICULAR RIGIDITY. THE SLIDE WAYS ALONG WHICH THE SPINDLE HEAD MOVES ARE OF SQUARE TYPE, AND ELABORATELY GROUND AFTER HARDENING. A TURCITE-B SHEET IS APPLIE TO THE SLIDE SURFACE OF THE SPINDLE HEAD, PROVIDING GOOD ACCOMMODATION TO THE SLIDE WAYS.
- B. THE ATC (AUTOMATIC TOOL CHANGER) IS LOCATED AT THE LEFT OF THE COLUMN AND THE PNEUMATIC VALVES IS AT THE BACK OF THE ATC.
- C. THE MOTOR THAT DRIVES THE SPINDLE HEAD IN Z AXIS (VERTICAL MOVEMENT) IS INSTALLE ON THE TOP OF THE COLUMN.

2.2.3 BED

- A. THE BED IS PROVIDE WITH LEVELING BOLTS AT ITS FEET, AND HAS THE SECTION WHERE THE COLUMN IS INSTALLE AS WELL AS THE SLIDE WAYS OF SQUARE TYPE ON THE TOP OF THE BED.
- B. THE Y AXIS (CROSSWISE MOVEMENT) FEED MOTOR ARE INSTALLE ON THE BACK WALL OF THE BED.
- C. SINCE THE BED SUSTAINING THE WEIGHT OF THE COLUMN MUST ASSURE RELIABLE Y AXIS MOVEMENT, AND LARGELY AFFECTS CUTTING ACCURACY, IT IS DESIGNE TO HAVE EXTREME RIGIDITY.
- D. IT IS ALSO CONSIDER IN DESIGNING THE BED THAT CHIPS AND CUTTING OIL CAN BE READILY ELIMINATED AND COLLECTED.

2.2.4 TABLE

- A. THE TABLE IS THE ONLY PLACE WHERE YOU CAN LOCK YOUR WORK PIECE ON IT AND MACHINING, IT MOVES ON THE SADDLE IN LENGTHWISE DIRECTION (X AXIS).

2.2.5 ATC (AUTOMATIC TOOL CHANGER)

- A. THE ATC IS INSTALLED ON THE LEFT WALL OF THE COLUMN. THE ATC PERMITTING DIRECT TOOL CHANGE; ANY TOOL CAN BE IMMEDIATELY AND RELIABLY CHANGED.
- B. THE FEATURES OF THE ATC INCLUDE PNEUMATICALLY DRIVE SYSTEM, SIMPLE STRUCTURE, FAST MOVEMENT, AND RAPID BI-DIRECTIONAL RANDOM TOOL SELECTION IS DIRECTLY DESIGNATED TOOL NO. WITH T CODE. (24 / 32 TOOLS CAM TYPE ATC ARE AVAILABLE AS AN OPTION)

2.2.6 OPERATION PANEL

- A. THE OPERATION PANEL IS LOCKED IN THE RIGHT FRONT OF THE MACHINE, AND BASICALLY CONSISTS OF THE NC OPERATION PANEL, IN WHICH PROGRAM LOADING FROM TAPE TO THE MEMORY, PROGRAM EDITING AND MID OPERATION ARE PERFORMED, AND THE OPERATION PANEL (OPERATOR'S STATION) HAVING CONTROL SWITCHES AND PUSH BUTTONS ON THE PANEL AND FUNCTIONAL SWITCHES IN THE PANEL.
- B. ALMOST ALL CONTROL SWITCHES AND PUSH BUTTONS NECESSARY TO OPERATE THE MACHINE ARE INSTALLED ON THE OPERATION PANEL, THUS THE OPERATOR CAN READILY CONTROL THE MACHINE OPERATION AT THE FRONT OF THE OPERATION PANEL.

2.2.7 NC SYSTEM

- A. THE NC SYSTEM READS SIGNIFICANT INFORMATION FROM THE PROGRAM, AND PRODUCES COMMAND OR INSTRUCTION TO SEQUENTIALLY CONTROL THE MACHINE MOVEMENT AND OPERATION.
- B. THE NC SYSTEM IS NORMALLY LOCATED IN THE ELECTRIC CABINET.

2.2.8 ELECTRIC CABINET

- A. THE ELECTRIC CABINET RECEIVES THE COMMAND SIGNALS FROM THE NC SYSTEM, AND DRIVES THE MACHINE. IN THE ELECTRIC CABINET, RELAY CIRCUIT AND POWER SOURCE CIRCUIT ARE INCORPORATED.

2.2.9 PNEUMATIC UNIT

- A. THE FUNCTIONS OF THE PNEUMATIC UNIT INCLUDE
 - a. TOOL UNCLAMPING AT THE SPINDLE,
 - b. AIR BLOWING FOR CLEANING THE SPINDLE AND TOOL TAPER.
 - c. ATC CROSSWISE MOVEMENT AND ATC MAGAZINE VERTICAL MOVEMENT.(18 ATC)
 - d. TOOL POT UP/DOWN (24/32 ATC)
- B. ONLY STRICTLY SELECTED PARTS AND DEVICES ARE USED IN THE PNEUMATIC UNIT, THUS ASSURING STABLE AND RELIABLE OPERATION

2.3 MACHINE SPECIFICATIONS

SPECIFICATION MAY DIFFERENT ACCORDING TO CUSTOM REQUEST OR OPTIONS.

TABLE

	MCV 2000
WORKING SURFACE (X X Y)	2200 X 1000 mm (88 X 39 inch)
T SLOT (NO. X WIDTH X PITCH)	22 X 6X 160 mm (0.86 X 6 X 6.3 inch)
TABLE STROKE (X X Y)	2050 X 1150 mm (80 X 45 inch)
CUTTING FEEDRATE	1-8000 mm/min (0.04-315 inch / min)
RAPID TRAVERSE (X , Y)	20,000 mm/min (787 inch /min)
RAPID TRAVERSE (Z)	15,000 mm/min (590 inch /min)
X,Y FEED MOTOR (AC SERVO UNIT)	22Nm AC MOTOR
Z FEED MOTOR (AC SERVO UNIT)	30Nm AC MOTOR
TABLE LOAD CAPACITY	3000 kg (6600 lbs)




FIG. 2.3.1 PRINCIPAL DIMENSIONS OF TABLE

SPINDLE

	MCV 2000	
	40 TAPER SPINDLE (DIRECT DRIVEN)	50 TAPER SPINDLE (GEAR DRIVEN)
STROKE (Z)	760 mm (30 inch)	
SPINDLE MOTOR	15 kW /18.5 kW (30min)	15 kW /18.5 kW
SPINDLE SPEED	120-6,000 /min 180-10,000 /min 240-20,000 /min (build-in)	40-4000 /min 40-6000 /min
MAX. SPINDLE MOMENT OF INERTIA	190 Nm	1000Nm
PULL STUD	MAS-P40T-1 45 DEGREE	MAS-P50T-1 45 DEGREE

AUTOMATIC TOOL CHANGE (ATC)

	TOOL STORAGE CAPACITY	
	40 TAPER SPINDLE	50 TAPER SPINDLE
TOOL CHANGE TIME (TOOL TO TOOL)	4 sec.	5 sec
MAX. ADJACENT TOOL DIAMETER	100 mm (3.9 inch)	110 mm (4.3 inch)
MAX. TOOL WEIGHT	7 kg (15 lbs)	15 kg (33 lbs)
MAX. TOOL LENGTH	300 mm (11.8 inch)	
MAX. TOOL POT WEIGHT	10 kg (22 lbs)	17 kg (37.4 lbs)
MAX. TOOL CHANGE MOMENT OF WERTIA	0.858 kgm ²	1.838 kgm ²

GENERAL INFORMATION

	MCV 2000	
AIR POWER REQUIRED	5.5 bar	
FLOOR TO TABLE	810 mm (32 inch)	800 mm (31.5 inch)
MACHINE HEIGHT	3,800 mm (150 inch)	
MACHINE WEIGHT	14,000 kg (31000 lbs)	
FLOOR AREA REQUIRED	7000mm(275.6")(W)x 4000mm(157.5")(D)	

2.4 MACHINING AREA

- IT IS RECOMMEND TO PUT THE MACHINING PARTS OR FIXTURE NEAR THE CENTER OF THE TABLE.
- BIG FIXTURE OR PARTS MAY HIT MACHINE BODY OR COVER WHEN TRAVELLING AXIS. MAKE A SLOW TEST RUN REFORE MACHINING.
- BIG OR LONG TOOLS MAY HIT MACHINE BODY OR COVER WHEN TRAVELLING AXIS. MAKE A SLOW TEST RUN REFORE MACHINING.
- BEFORE STOP MACHINE, IT IS RECOMMEND MOVING THE TABLE TO THE CENTER OF X, Y AXIS. TO PERVENT FROM BENDING OF THE MACHINE.

2.4.1 MACHINING AREA




FIG. 2.4.1 MACHINING AREA





FIG. 2.4.2 GRAVITY CENTER

2.5 TOOL SHANK AND STUD


BT SHANK




Unit: mm

Model No.	D1	D2	d1	d2	L	T1	T2	T3	T4	b	l
BT40	63	44.45	17	M16	65.4	25	10	16.6	2	16.1	22.6
BT50	100	69.85	25	M24	101.8	35	15	23.2	3	25.7	35.4


BT40 STUD



BT50 STUD





CAT SHANK TAPER (ANSI B5.50-78)



UNIT: inch
(mm)



	D1	D2	D6	D8	L1	L2	F2	F3	A	G
CAT40	1.750 (44,45)	.641 (16,28)	2.500 (63,05)	1.750 (44,45)	2.687 (68,25)	.188 (4,78)	1.375 (35,00)	.625 (15,88)	.125 (3,18)	5/8-11 thread
CAT50	2.750 (69,85)	1.031 (26,19)	3.875 (98,43)	2.750 (69,85)	4.000 (101,6)	.25 (6,35)	1.375 (35,00)	.625 (15,88)	.125 (3,18)	1"-8 thread

CAT40 STUD




Cooling Though Spindle

CAT50 STUD



Cooling Though Spindle


DIN69871A



Unit: mm

Taper	b H12	d1	g	d3 H7	d6 -0.1	d7	L1 -0.3	L5 -0.3	L6 -0.4	L7 -0.4
40	16.1	44.45	M16	17	63.55	56.25	68.4	18.5	22.8	25
50	25.7	69.85	M24	25	97.50	91.25	101.75	30	35.5	37.7

DIN STUD



	d1 f7	d2 0 -0.1	d3 0 -0.2	d4 g6	d5	d6 +0.1 0	L1	L2 ±0.1	L3 ±0.1	L4 +0.5 0	L5	s 0 -0.1
DIN 40	19	14	23	17	M16	7	54	26	20	21	4	19
DIN 50	28	21	36	25	M24	11.5	74	34	25	30	5	30

3. TRANSFER AND INSTALLATION OF MACHINE

3.1 HANGING OF MACHINE

BEFORE HANGING AND TRANSFERRING THE MACHINE, BE SURE TO CHECK THE TRANSFERRING ROUTE FOR SAFETY. LOCATE THE SADDLE BY THE COLUMN, AND THE TABLE AT THE CENTER OF ITS STROKE TO BALANCE THE MACHINE.

WE BALANCED THE MACHINE BEFORE SHIPPING.

MACHINE WEIGHT:

SV-8045A
19,000 kg (41800 lbs)

- A. CHECK THE HOOK, HANGING DEVICE AND LIFT FORK CAREFULLY BEFORE HANGING AND LIFTING FOR SAFTY OPERATION.
- B. DURING MOVING THE MACHINE, FOR SAFTY OPERATION, EVACUATE THE MACHINE MOVING AREA, NO PEOPLE SHOULD NEAR THE MACHINE.
- C. WHEN LOCATE THE MACHINE BE WARE TO CLEAR THE LOCATION AREA (MAKE SURE THERE IS NO PIPE, CABLE ...)
- D. BEFORE HANGING THE MACHINE, TAKE OFF THE UPPER COVER OF COLUMN AS SHOWN IN FIG. 3.1 .1TO PREVENT FROM DAMAGE OF THE MACHINE.
- E. THE MACHINE HAS HOOKS. TO HANG THE MACHINE, APPLY TWO WIRE ROPE, OR SLING, TO THE HOOKS AS SHOWN IN FIG. 3.2.1.
- F. BEFORE HANGING THE FRONT POINT OF THE MACHINE, TAKE OFF THE FRONT COVER OF Y AXIS TO FIND OUT THE HANGING POINT.
- G. BE SURE TO USE A WIRE ROPE OF A SIZE LARGER THAN HOOK SIZE AND MAKE SURE THAT THE WIRE ROPE DOES NOT LEAVE THE HOOKS DURING TRANSFERRING OF THE MACHINE.
- H. PUT A RUBBER SHEET OR RAG ON THE MACHINE SURFACE WITH WHICH THE WIRE ROPE CAN COME INTO CONTACT TO PREVENT DAMAGE TO THE MACHINE SURFACE (PAINT).
- I. DURING HANGING AND TRANSFERRING OF THE MACHINE, USE CARE NOT TO GIVE DETRIMENTAL VIBRATION OR SHOCK TO THE MACHINE, AND TO MAINTAIN THE MACHINE UPRIGHT.

NOTICE: THAT THE MACHINE IS LIABLE TO TILT BECAUSE THE ELECTRICAL UNIT EQUIPPED VERTICAL MACHINING CENTER HAS THE CENTER OF GRAVITY RELATIVELY HIGH POSITION.




FIG 3.1.1 HANGING THE MACHINE

3.2 REFERENCE DIMENTIONS FOR HANGING




FIG 3.2.1 HANGING DIMENSIONS AND POSITION

3.3 MACHINE TRANSPORT BY FORK LIFT

USE A FORK LIFT WITH MINIMUM CAPACITY OF 20 kN

THE LENGTH OF THE FORK MUST LONGER THEN 2400mm.

WHEN MOVING MACHINE KEEP THE POSITION LOWER AND MOVE IT SMOOTH AND SLOWER.




FIG 3.3.1 MACHINE TRANSPORTED BY FORK LIFT

3.4 HANGING OF PARTS AND ACCESSORIES

3.4.1 FRONT COOLANT TANK




FIG 3.4.1 HANGING OF FRONT COOLANT TANK

3.4.2 SIDE COOLANT TANK




FIG 3.4.2 HANGING OF SIDE COOLAN TANK

3.4.3 CHIP CONVEY




FIG 3.4.3 CHIP CONVEYER HANGING

3.4.4 COOLANT SYSTEM




FIG 3.4.4 COOLAN SYSTEM HANGING

3.4.5 OTHER ACCESSORIES

FOR OTHER ACCESSORIES NOT LIST HERE, CHECK WITH YOUR MACHINE AGENT FOR SAFETY HANGING INFORMATION.

3.5 INSTALLATION SPACE

- RESERVED SPACE FOR OPERATION AREA AND MAINTANCE AREA IS NECESSARY FOR SAFTY AND EFFENCY USE OF THE MACHINE AFTER INSTALLATION, FIG 3.5.1.
- IF YOU HAVE ANY QUESTION ABOUT INSTALLTION SPACE, CHECK WITH YOUR MACHINE AGENT BEFORE INSTALLTION.




FIG 3.5.1 INSTALLATION SPACE

3.6 INSTALLATION

THIS INSTALLATION IS ROUGHLY PUT THE MACHINE APPROPRIATELY ON THE SUPPORTING PADS, FOR DETAIL ADJUSTING LEVELING REFER TO CHAPTER 4.

3.6.1 FOUNDATION

- A. THE FOUNDATION ON WHICH THE MACHINE INSTALLED SHOULD BE RIGIDLY CONSTRUCTED WITH CONCRETE.
- B. SINCE MACHINING ACCURACY IS LARGELY GOVERNED BY THE ADEQUACY OF FOUNDATION AND INSTALLATION, ELABORATELY CONSTRUCT THE FOUNDATION AND INSTALL THE MACHINE ON IT.
- C. THE MACHINE SHOULD BE LOCATED WHERE IS NOT SUBJECTED TO VIBRATION FROM OTHER MACHINERY, AND TO DIRECT SUNBEAM.
- D. THE THICKNESS AND SIZE OF THE CONCRETE FOUNDATION SHOULD BE DETERMINED CONSIDERING THE GROUND CONDITION.
- E. WHEN FOUNDATION BOLT IS NOT USED, USE LEVELING PADS FURNISHED TO THE MACHINE TO INSTALL THE MACHINE.

3.6.2 INSTALLATION

- A. CLEAN THE REVERSE SURFACE OF THE LEVELING PADS AND THE SUPPORTING PADS. AND PLACE THE LEVELING PADS AND THE SUPPORTING PADS ACCORDING TO THE FLOOR PLAN FIG 3.6.1
- B. CAREFULLY LOWER THE HUNG MACHINE SO THAT EACH FOOT OF THE MACHINE CAN REST ON THE RECESS OF EACH LEVELING PADS. THEN ADJUST THE LEVEL OF THE MACHINE BY THE LEVELING BOLTS.
- C. WHEN ANCHOR BOLT IS USED, INSTALL THE MACHINE ACCORDING TO THE PLAN.
- D. BECAUSE MORTARED HOLD MAY SINK WITH TIME UNTIL THE MORTAR IS COMPLETELY SET, PERIODICALLY CHECK THE LEVEL OF THE MACHINE FOR 6 TO 8 MONTHS AFTER THE INSTALLATION AND READJUST IF NECESSARY.
- E. FOR CHECKING THE LEVEL, USE A LEVEL VIAL WITH SCALE OF 0.02mm / 1000mm




FIG. 3.6.1 FLOOR PLAN




FIG. 3.6.2 FOUNDATION DRAWING

3.7 INSTALLATION ENVIRONMENT

PLEASE REFER TO CHAPTER 1.3.2 FOR MORE INFORMATION.

4. ASSEMBLY PROCEDURE AND TEST RUN

WARNING: ALL ELECTRIC, HYDRAULIC, COOLANT SYSTEM, PNEUMATIC CONNECTING, AND MACHINE ASSEMBLY MUST BE DONE BY QUALIFIED TRAINED AND AUTHORIZED TECHNICAL PERSON.

QUICK REFERENCE

- 1. CLEANING OF MACHINE**
- 2. REMOVAL OF LOCKING DEVICES**
- 3. LUBRICATION AND AIR PIPING**
- 4. SWITCHING ON THE POWER SOURCE AND CHECKING**
- 5. TAKE OFF SPINDLE HEAD SUPPORT DEVICE**
- 6. LEVELING CHECK**
- 7. ASSEMBLE OF PARTS AND DEVICES**
- 8. DEVICE PIPING INSTRUCTION**
- 9. COOLANT**

4.1 CLEANING OF MACHINE

- A. ANTICORROSIVE AGENT HAS BEEN APPLIED ON THE MACHINE TO PREVENT CORROSION.
- B. REMOVE THE ANTICORROSIVE AGENT BEFORE STARTING TEST RUN.
NOTICE THAT ANY MOVABLE PART OF THE MACHINE, SUCH AS TABLE, SPINDLE HEAD AND ATC, SHOULD NOT BE MOVED BEFORE THE ANTICORROSIVE AGENT HAS BEEN THOROUGHLY REMOVED.
- C. PARTICULAR CARE SHOULD BE GIVEN TO THOROUGHLY REMOVE THE ANTICORROSIVE AGENT FROM THE SLIDE WAYS, ATC AND SPINDLE TAPER.

4.2 REMOVAL OF LOCKING DEVICES

- A. ACCORDING TO THE DRAWING, REMOVE ALL LOCKING DEVICES USED TO SECURE THE MOVABLE COMPONENTS OF THE MACHINE DURING THE TRANSPORT, SUCH AS X AXIS LOCKING DEVICES (A) Y AXIS LOCKING DEVICES (B),
- B. HOWEVER, DO NOT REMOVE THE SPINDLE HEAD LOCKING WOOD BLOCK (C) WHICH SHOULD BE REMOVED AFTER THE POWER SOURCE IS GIVEN TO THE MACHINE. (SHOULD CONTINUE TO READ THIS MANUAL UNTIL 3.5.5 FOR REMOVING ALL LOCKING DEVICES.)
- C. TAKE OFF THE BASE HOOKERS (D) (4 OF THEM)
- D. IF THE SURFACE IS FOUND FOUL AFTER THE REMOVAL OF LOCKING DEVICE OR SCREW THOROUGHLY CLEAN.
- E. ONCE REMOVED PACKING MATERIAL. AND LOCKING DEVICES ARE NO LONGER USED.PUT THEM ASIDE FOR SAFE WORK.

A: X AXIS LOCKING DEVICE
 B: Y AXIS LOCKING DEVICE
 C: LOCKING WOOD BLOCK
 D: BASE HOOKER
 E: DOOR LOCK DEVICE
 F: OPERATION PANEL LOCK DEVICE
 G: Y AXIS MOTOR






FIG. 4.2.1 LOCKING DEVICE

4.3 LUBRICATION AND AIR PIPING

4.3.1 LUBRICATION

- A. BEFORE STARTING THE OPERATION, THE MACHINE SHOULD BE PROPERLY OILED.
- B. USE A HIGH QUALITY, PURE OIL SPECIFIED IN THE LUBRICATION TABLE AND FILL EACH PART. BEFORE STARTING THE TEST RUN,
- C. THE FOLLOWING PARTS SHOULD BE OILED

PART TO BE OILED	Q'TY	LUBRICANT	REMARKS
LUBRICATION PUMP	4.6L	1	
LUBRICATOR OF PNEUMATIC	0.17L	4	

LUBRICANT	SHELL	ESSO	MOBIL
1	SHELL TONNAOIL	FEBIS K68	MOBIL VACTRA OIL NO.2
4	SHELL TURBIN OIL T32	TERESSO 32	MOBIL DTE OIL LIGHT




FIG. 4.3.1 LUBRICATION

4.3.2 AIR PIPING

- A. CONNECT THE PIPES TO THE AIR INLET OF THE PNEUMATIC UNIT.
- B. THE PNEUMATIC DEVICES ARE DESIGNED TO WORK WITH COMPRESSED AIR AT 5.5 bar.
- C. THEREFORE, USE AN AIR SOURCE AT CONSTANT PRESSURE OF AT LEAST 6 bar.
- D. THE AIR PRESSURE HAVE BEEN PROPERLY SET UP BEFORE SHIPPING OUT THE MACHINE, IF ANY PROBLEM PLEASE CHECK CHAPTER 6.

NOTICE: FOR LONG-TERM USAGE OF THE MACHINE, THE QUALITY OF THE AIR IS VERY IMPORTANT. BED QUALITY OF THE AIR MAY DAMAGE THE PNEUMATIC DEVICES AND CAUSE FAILURE OF MECHANICAL MOTION.




FIG. 4.3.2 AIR PIPING

4.4 SWITCHING ON THE POWER SOURCE AND CHECKING

- FOR TRANSPORT REASON, SOMETIMES THE Z AXIS MOTOR, Y AXIS MOTOR OR OTHER MOTOR COULD BE TAKEN OFFBEFORE SHIPPING, IN THIS CASE, ACCSEMBLE THESE MOTORS BEFORE THIS PROCEDURE.
- ONLY OTHERIZED PERSON CAN DO THE MOTOR ASSEMBLE.

4.4.1 WIRING CABLE AND PLACE SEE FIG 4.4.1


NOTICE: MAKE SURE THE VOLTAGE AND CAPACITY IS SAME AS REQUIRED BEFORE WIRING.

PE WIRE mm ²	SUPPLY WIRE mm ²
25.0	25.0

- SUPPLY VOLTAGE: 0.9 - 1.1 NOMINAL SUPPLY VOLTAGE
- SOURCE FREQUENCY: 0.99 - 1.01 NOMINAL FREQUENCY
- WHEN THE POWER CABLE IS DISCONNECTED AND CONNECTED AGAIN, CARE SHOULD BE EXERCISED TO CONNECT EACH TERMINAL IN THE CORRECT PHASE (L1, L2, L3 PHASES).
 - MAKE SURE THAT CLEANING OF MACHINE OILING AND OIL PIPING HAVE BEEN COMPLETED

4.4.2 TO CONNECT THE POWER CABLE

OPEN ELECTRIC CABINET AND CONNECTED TO QF1 AND PE IN THE ELECTRIC CABINET. THE POWER CABLE SHOULD HAVE CRAMP TERMINALS AND EACH TERMINALS SHOULD BE FULLY TIGHTENED WITH PLUS SCREWDRIVER,



POWER SOURCE

ALIMATION : 3PH 50/60Hz L1,L2,L3+PE

SUPPLY : WIRING VOLTAGE MAY DIFFERENT PLEASE CHECK

CABLE LENGTH : MAX: 3m


SUPPLY VOLTAGE: 0.9 - 1.1 NOMINAL SUPPLY VOLTAGE

SOURCE FREQUENCY: 0.99 - 1.01 NOMINAL FREQUENCY

FIG. 4.4.1 POWER SOURCE DRAWING

- TURN ON THE POWER SWITCH TO "ON" POSITION MAKE SURE INTO THE CONTROL POWER SOURCE IS REQUIRED AND FAN WILL ON.
- HOLD DOWN THE PUSH-BUTTON "POWER ON" ON THE NC CONTROL PANEL FOR 2-3 SEC. DURING WHICH THE POWER SOURCE WILL BE GIVEN TO THE SERVO SYSTEM, INVERTER AND OTHER ELECTRIC UNITS AND DEVICES, THEN PERFORM THE FOLLOWING CHECKING

- A. CHECK IF ANY ALARM MESSAGE APPEARS? (CRT OR OP PANEL LED)
- B. CHECK COOLANT PUMP ROTATION, SPINDLE FAN ROTATION, OR ATC ROTATION FOR CORRECT DIRECTION OF POWER SOURCE.




- C. IF ALARM MESSAGE OCCURS REFER TO CHAPTER 7 TROUBLE SHOOTING USING ERROR MESSAGE#, TNC MESSAGE AND ELIMINATE THE CAUSE OF THE ALARM
- D. IF MOTOR DIRECTION RUN WRONG DIRECTION STEP AS NEXT
 - a. TURN POWER OFF ON OPERATION PANEL
 - b. ALSO TURN MAIN POWER SWITCH OFF
 - c. OPEN CABINET (LEFT SIDE) CHANGE POWER CABLE CONNECTION 2 OF 3 WIRES (L1,L2,L3) AGAIN CHECK MOTOR DIRECTION

NOW POWER CABLE CONNECTION HAS BEEN COMPLETED

4.5 TAKE OFF SPINDLE HEAD SUPPORT DEVICE

4.5.1 OPERATE IN DOOR OPEN STATUS WITH NON CE DOOR INTERLOCK SWITCH (OPTION)

- A. WHEN NON CE DOOR INTERLOCK SWITCH IS MOUNTED, PRESS THIS KEY



TO RELEASE DOOR INTERLOCK.

- B. RELEASE DOOR INTERLOCK IN ANY MODE.
- C. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE WHEN DOOR OPENED
- D. DUE TO SAFETY REASON, WHILE DOOR OPEN THE MACHINE CAN ONLY OPERATE IN FOLLOWING STATUS.
- a. SPINDLE SPEED UNDER 50/min
 - b. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE.
 - c. AXIS FEED RATE UNDER 2000mm/min.
- E. CLOSE DOOR TO RESUME SYSTEM.


4.5.2 OPERATE IN DOOR OPEN STATUS WITH CE DOOR INTERLOCK SWITCH (OPTION)

- A. CONDITION IN DOOR OPEN STATUS

DUE TO CE REGULATION AND SAFETY REASON, WHILE DOOR OPEN THE MACHINE CAN ONLY OPERATE IN FOLLOWING STATUS.

- a. SPINDLE SPEED UNDER 50 /min.
- b. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE.
- c. AXIS FEEDRATE UNDER 2000 mm/min

- B. HOW TO OPERATE IN DOOR OPEN STATUS






- a. PUSH DOOR OPEN BUTTON.

- b. AFTER ENABLE THIS BUTTON, THE LAMP IN THE BUTTON LIGHTS.

NOTICE: ONCE YOU PUSH THIS BUTTON, YOU MUST EXECUTE OPEN AND CLOSE DOOR PROCEDURE TO RESUME THE SYSTEM.



- c. OPEN THE DOOR.
- d. CLOSE DOOR TO RESUME SYSTEM.

- C. MOVE THE AXIS OR TURN THE SPINDLE IN MANUAL MODE

- a. SWITCH KEY  TO MODE ENABLE.
- b. SWITCH MODE  TO "MANUAL" (HANDLE, JOG.)
- NOTE: MAKE SURE NOW MAGAZINE ON INITIAL POSITION.
- c. BEFORE ANY MOVEMENT, KEEP PUSHING THE PERMISSIVE

 BOTTOM
- FOR MACHINE WITH REMOVEABLE HANDWHEEL, THE BUTTON IS ON THE SIDE OF THE HANDWHEEL.
 - FOR MACHINE WITHOUT REMOVEABLE HANDWHEEL, THIS BUTTON IS ON THE OPERATION PANEL.
- d. DURING ANY MOVEMENT, YOU MUST KEEP PUSHING PERMISSIVE BUTTON TO ENABLE THE MOVEMENT.


NOTICE: DON'T RELEASE THE PERMISSIVE BUTTONS BEFORE STOP THE MOVEMENT. IT WILL CAUSE THE FAILURE OF THE MOVEMENT.


4.5.3 PROCEDURE TO TAKE OFF

-  TO  HANDLE X10 MODE , AND ADJUST FEEDRATE OVERRIDE LOWER
- A. SELECT MODE
- B. USE HANDWHEEL Z+ (OR PUSH Z+ BUTTON) TO RAISE THE HEAD, AND THEN TAKE OFF THE SUPPORT DEVICE.
- C. IF YOUR MACHINE IS WITH OPTION OF Z AXIS COUNTERWEIGHT, PROCESS FOLLOWING...
- a. USE HANDWHEEL Z- , UNTIL THE COUNTERWEIGHT CHAIN HAS TIGHTEN .
 - b. REFER TO FIG 4.2.1 TAKE OFF LOCK SCREW 7 AND 8. (ADJUST PROPER Z AXIS POSITION FOR EASIER TAKE OFF LOCK SCREW)




4.5.4 MOVE AXIS TO REFERENCE POINT

MOVE SPINDLE HEAD (Z AXIS), SADDLE (Y AXIS), TABLE (X AXIS) TO THE REFERENCE POINT (COORDINATE ZERO)

- A. SWITCH KEY  TO MODE ENABLE

- B. SET THE MODE SWITCH  TO ZERO POSITION.

- C. SET THE SWITCH "RAPID OVERRIDE"  TO 25%.

- D. PRESS THE PUSH BUTTON  UNTIL THE ZERO (REFERENCE POINT) LAMP "Z" LIGHTS (THEN,  FOR X AXIS AND  FOR Y AXIS)

- E. WHEN THE LAMP LIGHTS, THE SPINDLE HEAD REACHES THE REFERENCE IN Z AXIS. REPEAT THE STEPS ABOVE TO RETURN THE SADDLE AND TABLE TO THE REFERENCE POINT IN Y AXIS X AXIS RESPECTIVELY.

NOTICE: WHEN OPERATION IS RESUMED AFTER THE POWER SOURCE IS ONCE TURNED OFF OR EMERGENCY STOP BUTTON PUSHED PERFORM THE OPERATION TO RETURN THE REFERENCE POINT AND THEN START THE OPERATION AGAIN

NOTE: AFTER ZERO RETURN COMPLETED ON/OFF AGAIN TO MAKE SURE EVERYTIME SAME POSITION.

4.6 LEVELING CHECK

A. LACE TWO PRECISION LEVEL VIAL

- a. MOVE AND PLACE THE TABLE IN THE CENTER OF THE X AND Y AXIS MOVEMENT,
- b. FOR CHECKING THE LEVEL, USE A LEVEL VIAL WITH SCALE OF 0.02 mm / 1000 mm.
- c. PLACE TWO PRECISION LEVEL VIAL NEAR THE CENTER SURFACE OF TABLE (FIG 4.6.1)




FIG. 4.6.1 LEVELING CHECK

B. ADJUST THE LEVEL OF THE MACHINE BY THE LEVELING BOLTS

- a. ADJUST THE LEVEL OF THE MACHINE BY THE LEVELING BOLTS (FIG. 4.6.2)
- b. MAKE SURE EVERY LEVELING PADS ARE FIRMLY SECURED BY LEVELING BOLTS.
- c. ONCE YOU HAVE SET UP THE LEVELING, AFTER USING THE MACHINE 6 MONTH IT IS SUGGESTED TO CHECK THE LEVELING.





FIG. 4.6.2 LEVELING ADJUST


4.7 ASSEMBLE OF PARTS AND DEVICES

- BE WARE TO SWITCH OFF THE MAIN POWER WHILE ASSEMBLE OF PARTS AND DEVICES.
- FOR HANNING INFORMATION OF PARTS AND DEVICES PLEASE REFER TO CHAPER 3




4.7.1 MOTORS

- A. SOMETIMES DUE TO TRANSPORT REASON THE Z AXIS, Y AXIS, OR OTHER MOTOR COULD BE TAKEN OFF BEFORE TRANSPORT.
- B. ASSEMBLE THESE MOTOR BEFORE POWER WIRING.
- C. ONLY OTHERIZED PERSON CAN DO THE MOTOR ASSEMBLE.
- D. FOR MORE INFORMATION, CHECK YOUR MACHINE AGENT.




4.7.2 CABLE CHAIN


- A. CABLE CHAIN COULD BE RELEASED FOR TRANSPORTATION REASON.
- B. TO OPEN, CLOSE AND ADJUST CABLE CHAIN AS FIG 4.7.2



OPEN CABLE CHAIN COVER



CLOSE CABLE CHAIN COVER



ADJUST LENGTH OF CABLE CHAIN





FIG. 4.7.2 CABLE CHAIN



4.7.3 SIDE COOLANT TANK AND MOTORS

- A. BEFORE SETTING UP THE TANK, DO NOT FILL COOLANT LIQUIDE INTO THE TANK.
- B. PUSH THE SIDE TANK UNDER THE MACHINE.
- C. THERE ARE ALSO WHEELS AND LOCK SCREW UNDER THE TANK.
- D. SECURE COOLANT MOTOR, CHIP FLASH MOTOR AND C.T.S. MOTOR ON THE TANK, FOR PIPING AND WIRING, REFER TO NEXT SECTION "DEVICE PIPING INSTRUCTION".






4.7.4 CHIP CONVEYOR (OPTION)

- A. BEFORE SETTING UP THE TANK, DO NOT FILL COOLANT LIQUIDE INTO THE TANK.
- B. THERE ARE WHEELS AND LOCK SCREW UNDER FRONT COOLANT TANK.
- C. MAKE SURE THE OUTLET OF FRONT COOLANT TANK REACH THE SUB COOLANT TANK.
- D. FOR USERS WHICH HAVE CHIP CONVEYOR OPTION, IT IS NECESSARY TO PUT CONVEYOR ONTO COOLANT TANK, THAN PUSH THE WHOLE SET UNDER THE MACHINE.




4.7.5 CHIP CONVEYOR (OPTION)

- A. PUT CONVEYOR ONTO COOLANT TANK, THAN PUSH THE WHOLE SET UNDER THE MACHINE.
- B. THERE ARE TWO TYPES OF CHIP CONVEYOR, SCREW TYPE AND FLAT TYPE.
- C. THIS OPTION INCLUDES A CHIP CART, WHICH HAVE WHEELS UNDER THE CART.



4.7.6 SPINDLE CHILLER (OPTION)

- A. AS SET THE SPINDLE CHILLER IN POSITION.
- B. IT IS IMPORTANT TO KEEP THE SPINDLE CHILLER IN STANT POSITION DURING MOVING. (CAN NOT ROTATE THE CHILLER)
- C. ACCORDING TO THE REFRIGERANT LIQUID IN THE CHILLER, BEFOR START THE CHILLER IT IS NECESSARY TO WAIT 30 min. AFTER MOVING THE CHILLER.
- D. REFER TO SPINDLE CHILLER'S OPERATIONAL MANUAL FOR MORA INFORMATION




4.7.7 EXHAUST (VACUUM) SYSTEM (OPTION)

A. SPECIFICATION

TYPE	DIMENTION			POWER	INLET	AIR CAPACITY	WEIGHT
	H	W	D				
TS300	2000mm	800mm	600mm	2.3 kW	Ø200mm	30-45 m ³ /min	120 kg

- B. AS FIG 4.7.1 SET THE EXHAUST (VACUUM) SYSTEM IN POSITION. REMEMBER TO GIVE PLACE FOR MAINTENANCE.
- C. CONNECT THE EXHAUST (VACUUM) PIPE TO THE TOP OF THE MACHINE.
- D. CONNECT THE POWER TO THE SIDE OF POWER CABINET. (BE WARE TO SWITCH OF MAIN POWER)
- E. REFER TO VACUUM SYSTEM'S OPERATIONAL MANUAL FOR MORA INFORMATION



4.7.8 OTHER OPTIONS









FOR OTHER OPTIONS NOT LIST ABOVE, CHECK YOUR MACHINE
AGENT FOR INSTALLTION PROCEDURE

4.8 DEVICE PIPING INSTRUCTION



4.8.1 PIPE LIST

NO	PARTS NO.	TYPE	SPEC.	Q	REMARK
Ⓐ	1000-2679-100	A	1/2" (18.50 mm)x1m	1	
Ⓑ	1000-2835-100	B	3/4" (24.00 mm)x1.58m	1	
Ⓒ	1000-2889-100	C	3/4" (24.00 mm)x3m	1	
Ⓓ	1500-2115-100	A	3/8" (15.00 mm)x0.8m	1	
Ⓔ	1500-2373-100	B	3/4" (24.00 mm)x1.7m	1	
Ⓕ	4800-2270-100	A	1" (30.25 mm)x2m	1	
Ⓖ	1000-2860-100	A	3/8" (15.00 mm)x0.4m	1	
Ⓗ	1500-2156-100	B	1/2" (18.50 mm)x1.4m	1	
Ⓘ	1000-2154-100	A	1/2" (18.50 mm)x3m	2	
Ⓙ	1000-2678-100	A	3/8" (15.00 mm) x0.68m	1	
Ⓚ	1500-2372-100	B	1/2" (18.50 mm) x1.5m	1	
Ⓛ	1500-2206-100	A	1/4" (11.50 mm)x0.4m	1	
Ⓜ	1000-1093-100	C	1/2" (18.50 mm)x7m	1	
Ⓝ	1000-2335-100	C	1" (30.25 mm)x1m	1	
Ⓞ	1000-2834-100	C	1" (30.25 mm)x3.2m	1	
Ⓟ	1500-2111-100	A	1" (30.25 mm)x1m	2	
TYPE A: RESIST COMPRESSION PIPE. TYPE B: NYLON PIPE TYPE C: OIL RESIST PIPE					


4.8.2 PIPING ON TOP OF THE MACHINE

	<p>1. Basic Coolant 基本冷卻系統</p> 
	<p>2. Basic Coolant + Coolant Through Spindle 基本冷卻系統 + 主軸中心出水系統</p> 
	<p>3. Basic Coolant + Spindle Chiller 基本冷卻系統 + 主軸冷卻系統</p> 
	<p>4. Basic Coolant + Coolant Through Spindle + Spindle Chiller 基本冷卻系統 + 主軸中心出水系統 + 主軸冷卻系統</p> 

4.8.3 PIPING ON DEVICES



4.8.4 POWER CONNECTOR ON ELECTRIC CABINET



4.9 COOLANT

4.9.1 QUANTITY OF COOLANT

THE APPROXIMATELY QUANTITY FOR COOLANT TANK AS FOLLOWS:

SV-8045A
1070 Liter

4.9.2 TYPE OF COOLANT

- A. THERE ARE TWO TYPES OF COOLANT, WATER SOLUBLE, AND NON-WATER SOLUBLE, RESPECTIVELY OF WHICH HAVE MANY VARIATIONS. THE SUITABLE COOLANT DEPENDS ON CUTTING CONDITION AND OTHERS. THE FOLLOWING TABLE IS ONLY FOR REFERENCE. FIND YOUR COOLANT DEALER FOR MORE INFORMATION.

BRAND REFERENCE	MATERIAL			
	CASTING	STEEL	ALLOY STEEL	ALUMINUM
1. AVANTIN 620 2. CIMCOOL MB-602-S				
DILUTE WITH WATER (COOLANT : WATER)	1:20	1:20-25	1:15-20	1:10-25

4.9.3 SAFETY NOTICE

- A. TO PREVENT FIRE, OBEY THE FOLLOWING INSTRUCTIONS FOR UNMANNED OPERATION AT NIGHT OR FOR CASES WHEN OPERATOR HAS TO BE AWAY FROM THE MACHINE FOR A LONG TIME.
- USE NON-FLAMMABLE COOLANT ONLY.
 - CHECK THAT LUBRICATION OIL AND COOLANT ARE SUFFICIENT AND ARE WORKING PROPERLY.
 - CHECK THE TOOL TIPS, CUTTING CONDITIONS, CYCLE TIME, TOOL LIFE, ETC.
 - NEVER PLACE FLAMMABLE ITEMS, SUCH AS WOODEN BLOCKS, PAPER, CLOTH, ETC., AROUND THE MACHINE.

5. OPERATION OF MACHINE







5.1 SWITCHING ON THE POWER SOURCE TO MACHINE

5.1.1 APPLY THE POWER SOURCE TO THE MACHINE ITSELF AS FOLLOWS:

- A. MAKE SURE THE FRONT DOOR IS CLOSED.
- B. MAKE SURE THAT NO TROUBLE OCCURS WITH THE MACHINE REFERRING TO THE DESCRIPTION OF CHAPTER 6.1 CHECKING BEFORE STARTING THE MACHINE, WRITTEN IN THE DAILY CHECKING SCHEDULE.
- C. TURN ON THE POWER SWITCH ON THE ELECTRIC BOX. THE SPINDLE MOTOR AND THE COOLING FAN IN THE ELECTRIC BOX WILL START RUNNING.
- D. HOLD DOWN THE PUSH BUTTON POWER ON THE NC OPERATION PANEL FOR 2 OR 3 sec. THE POWER SOURCE WILL BE GIVEN THROUGHOUT THE MACHINE.
- E. REFERRING TO THE DESCRIPTION OF CHECKING BEFORE STARTING THE MACHINE IN DAILY CHECKING BEFORE STARING THE MACHINE IN DAILY CHECKING SCHEDULE 6.1, MAKE SURE NO TROUBLE IS FOUND IN THE MACHINE AND THEN START THE OPERATION.

5.1.2 MOVE AXIS TO REFERENCE POINT (MANUALLY)

MOVE SPINDLE HEAD (Z AXIS), SADDLE (Y AXIS), TABLE (X AXIS) TO THE REFERENCE POINT (COORDINATE ZERO)

- A. SWITCH KEY  TO MODE ENABLE
- B. SET THE MODE SWITCH  TO ZRTN POSITION.
- C. SET THE SWITCH "RAPID OVERRIDE"  TO 25%.
- D. PRESS THE PUSH BUTTON  UNTIL THE ZERO (REFERENCE POINT) LAMP "Z" LIGHTS (THEN,  FOR X AXIS AND  FOR Y AXIS)


5.2 SWITCHING OFF THE POWER SOURCE

TO TURN OFF, PROCEED AS FOLLOW:

- A. MAKE SUR THE FRONT DOOR IS CLOSED
- B. MAKE SURE THAT THE LAMP OF THE CYCLE START ON PUSH BUTTON ON THE OPERATION PANEL DOES NOT LIGHT.
- C. MAKE SURE THAT ALL MOVABLE PARTS OF THE MACHINE ARE IN STANDSTILL.
- D. WHEN TAPE PUNCH UNIT (ASR33 OR RS-232C) IS USED, TURN OFF THE UNIT.
- E. THEN HOLD THE PUSH BUTTON POWER OFF ON THE NC OPERATION PANEL FOR 1 OR 2 SEC.
- F. TURN OFF THE POWER SWITCH ON THE ELECTRIC BOX.







5.3 EMERGENCY STOP










- A. REFERRING TO THE DESCRIPTION OF CHAPTER 5.4 SWITCH 43.



- | | | | | |
|---------------------------------|----------------------------|------------------------------------|-----------------------------------|---------------------------------|
| 1. Manual Pulse Generator | 13. Dry Run | 25. Limit Switch Remove | 37. Spindle Stop | 49. 4th Axis Zero Position Lamp |
| 2. Cycle Start | 14. Optional stop | 26. Manual Feed - Z | 38. Spindle On Counter Clockwise | 50. 5th Axis Zero Position Lamp |
| 3. Feed Hold | 15. Optional Block Skip | 27. Manual Feed + Y | 39. Feedrate Override | 51. Program Finish Lamp |
| 4. Tool Magazine Backward | 16. Machine Lock | 28. Manual Feed - IV | 40. Rapid Traverse | 52. Low Gear Lamp |
| 5. Tool Magazine Forward | 17. M.S.T. Code Lock | 29. Auto Zero Return | 41. Spindle Override | 53. High Gear Lamp |
| 6. Tool Magazine Turn Clockwise | 18. Manual Feed + Z | 30. Override Cancel | 42. Mode Select | 54. Optional Stop Lamp |
| 7. Spindle Orientation | 19. Manual Feed - Y | 31. Menu | 43. Emergency Stop | 55. Lubrication Low Level lamp |
| 8. Chip Conveyor ON/OFF | 20. Manual Feed + IV | 32. Tool Change | 44. Program Protect & Mode Enable | 56. Motor Overload Lamp |
| 9. Chip Conveyor Reverse ON/OFF | 21. Operatin Guard Release | 33. Coolant Through Spindle ON/OFF | 45. Tool NO. Indicator | 57. Air Pressure Low Level Lamp |
| 10. Work Lamp ON/OFF | 22. Manual Feed + X | 34. Chip Flush ON/OFF | 46. X Axis Zero Position Lamp | 58. NC Alarm Lamp |
| 11. Spare Function for Option | 23. Rapid | 35. Coolant ON/OFF | 47. Y Axis Zero Position Lamp | 59. O.T. Detect Lamp |
| 12. Single Block | 24. Manual Feed - X | 36. Spindle on Clockwise | 48. Z Axis Zero Position Lamp | 60. Emergenay Stop Lamp |


5.4 EXPLANATION FOR USE OF OPERATION PANEL

SWITCH	DESCRIPTION
1 	PULSE GENERATOR (HANDWHEEL) USED ON MODE  IF YOU HAVE A OPTION OF REMOVEABLE HANDWHEEL, THERE WILL BE NO HANDWHEEL ON THE OPERATION PANEL.
2 	CYCLE START THIS IS A LIGHTING PUSH BUTTON, AND USED TO START OPERATION IN (41) AUTO OR MDI OPERATION MODE. WHEN THE PUSH BUTTON IS PRESSED, THE LAMP IN THE PUSH BUTTON LIGHTS. THE PUSH BUTTON IS PRESSED TO RESTART OPERATION AFTER OPERATION STOP WHEN THE PUSH BUTTON FEED HOLD (37) OR SINGLE BLOCK (9) IS OPERATED, OR WHEN OPERATION MODE IS CHANGED.
3  BZ. CUT M30 CUT	FEED HOLD THIS PUSH BUTTON IS USED TO STOP OPERATION IN AUTO OR MDI OPERATION MODE. WHEN THE PUSH BUTTON IS PRESSED, THE LAMP IN THE PUSH BUTTON CYCLE START GOES OUT. WHEN THE PUSH BUTTON IS PRESSED IN THE COURSE OF COORDINATE DISPLACEMENT, THE MOVEMENT IS DECELERATED AND STOPS WHILE THE OPERATION DOES NOT IMMEDIATELY STOP, WHEN THE PUSH BUTTON IS DEPRESSED DURING EXECUTION OF M, S OT T FUNCTION, BUT STOPS AFTER THE COMPLETION OF THE FUNCTION. THE PUSH BUTTON IS NOT EFFECTIVE DURING TAPPING CYCLE (G84), (G74) OR DWELL (G04). HOWEVER OPERATION IS STOPPED DURING EXECUTION OF CANNED CYCLE BY OPERATING THE PUSH BUTTON SINGLE BLOCK, THE LAMP IN THE PUSH BUTTON LIGHTS INDICATING THE EXECUTION PUSH BUTTON LIGHTS INDICATING THE EXECUTION OF THE CANNED CYCLE. BUZZER CUT THIS PUSH BUTTON CAN BE USED TO STOP THE BUZZER SOUND.
4 	TOOL MAGAZINE BACKWARD USED ONLY IN 20 TOOLS MAGAZINE (UMBRELLA TYPE) IN MANUAL MODE, SPINDLE ORIENTATION, K7.0=1 (MAINTENANCE MODE) PUSH TO MOVE THE MAGAZINE BACKWARD.
5 	TOOL MAGAZINE FORWARD USED ONLY IN 20 TOOLS MAGAZINE(UMBRELLA TYPE), IN THE CONDITION OF "MANUAL MODE"Z AXIS ON TOOL CHANGE POINT AND M19 STATUS AND WITHOUT TOOL INTERFERENCE, PUSH THIS BUTTOM TO MOVE MAGAZINE FORWARD.

6 	TOOL MAGAZINE TURN CLOCKWISE PUSH THIS BUTTOM TO ROTATE TOOL MAGAZINE CLOCKWISE, RELEASE TO STOP (IN MANUAL MODE)
7 	M19 SPINDLE ORIENTATION PUSH THIS BUTTOM TO ORIENTATE SPINDLE (M19)
8 	CHIP CONVEYOR ON / OFF (JOG) PUSH THIS BUTTOM TO START THE CHIP CONVEYOR PUSH AGAIN TO STOP
9 	CHIP CONVEYOR REVERSE ON / OFF PUSH THIS PUTTON TO REVERSE THE CHIP CONVEYOR RELEASE TO STOP IT
10 	WORK LAMP ON/OFF PUSH TO LIGHT THE WORK LAMP, PUSH AGAIN TO TURN OFF.
11 	SPARE FUNCTIONFOR OPTION
12 	SINGLE BLOCK THE SWITCH IS APPLIED TO EXECUTE TAPE PROGRAM OR MEMORY PROGRAM STEP BY STEP. WHEN THE PUSH BUTTON IS SET TO ON AND THE PUSH BUTTON CYCLE START (2) IS PRESSED. THE MACHINE EXECUTES ONE BLOCK OF THE PROGRAM AND STOPS. WHEN THE PUSH BUTTON SINGLE BLOCK IS PRESSED DURING MEM MODE OPERATION, THE MACHINE STOPS AFTER EXECUTED OF THE CURRENT BLOCK.
13 	DRY RUN WHEN THE SWITCH IS SET AT ON, FEED COMMAND (F CODE) IN THE PROGRAM IS IGNORED DURING. MEM, MDI OPERATION MODE AND THE FEED SPEED SELECTED BY THE SELECT SWITCH JOG FEEDRATE (39) BECOMES EFFECTIVE. THE RAPID TRAVERSE SPEED CAN BE ALSO CHANGED BY THE SWITCH DRY RUN.
14 	OPTIONAL STOP BY SETTING THIS SWITCH, THE OPTIONAL STOP FUNCTION OF M 01 IS IGNORED OR NOT IGNORED DURING MEM OPERATION MODE. WHEN THE SWITCH IS SET AT ON, THE BLOCK WITH M 01 IS EXECUTED AND THE OPERATION STOPS AFTER THE EXECUTION OF THE BLOCK.

<div>15</div> <div><div><div><div></div><div>BLK SKP</div></div><div><div></div><div></div></div></div></div>		<div>OPTIONAL BLOCK SKIP</div> <div>BY SETTING THIS SWITCH, THE BLOCK HAVING "/" (SLASH) AT ITS HEAD IS IGNORED OR NOT IGNORED. WHEN THE SWITCH IS AT ON, THE BLOCK HAVING "/" AT ITS HEAD IS IGNORED.</div> <div>THE SWITCH IS NOT EFFECTIVE FOR THE BLOCK IN EXECUTION AND THE BLOCK READ IN THE BUFFER, AND BECOMES EFFECTIVE FROM THE NEWLY READ BLOCK.</div>					
<div>16</div> <div><div><div><div></div><div>M LOCK</div></div><div><div></div><div></div></div></div></div>		<div>MACHINE LOCK</div> <div>TO LOCK THE AXIS MOVEMENT DURING EXECUTE PROGRAM.</div> <div>IN AUTO OR MDI OPERATION MODE, THE PROGRAM CAN BE SIMULATED, THAT IS, THE MACHINE DOES NOT ACTUALLY WORK, BUT THE DISPLAY APPEARS AS IF THE MACHINE ACTUALLY DOES.</div> <div>NOTICE: M,S,T CODE STILL EXECUTE. (SPINDLE ROTATION, TOOL CHANGE STILL EXECUTE) TO</div> <div><div>CANCEL PUSH</div><div><div><div><div></div><div>AFL</div></div><div><div></div><div>M.S.T</div></div></div></div><div>M,S,T, CODE LOCK.</div></div>					
<div>17</div> <div><div><div><div><div></div><div>AFL</div></div><div><div></div><div>M.S.T</div></div></div></div></div>		<div>M.S.T. CODE LOCK</div> <div>TO CANCEL THE EXECUTION OF M, S, T, CODE IN THE PROGRAM.</div> <div>NOTICE: AXIS MOVEMENT (G CODE) STILL EXECUTE, TO CANCEL, PUSH</div> <div><div><div><div><div></div><div>M LOCK</div></div><div><div></div><div></div></div></div></div><div>MACHINE LOCK.</div></div>					
<div>18</div> <div><div><div><div></div><div>+Z</div></div></div></div>	<div>19</div> <div><div><div><div></div><div>-Y</div></div></div></div>	<div>20</div> <div><div><div><div></div><div>+IV</div></div></div></div>	<div>22</div> <div><div><div><div></div><div>+X</div></div></div></div>	<div>24</div> <div><div><div><div></div><div>-X</div></div></div></div>	<div>26</div> <div><div><div><div></div><div>-Z</div></div></div></div>	<div>27</div> <div><div><div><div></div><div>+Y</div></div></div></div>	<div>28</div> <div><div><div><div></div><div>-IV</div></div></div></div>
<div>MANUAL FEED + / -</div> <div><div><div><div><div></div><div>HANDLE</div></div><div><div></div><div>x10</div></div><div><div></div><div>x100</div></div></div></div><div>A. IN HANDLE</div><div>MODE USE X+ <div><div><div><div></div><div>+X</div></div></div></div> , Y+ <div><div><div><div></div><div>+Y</div></div></div></div> , Z+ <div><div><div><div></div><div>+Z</div></div></div></div> , IV+ <div><div><div><div></div><div>+IV</div></div></div></div> TO SELECT AXIS.</div></div> <div><div><div><div></div><div>JOG</div></div><div><div></div><div></div></div></div><div>B. IN JOG</div><div>MODE USE THESE BUTTON TO MOVE DESIRE DIRECTION.</div><div><div><div><div><div></div><div>FEEDRATE OVERRIDE</div></div><div><div></div><div></div></div></div></div><div><div><div><div><div></div><div>RAPID</div></div><div><div></div><div></div></div></div></div><div>WHEN RAPID MODE <div><div><div><div></div><div>RAPID</div></div></div></div> IS PRESSED ALTOGETHER .SET THE RAPID SPEED BY RAPID OVERRIDE</div><div><div><div><div><div></div><div>RAPID TRAVERSE</div></div><div><div></div><div></div></div></div></div><div>SELECT SWITCH</div></div><div><div><div><div><div></div><div>ZRTN</div></div></div></div><div>C. IN ZERO RETURN</div><div>MODE, USE <div><div><div><div></div><div>+X</div></div></div></div> <div><div><div><div></div><div>+Y</div></div></div></div> <div><div><div><div></div><div>+Z</div></div></div></div> <div><div><div><div></div><div>+IV</div></div></div></div> TO EXECUTE ZERO RETURN.</div><div><div><div><div><div></div><div>RAPID TRAVERSE</div></div><div><div></div><div></div></div></div></div><div>THE TRAVEL SPEED WILL REFER TO <div><div><div><div></div><div>RAPID TRAVERSE</div></div></div></div> RAPID TRAVERSE SWITCH</div></div></div></div></div></div>							

21



OPERATION GUARD RELEASE (CE)


A. CONDITION IN DOOR OPEN STATUS

DUE TO CE REGULATION AND SAFETY REASON, WHILE DOOR OPEN THE MACHINE CAN ONLY OPERATE IN FOLLOWING STATUS.

- SPINDLE SPEED UNDER 50 /min.
- CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE.
- AXIS FEEDRATE UNDER 2000 mm/min


B. HOW TO OPERATE IN DOOR OPEN STATUS




- PUSH DOOR OPEN  BUTTON.
- OPEN THE DOOR.
- CLOSE DOOR TO RESUME SYSTEM.

NOTICE: ONCE YOU PUSH THIS BUTTON, YOU MUST EXECUTE OPEN AND CLOSE DOOR PROCEDURE TO RESUME THE SYSTEM.

C. MOVE THE AXIS OR TURN THE SPINDLE IN MANUAL MODE.



- SWITCH KEY  TO MODE ENABLE.




- SWITCH MODE  TO "MANUAL" (HANDLE, JOG.)

PER
-MISSIVE

- BEFORE ANY MOVEMENT, KEEP PUSHING THE PERMISSIVE BOTTON
 - FOR MACHINE WITH REMOVEABLE HANDWHEEL, THE BUTTON IS ON THE SIDE OF THE HANDWHEEL.
 - FOR MACHINE WITHOUT REMOVEABLE HANDWHEEL., THIS BUTTON IS ON THE OPERATION PANEL.
- DURING ANY MOVEMENT, YOU MEST KEEP PUSHING PERMISSIVE BUTTON TO ENABLE THE MOVEMENT.

NOTICE: DON'T RELEASE THE PERMISSIVE BUTTONS BEFORE STOP THE MOVEMENT. IT WILL CAUSE THE FAILURE OF THE MOVEMENT.


23















RAPID

IN JOG MODE, PUSH THIS BUTTOM TOGETHER WITH X+ X- Y+ Y- Z+ Z- IV+ IV- TO MOVE THE AXIS RAPIDLY.

SET THE RAPID SPEED BY RAPID OVERRIDE SELECT SWITCH




<p>25</p> 	<p>2ND LIMIT SWITCH REMOVE</p> <p>IN USUAL CONDITION, FOR THE AXIS TRAVEL, OVER-TRAVEL CAN BE DETECTED BY THE STORED STROKE LIMIT AT THE FIRST STAGE</p> <p>ANOTHER OVER TRAVEL LIMIT SWITCH IS PROVIDING AT THE SECOND STAGE TO DETECT MORE OVER-TRAVEL IF IT IS NOT STOP AT THE FIRST STAGE.</p> <p>IN SUCH A CASE, ALARM (EMERGENCY STOP) TAKES PLACE, AND IMMEDIATELY STOP THE MACHINE.</p> <p>KEEP PUSH THIS SWITCH TO ELIMINATE THE EMERGENCY STOP STATUS, SO THAT YOU CAN MOVE THE TRAVEL TO NORMAL POSITION.</p> <p>NOTICE: ONCE YOU PUSH THIS BUTTON, THE AXIS TRAVEL IS NOMORE PROTECTED, WRONG DIRECTIONAL MOVEMENT MAY DAMAGE THE MACHINE. IT IS SUGGEST TO USE HANDWHEEL WITH SMALL MOVEMENT TO ELIMINATE THE STATUS.</p>
<p>29</p> 	<p>AUTO ZERO RETURN</p> <p>THE SWITCH IS USED TO RETURN THE SPINDLE HEAD(Z), SADDLE(Y) AND TABLE (X) TO THE REFERENCE POINT (COORDINATE ZERO).</p> <p>THE OPERATION IS AS FOLLOWS:</p>  <p>SET THE MODE SWITCH TO ZRTRN, PUSH THIS BUTTOM.</p>  <p>THE TRAVEL SPEED WILL REFER TO RAPID TRAVERSE SWITCH</p> <p>NOTICE: IF START POSITION FOR REFERENCE POINT RETURN IS LOCATED WITHIN 50mm (2 inch) FROM THE REFERENCE POINT (DECELERATION RANGE) THE AXIS WILL GOES REVERSE DIRECTION UNTIL PROPER DISTANCE.</p>
<p>30</p> 	<p>OVERRIDE CANCEL</p>

<div>32</div> <div><div><div><div><div></div><div>TOOL CHG</div></div><div></div></div></div></div> <div>TOOL CHANGE</div> <div>PUSH THIS BUTTON TO EXECUTE TOOL CHANGE (OPTION) .</div> <div>Z AXIS MUST IN TOOL CHANGE POSITION.</div>		
<div>33</div> <div><div><div><div><div></div><div>C.T.S.</div></div><div></div></div></div></div> <div>COOLANT THROUGH SPINDLE ON/OFF</div> <div>PUSH TO START COOLANT THROUGH SPINDLE, PUSH AGAIN TO STOP.</div>		
<div>34</div> <div><div><div><div><div></div><div>FLUSH</div></div><div></div></div></div></div> <div>CHIP FLASH ON/OFF</div> <div>PUSH TO START CHIP FLASH, PUSH AGAIN TO STOP.</div>		
<div>35</div> <div><div><div><div><div></div><div>COOLANT</div></div><div></div></div></div></div> <div>COOLANT ON / OFF</div> <div>PUSH TO START COOLANT, PUSH AGAIN TO STOP.</div> <div>PRIORITY IS GIVEN TO THE SETTING OF THE SWITCHES OVER M FUNCTION SUCH AS M08 (COOLANT ON) AND M09 (COOLANT OFF).</div>		
<div>36</div> <div><div><div><div><div></div><div>SP CW</div></div><div></div></div></div></div> <div>MO3 SPINDLE ON CLOCKWISE</div>	<div>37</div> <div><div><div><div><div></div><div>SP OFF</div></div><div></div></div></div></div> <div>SPINDLE STOP</div>	<div>38</div> <div><div><div><div><div></div><div>SP CCW</div></div><div></div></div></div></div> <div>MO4 SPINDLE ON COUNTERCLOCKWISE</div>
<p>TO START OR STOP THE SPINDLE IN RAPID, JOG OR HANDLE MANUAL OPERATION MODE, THESE SWITCHES ARE USED.</p> <p>A. SET THE MODE SELECT SWITCH TO MDI POSITION AND SET SPINDLE SPEED IN MDI OPERATION AS FOLLOW..</p> <p>IN FANUC 0i CONTRAL</p> <p>KEYIN SXXXX THEN "INPUT"</p> <p>PUSH (2) CYCLE START TO EXECUTE</p> <p>IN FANUC 18iMC CONTROL</p> <p>KEYIN SXXXX;</p> <p>PUSH (2) CYCLE START TO EXECUTE</p> <p>B. SELECT THE DESIRED MODE AMONG RAPID, JOG AND HANDLE MODES BY THE MODE SELECT SWITCH</p> <p>C. PRESS THE PUSH BUTTON SPINDLE CW OR CCW ,THE SPINDLE WILL START RUNNING AT THE SET SPEED AT STEP A.</p> <p>D. THE SPINDLE STOPS WHEN THE PUSH BUTTON SPINDLE OFF IS PRESSED.</p> <p>E. TO START AGAIN, PRESS THE PUSH BUTTON SPINDLE ON THE SPINDLE STARTS RUNNING AT THE SET SPEED AT STEP A. AGAIN.</p> <p>TO CHANGE SPINDLE SPEED REPEAT STEPS A. – E. AFTER SETTING PUSH THE CYCLE START BUTTOM THE SPINDLE</p>		

WILL RUN AT THE NEWLY SET SPEED. NOTE : DOOR MUST CLOSED TO MATCH COMMAND'S SPEED.

F. WHEN DOOR OPEN NEED TO RUN SPINDLE KEEP PRESS PERMISSIVE BUTTON PRESS SP CW OR SP CCW FOR JOG RELEASE TO STOP SPINDLE.

39



VERRIDE SELECT SWITCH (%)

JOG FEEDRATE SELECT SWITCH (mm / min)

A. THE SELECT SWITCH PERMITS OVERRIDING THE FEED SPEED SPECIFIED BY F CODE IN AUTO OR MDI MODE OPERATION WITHIN A RANGE FROM 0 TO 200% WITH INCREMENT OF 10%.

HOWEVER, THE OVERRIDE SELECTION REMAINS INEFFECTIVE WHEN SWITCH LOCATED OVER THE OVERRIDE SELECT SWITCH IS SET AT CANCEL POSITION. THE OVERRIDE SELECT SWITCH DOES NOT EFFECT THE TAPPING FEED SPEED IN TAPPING CYCLE (G84).

B. THE FEED SPEED CAN BE PRESET BY THIS SELECT SWITCH IN AUTO OR MDI


MODE WHEN THE SWITCH DRY RUN  IS SET AT ON.

THE SPEED IS SELECTABLE WITHIN A RANGE FROM

0 TO 3,500 mm / min

40

RAPID TRAVERSE



RAPID OVERRIDE SELECT SWITCH

RAPID SPEED CAN BE OVERRIDDEN BY 100%, 50% 25% F0.

WHEN THE RAPID TRAVERSE SPEED IS AT 20 m / min, AND OVERRIDDEN BY 50%, FOR EXAMPLE, THE SPEED IS REDUCED TO 10 M / min.

F0 IS SET TO 100 mm / min. THE OVERRIDE FUNCTION IS APPLICABLE TO THE FOLLOWING RAPID TRAVERSE.

A. RAPID TRAVERSE IN GOO.


B. RAPID TRAVERSE DURING EXECUTION OF CANNED CYCLE.

C. RAPID TRAVERSE IN G27,28,29.

D. MANUAL RAPID TRAVERSE IN RAPID MODE OPERATION.














41








SPINDLE OVERRIDE






















SPINDLE SPEED OVERRIDE SELECT SWITCH

THIS SWITCH CAN OVERRIDDEN THE SPINDLE SPEED FROM 50 % TO 120 % , 10 % PER STEP.













<p>42</p>		<p>MODE SELECT SWITCH</p> <p>USE THIS SWITCH TO CHANGE OPERATION MODE.</p> <p>(CE) BEFORE CHANGE MODE, TURN THE KEY SWITCH  TO "MODE ENABLE", TO RELEASE THE CHANGE MODE PROTECTION.</p> <p>AFTER MODE CHANGE, TURN THE KEY BACK TO OFF POSITION.</p>
<p>DESCRIPTION OF MODE SELECT SWITCH</p>	 REMOTE	<p>DNC (REMOTE) MODE</p> <p>USE THIS MODE TO RUN THE PROGRAM (MACHINING) FROM YOUR CONNECTED PERSONAL COMPUTER, AND THE OPERATION METHOD DEPENDS ON THE DNC SOFTWARE IN YOUR COMPUTER .</p>
	 EDIT	<p>EDIT MODE</p> <p>THIS MODE IS SELECTED TO STORE PROGRAM IN THE MEMORY AND TO EDIT THE PROGRAM STORED IN THE MEMORY.</p>
	 AUTO	<p>AUTO (MEMORY) MODE</p> <p>THIS MODE IS SELECTED TO EXECUTE THE PROGRAM STORED IN THE MEMORY, OR TO SEARCH THE SEQUENCE NO. OF PROGRAM STORED IN THE MEMORY.</p>
	 MDI	<p>MDI MODE</p> <p>THIS MODE IS SELECTED WHEN DATA IS MANUALLY ENTERED (KEY IN).</p>
		<p>HANDLE MODE</p> <p>THIS MODE IS SELECTED WHEN USING PULSE GENERATOR HANDWHEEL</p>  <p>TO MOVE AXIS MANUALLY</p> <p>THE AXIS SELECTED BY THE AXIS SELECT BUTTOM</p> <p>X+  , Y+  , Z+  , IV+  (OR FROM REMOVEABLE HANDWHEEL)</p> <p>AFTER SELECTED THE LAMP OF THE BUTTOM WILL BLINK</p> <p>SCALE MULTIPLE:</p> <p>X1 = 0.001 mm (OR 0.0001 inch IN inch SYSTEM).</p> <p>X10 = 0.01 mm (OR 0.001 inch IN inch SYSTEM).</p> <p>X100 = 0.1 mm (OR 0.01 inch IN inch SYSTEM).</p>
		<p>JOG MODE</p> <p>THIS MODE IS SELECTING TO MANUALLY MOVE COORDINATE IN THE AXIS, SELECTED BY THE AXIS SELECT BUTTOM X+ X- Y+ Y- Z+ Z- A+ A- FOR JOG OPERATION.</p>





	<p>ZRTN</p>	<p>ZERO RETURN MODE</p> <p>SELECT THIS MODE THEN PUSHING</p> <p>+X  TO MOVE X TO ZERO POINT</p> <p>+Y  TO MOVE Y TO ZERO POINT</p> <p>+Z  TO MOVE Z TO ZERO POINT</p> <p>+IV  TO MOVE IV TO ZERO POINT</p> <p>YOU CAN PUSH 2 OR 3 AXIS TOGETHER</p> <p>OR IN THIS MODE PUSH AUTO ZERO RETURN BUTTON  TO MOVE THREE AXIS TOGETHER TO ZERO POINT.</p> <p>THE TRAVEL SPEED WILL REFER TO  RAPID TRAVERSE SWITCH</p>
<p>43</p>	<p>EMERGENCY STOP</p> 	<p>EMERGENCY STOP</p> <p>THE PUSH BUTTON IS USED IMMEDIATELY STOP THE MACHINE OPERATION IN CASE OF EMERGENCY. AT THE SAME TIME AS THE PUSH BUTTON IS PRESSED, THE SERVO SYSTEM OF THE MACHINE IS SHUT OFF THE POWER SOURCE AND THE NC EQUIPMENT IS RESET.</p> <p>TO START THE MACHINE AGAIN AFTER THE EMERGENCY STOP, PROCEED AS FOLLOWS:</p> <ol style="list-style-type: none"> ELIMINATE THE CAUSE OF EMERGENCY STOP AND SET UP THE MACHINE TO BE READY FOR OPERATION. WHEN THE EMERGENCY STOP PUSH BUTTON IS PRESSED, THE PUSH BUTTON IS LOCKED. TO RELEASE THE PUSH BUTTON FROM LOCKING, ROTATE OR PULL IT . PRESS RESET BUTTON ON THE NC OPERATION PANEL. AFTER RESETTING FROM THE EMERGENCY STOP, BE SURE TO PERFORM ZERO RETURN OF ALL AXIS IN MANUAL OPERATION.

<div>44</div> <div><div><div>EDIT</div><div></div><div>OFF</div></div><div><div>MODE ENABLE</div><div></div><div><div></div><div>ON</div></div></div></div>		<div>PROGRAM PROTECT AND MODE ENABLE</div> <div>THERE ARE TWO FUNCTIONS ON THIS PROTECT KEY SWITCH</div> <div>A、PROGRAM EDIT PROTECT</div> <div>FOR PROTECT THE PROGRAM STORED IN THE MEMORY FROM ERRONEOUS OPERATION. THE SWITCH SHOULD NORMALLY SET AT OFF POSITION.</div> <div>WHEN THE SWITCH IS SET AT ON, THE FOLLOWING FUNCTIONS ARE AVAILABLE.</div> <div><div><div></div><div>STORING AND EDITION OF PROGRAM.</div></div><div><div></div><div>RESETTING OF COORDINATE SYSTEM</div></div></div> <div>WHEN THE SWITCH ZERO RETURN IS PRESSED WITH X, Y OR Z AXIS SPECIFIED, THE ABSOLUTE VALUE OF THE CORRESPONDING AXIS TURN TO "O".</div> <div>SETTING OF TOOL POSITION OFFSET, TOOL DIAMETER OFFSET AND TOOL SETTING UP.</div> <div>B、MODE ENABLE</div> <div>WHEN CHANGE MODE SELECT SW (42) MUST ON THEN OFF TO CONFIRM MODE CHANGE.</div>		
<div>45</div> <div></div>		<div>TOOL NO. INDICATOR</div> <div>THE TWO NUMBER ON THE LEFT SHOWS THE TOOL NUMBER OF STANDBY TOOL POT.</div> <div>THE TWO NUMBER ON THE RIGHT SHOWS THE SPINDLE TOOL NUMBER.</div>		
<div>46</div> <div></div>	<div>47</div> <div></div>	<div>48</div> <div></div>	<div>49</div> <div></div>	<div>50</div> <div></div>
<div>LAMP X Y Z IV AND V AXIS ZERO POSITION</div> <div>THE LAMP INDICATES THAT THE TABLE (X AXIS). SADDLE (Y AXIS) AND SPINDLE HEAD (Z AXIS) ARE AT THE REFERENCE POINT (COORDINATE ZERO). THE LAMP LIGHTS WHEN REFERENCE POINT IS COMPLETED BY MANUAL OPERATION, OR RETURN TO REFERENCE POINT (G28). OR REFERENCE POINT RETURN CHECK (G27). THE LAMP GOES OUT WHEN THE TABLE, SADDLE OR SPINDLE OR SPINDLE HEAD LEAVES THE REFERENCE POINT.</div>				
<div>51</div> <div></div>	<div>PROGRAMFINISH</div> <div>WHEN PROGRAM EXECUTE M02 OR M30 THIS LAMP LIGHTS</div>			
<div>52</div> <div></div>	<div>LAMP LOW GEAR</div> <div>INDICATES THE LOW GEAR OF THE SPINDLE</div> <div>(NOT USED ON MCV-600/800/1000)</div>			

53 	LAMP HIGH GEAR INDICATES THE HIGH GEAR OF THE SPINDLE (NOT USED ON MCV-600/800/1000)
54 	LAMP OPTIONAL STOP THE LAMP LIGHTS WHEN THE PROGRAM RUNS TO THE OPTIONAL STOP (M01) OR THE PROGRAM RUNS TO THE END (M00) , .
55 	LAMP LUBRICATION LEVEL (FAILURE) IF AMOUNT OF LUBRICATING OIL DECREASES TO ABOUT ONE FOURTH OF THE LUBRICATING OIL TANK CAPACITY, THE LAMP LIGHTS. SINCE THE MACHINE DOES NOT STOP AUTOMATICALLY WHEN THE LAMP LIGHTS, IMMEDIATELY STOP THE MACHINE AND REPLENISH NECESSARY AMOUNT OF OIL WHEN THE IS FOUND LIGHTING. WHEN THE OIL TANK IS FILLED. THE LAMP GOES OUT.
56 	LAMP OVERLOAD · THE LAMP LIGHTS IF OVERLOAD OCCURS WITH THE COOLANT PUMP, LUBRICATION PUMP OR ATC MAGAZINE DRIVE MOTOR. SINCE THE MACHINE DOES NOT STOP AUTOMATICALLY WHEN THE LAMP LIGHTS, STOP THE MACHINE IMMEDIATELY AND EXAMINE THE THERMAL RELAYS FOR CAUSE IF THE LAMP LIGHTS. TO RESUME THE OPERATION, ELIMINATE THE CAUSE OF THE OVERLOAD.
57 	LAMP AIR PRESSURE (FAILURE) THE LAMP LIGHTS IF COMPRESSED AIR PRESSURE GOES DOWN BELOW 4 bar . THE ALARM BUZZER ALSO SOUNDS AND TOOL CHANGE BECOMES IMPOSSIBLE WHEN THIS LAMP LIGHTS. WHEN THE LAMP LIGHTS, STOP THE MACHINE OPERATION, CHECK AIR PRESSURE IN THE PNEUMATIC UNIT THROUGH PRESSURE GAUGE AND AIR PRESSURE TO 5.5 bar .THEN PRESS CYCLE START TO CANCEL ALM.
58 	LAMP NC ALARM WHEN GENERATE SEQUENCE ERROR, THIS LAMP LIGHTS
59 	OT DETECT WHEN X, Y, Z OR 4TH AXIS DETECT THE HARDWARE OVERTRAVEL THIS LAMP LIGHTS
60 	EMERGENCY STOP IN EMERGENCY STOP STATUS, THIS LAMP LIGHTS.

5.5 OTHER SWITCHES AND SIGNAL


	<p>TOOL CLAMP / UNCLAMP</p> <p>INFRONT OF THE SPINDLE,</p> <p>IN MANUAL MODE, PUSH TO UNCLAMP TOOL, RELEASE TO CLAMP.</p> <p>(IN DOOR OPEN STATUS)</p>
 <p>24/32T TOOL CHANGE SWITCH BOX</p>	<p>24/32 TOOL CHANGE SWITCH BOX (OPTION)</p> <p>THIS SWITCH BOX LOCATED ON THE LEFT BACK OF THE MACHINE.</p> <p>THIS SWITCH BOX AND A TOOL CHANGE WINDOW BESIDE PROVIDE YOU TO LOAD OR UNLOAD TOOLS FROM HERE.</p> <p> TOOL MAGAZINE TURNS COUNTER CLOCKWISE.</p> <p> TOOL MAGAZINE TURNS CLOCKWISE.</p> <p> EMERGENCY STOP (FUNCTION AS ON OPERATER PANEL)</p> <p> MAGAZINE GUARD RELEASE (CE).</p> <p>TO OPEN MAGAZNE GUARD (WINDOW):</p> <ul style="list-style-type: none"> • IN MANUAL MODE • KEEP PUSH THIS BUTTON, AND OPEN GUARD. • RELEASE BUTTON. (NOW THE NC IS IN SERVO OFF STATUS)
	<p>REMOVEABLE HANDWHEEL (OPTION)</p> <p>THIS HANDWHEEL ONLY EFFECTIVE IN  MODE</p> <p>1. HANDWHEEL:</p> <p>FUNCTION AS ON PANEL.</p> <p>2. AXIS SELECT SWITCH:</p> <p>TO SELECT AXIS, HAS HIGER PRIORITY FUNCTION AS </p> <p>   , IN MANUAL MODE FOR AXIS SELECT.</p>

	<p>3. HANDWHEEL SCALE MULTIPLE</p> <p>HAS HIGHER PRIORITY FUNCTION AS</p> <p>4. EMERGENCY STOP</p> <p>FUNCTION AS ON OPERATION PANEL.</p> <p>5. PERMISSIVE BUTTON. (CE)</p> <p>FOR OPERATION IN DOOR OPEN STATUS.</p> 
<div>PER -MISSIVE</div>	<p>PERMISSIVE BUTTON (CE)</p> <p>ON OPERATION PANEL</p> <p>FOR OPERATION IN DOOR OPEN STATUS.</p>
	<p>SIGNAL LIGHT AND BUZZER</p> <p>A. RED (BLANKING): ALARM SIGNAL (SUCH AS OVER LOAD, LUBRICATION LOW, AIR LOW, NC ALARM, BATTERY ALARM) ELIMINATE ALARM TO CUT SIGNAL.</p> <p>B. YELLOW (BLANKING): PROGRAM END (M00/M01/M30) PUSH</p>  <p>FEED HOLD SWITCH TO CUT SIGNAL.</p> <p>C. GREEN (BLANKING): PROGRAM EXECUTING.</p> <p>D. BUZZER: WHEN ALARM ACCRUES THE BUZZER SOUNDS. TO CUT</p> <p>OF THE BUZZER, JUST PUSH</p>  <p>FEED HOLD SWITCH.</p>

5.6 OPERATE IN DOOR OPEN STATUS

5.6.1 OPERATE IN DOOR OPEN STATUS WITH NON CE DOOR INTERLOCK SWITCH (OPTION)

- A. WHEN NON CE DOOR INTERLOCK SWITCH IS MOUNTED, PRESS THIS KEY



TO RELEASE DOOR INTERLOCK.

- B. RELEASE DOOR INTERLOCK IN ANY MODE.
- C. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE WHEN DOOR OPENED
- D. DUE TO SAFETY REASON, WHILE DOOR OPEN THE MACHINE CAN ONLY OPERATE IN FOLLOWING STATUS.
- a. SPINDLE SPEED UNDER 50/min
 - b. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE.
 - c. AXIS FEED RATE UNDER 2000mm/min.
- E. CLOSE DOOR TO RESUME SYSTEM.


5.6.2 OPERATE IN DOOR OPEN STATUS WITH CE DOOR INTERLOCK SWITCH (OPTION)

- A. CONDITION IN DOOR OPEN STATUS

DUE TO CE REGULATION AND SAFETY REASON, WHILE DOOR OPEN THE MACHINE CAN ONLY OPERATE IN FOLLOWING STATUS.

- a. SPINDLE SPEED UNDER 50 /min.
- b. CAN OPERATE ONLY IN JOG AND HANDWHEEL MODE.
- c. AXIS FEEDRATE UNDER 2000 mm/min

- B. HOW TO OPERATE IN DOOR OPEN STATUS




- a. PUSH DOOR OPEN BUTTON.


- b. AFTER ENABLE THIS BUTTON, THE LAMP IN THE BUTTON LIGHTS.

NOTICE: ONCE YOU PUSH THIS BUTTON, YOU MUST EXECUTE OPEN AND CLOSE DOOR PROCEDURE TO RESUME THE SYSTEM.

- c. OPEN THE DOOR.
- d. CLOSE DOOR TO RESUME SYSTEM.


- C. MOVE THE AXIS OR TURN THE SPINDLE IN MANUAL MODE

- a. SWITCH KEY  TO MODE ENABLE.

- b. SWITCH MODE  TO "MANUAL" (HANDLE, JOG.)

NOTE: MAKE SURE NOW MAGAZINE ON INITIAL POSITION.

- c. BEFORE ANY MOVEMENT, KEEP PUSHING THE PERMISSIVE

BOTTON 

- FOR MACHINE WITH REMOVEABLE HANDWHEEL, THE BUTTON IS ON THE SIDE OF THE HANDWHEEL.
 - FOR MACHINE WITHOUT REMOVEABLE HANDWHEEL, THIS BUTTON IS ON THE OPERATION PANEL.
- d. DURING ANY MOVEMENT, YOU MEST KEEP PUSHING PERMISSIVE BUTTON TO ENABLE THE MOVEMENT

NOTICE: DON'T RELEASE THE PERMISSIVE BUTTONS BEFORE STOP THE MOVEMENT. IT WILL CAUSE THE FAILURE OF THE MOVEMENT.


5.7 WHEN TOOL CHANGE MOVEMENT IS INTERRUPTED BY EMERGENCY STOP OR RESET


5.7.1 20 TOOLS ATC

- A. THE ATC MAGAZINE AND SPINDLE TAKES FOLLOWING CONDITIONS WHEN TOOL CHANGE MOVEMENT INTERRUPTED BY EMERGENCY STOP OR RESET.
 - a. ATC MAGAZINE KEEPS THE POSITION WHEN EACH MOVEMENT OF ATC MAGAZINE HAS COMPLETED.
 - b. THE ATC MAGAZINE ROTATING MOVEMENT JUST STOPS THE POSITION WHEN EMERGENCY STOP OR RESET GENERATES.
 - c. THE SPINDLE TAKES CLAMP CONDITION DURING THE ATC MAGAZINE IS MOVING ON FORWARD - BACK SPACE.
 - d. THE SPINDLE TAKES UNCLAMP CONDITION DURING THE Z AXES IS MOVING ON UP - DOWN SPACE.
 - e. THE SPINDLE ORIENTATION MOVEMENT IS JUST STOPPED THE POSITION WHEN EMERGENCY STOP OR RESET GENERATES.

◆ HOW TO MAKE RESTART IN CASE OF (b)

- a. ELIMINATE THE CAUSE OF EMERGENCY STOP STATUS OR RESET AND SET UP THE MACHINE TO BE READY FOR OPERATION.
- b. WHEN THE ATC MAGAZINE DID NOT STOP AT INDEXING POINT, IN

ZRTN MODE, PRESS  MAGAZINE TURN CLOCKWISE KEY

AND  CYCLE START KEY TOGETHER, MAGAZINE WILL GO TO POCKET 1 (MAGAZINE REFERENCE POSITION) AUTOMATICALLY.

- c. CHECK SPINDLE CLAMP SWITCH BEING ON CLAMP CONDITION.
- d. WHEN MAGAZINE ON MIDDLE OF STROKE SETTING KEEP RELAY K7.0=1(MAINTENANCE MODE)

【MAGAZINE BACKWARD】

PRESS  TO MOVE BACK

MAGAZINE TO INITIAL POSITION.

- e. PRESS POWER OFF BUTTON ON THE NC OPERATION PANEL. THEN, PRESS THE POWER ON BUTTON.
- f. PERFORM REFERENCE POINT RETURN OF ALL AXES IN MANUAL OPERATION. (ATC REFERENCE ALSO)

5.7.2 24 / 32 TOOLS ATC

A. THE TOOL CHANGER ARM IS IN POSITION

- a. ELIMINATE THE CAUSE OF EMERGENCY STOP AND SET UP THE MACHINE TO BE READY FOR OPERATION.
- b. PRESS POWER OFF BUTTON ON THE NC OPERATION PANEL. THEN, PRESS THE POWER ON BUTTON.
- c. PERFORM ZERO RETURN OF ALL AXES IN MANUAL OPERATION.

B. THE TOOL CHANGER ARM IS NOT IN POSITION

- a. ELIMINATE THE CAUSE OF EMERGENCY STOP
- b. ROTATE THE ARM MANUALLY (USE ALLEN KEY) FROM THE MOTOR UPON TOOL CHANGER , UNTIL

0iM	18iMB/21iMA
X10.2	X24.2
X10.3	X24.3
X10.1	X24.1

C. SET UP THE MACHINE TO BE READY FOR OPERATION.

D. CHECK IF THE TOOL POT NUMBER AND TOOL NUMBER IS CORRECT.

CHECK G.DATA SETTING

PLEASE REFER TO "PARAMETER LIST " DATA TABLE SETTING" FOR THE CORRECT G.DATA SETTING.

E. IF TOOL NUMBER IS NOT CORRECT REFER TO CHAPTER 7 TROUBLESHOOTING, FOR ATC

WARNING ! ONLY AUTHORIZED PERSON CAN DO THE OPERATION ABOVE. AND WHEN DOING THE OPERATION BE WARE NOT TO MOVE THE MACHINE. TO PREVENT FROM DANGEROUS PUSH EMERGENCY STOP BEFORE OPERATION.


WARNING ! PLEASE ALWAYS CHECK THE TOOL TABLE G. DATA SETTING SHOULD BE CORRECT BEFORE AUTOMATIC MACHINING . WRONG TOOL TABLE MAY CAUSE INCORRECT TOOL CHANGE AND CRUSH THE MACHINE.


5.8 WHEN INSTALL OR REMOVE THE TOOL MANUALLY


TO MANUALLY INSTALL OR REMOVE THE TOOL FROM / TO SPINDLE
PROCEED AS FOLLOWS :

A. INSTALLATION OF TOOL

- a. STOP THE SPINDLE AND COORDINATE DISPLACEMENT IN EACH AXIS.

- b. DOOR OPEN  1 SEC.

- c. SET THE MODE SELECT SWITCH  TO HANDLE POSITION. MAKE SURE THAT THE SPINDLE TAPER BORE AND THE TOOL TAPER ARE CLEAN.

- d. PRESS THE UNCLAMP SWITCH  AND MAKE SURE THE SWITCH IS LIGHTING.
- e. INSERT THE TOOL INTO THE SPINDLE TAPER BORE.
- f. WHEN THE TOOL IS SECURELY SET UP IN THE SPINDLE, PRESS THE UNCLAMP SWITCH AND MAKE SURE THE LIGHTING GOES OUT. NOW THE SPINDLE HAS BEEN CLAMPED IN THE SPINDLE.
- g. AFTER MAKING SURE THE TOOL HAS BEEN SET UP IN THE SPINDLE, RELEASE HAND FROM THE TOOL.

NOTICE: AT STEP C), AIR BLOW OUT TO REMOVE FINE METALLIC PARTICLES AND DUST FROM THE TOOL TAPER AND THE SPINDLE TAPER BORE, WHEN THE UNCLAMP SWITCH IS PRESSED. CARE SHOULD BE TAKEN TO SECURELY HOLD THE TOOL TO PREVENT BLOWING OFF OF THE TOOL..

B. REMOVAL OF TOOL


- a. PERFORM STEPS a) AND b) INSTRUCTED ABOVE.
- b. PRESS THE UNCLAMP SWITCH THE PULL STUD WILL BE PRESSED AND THE TOOL SINKS BY APPROXIMATELY 0.5 mm (0.02 inch).
- c. REMOVE THE TOOL.
- d. PRESS THE UNCLAMP SWITCH.

NOTICE: SINCE THE TOOL GOES DOWN AT STEP b), AND IS SUBJECTED TO THE AIR BLOW PRESSURE, SECURELY HOLD THE TOOL BY HAND. WHEN THE TOOL IS REMOVED, BE SURE TO REMOTELY LOCATE THE SPINDLE HEAD (Z AXIS) TO PREVENT CONTACT OF THE TOOL WITH THE WORK OR TABLE


5.9 WHEN OVERTRAVEL IS DETECTED BY 2ND LIMIT SWITCH

TO RESET FROM THE ALARM STATUS, OPERATE SWITCHES AS FOLLOWS:

- A. STOP THE BUZZER BY OPERATING THE BUZZER STOP SWITCH




- B. PRESS THE 2ND LS REMOVE SWITCH



- C. THE SWITCH (PUSH BUTTON) SHOULD BE HELD DOWN UNTIL THE RESETTING IS COMPLETED. WHEN 2ND LS REMOVE SWITCH IS PRESSED, THE POWER SOURCE IS GIVEN TO THE MACHINE.
- D. SET THE AXIS IN WHICH OVER TRAVEL OCCURRED AND THEN PRESS THE MANUAL FEED SWITCH OF THE DIRECTION ("+" OR "-") REVERSE TO THE OVER-TRAVEL DIRECTION. THE COORDINATE SHOULD BE DISPLACED AT LEAST 50 mm (2 inch) FROM STOPPED POSITION.
- E. PRESS RESET BUTTON ON THE NC OPERATION PANEL TO CLEAR THE ALARM CONDITION. NOW THE MACHINE HAS BEEN RELEASED FROM THE ALARM (EMERGENCY STOP) CONDITION. IF IT IS PRESUMABLE THAT OPERATION MAY BECOME OUT OF CONTROL AGAIN WHEN THE 2ND LS REMOVE SWITCH IS PRESSED AT STEP B), CONSULT, WITH OUR SERVICE ENGINEER.
- F. NOTE: BEFORE TURNING ON THE POWER SOURCE, PERFORM REFERENCE POINT RETURN IN MANUAL OPERATION IN ALL AXES.
- G. IF THE COORDINATE IS DISPLACED TO THE STROKE END IN - DIRECTION WITHOUT PERFORMING REFERENCE POINT RETURN, IT MAY NOT BE DETECTED AT THE STORED STROKE END (1ST STAGE), BUT DETECTED BY THE 2ND LIMIT SWITCH CAUSING STOP TO THE MACHINE. THEREFORE, IF EMERGENCY STOP OCCURS, IDENTIFY THE CAUSE OF EMERGENCY STOP (WHETHER IT IS CAUSED BY FAILURE OF REFERENCE POINT RETURN, OR BY OTHER TROUBLE).
- H. WHEN THE EMERGENCY STOP IS DUE TO FAILURE OF REFERENCE POINT RETURN, OPERATE THE 2ND LS REMOVE SWITCH TO RELEASE THE MACHINE FOR EMERGENCY STOP CONDITION AND THEN RESUME USUAL OPERATION.

5.10 FANUC OPERATION PANEL

5.10.1 MD1 KEYBOARD AND CRT



FOR MORE INFORMATION PLEASE REFER TO FANUC OPERATOR'S MANUAL

5.10.2 LIST OF OPERATION

CLASSIFICATION	FUNCTION	KEY SWITCH	SETTING PWE=1	MODE SWITCH BUTTON	FUNCTION BUTTON	OPERATION
CLEAR	MEMORY ALL CLEAR			POWER ON	—	[RESET] AND [DELETE]
	PARAMETER AND OFFSET		○	POWER ON	—	[RESET]
	CLEARING STORED PROGRAM		○	POWER ON	—	[DELETE]
RESET	RUN TIME			—	—	[R/3] → [CAN]
	PARTS NUMBER			—	—	[P/Q] → [CAN]
	OT ALARM			POWER ON	—	[P/Q] AND [CAN]
DATA INPUT FROM MDI	PARAMETER			MDI	PARAM	[P/Q] → PARAM. NO. → [INPUT] → [DATA] → [INPUT] → PWE=0 → [RESET]
	OFFSET VALUE		○	—	OFFSET	[P/Q] → OFFSET NO. → [INPUT] → OFFSET DATA → [INPUT]
	SETTING DATA			MDI	PARAM	[P/Q] → 0 → [INPUT] → DATA → [INPUT]
	PMC PARAMETER	○			DGNOS	[P/Q] → DIAGRAM NO. → [INPUT] → DATA → [INPUT]
	TOOL LENGTH MEASUREMENT			JOG	POS OFFSET	[POS] (RELATIVE) → [Z] → [CAN] → [OFFSET] → MOVE TOOL TO MEASURING POSITION →
						[P / Q] → OFFSET NO. → [EOB] AND [Z] → [INPUT]
DATA INPUT FROM TAPE	PARAMETER (TAPE TO MEMORY)		○	EDIT	PARAM	[INPUT]
	OFFSET VALUE	○		EDIT	OFFSET	[INPUT]
	PROGRAM INPUT			EDIT / AUTO	PRGRM	[INPUT]
TAPE PUNCH	PARAMETER			EDIT	PARAM	[START]
	OFFSET VALUE			EDIT	OFFSET	[START]

	ALL PROGRAM			EDIT	PRGRM	[0] → -999 → [START]
	ONE PROGRAM			EDIT	PRGRM	[0] → PROGRAM NO. → [START]
SEARCH	PROGRAM NO. SEARCH			EDIT / AUTO	PRGRM	→ [0] PROGRAM NO. → [↓] (CURSOR)
	SEQUENCE NUMBER SEARCH			AUTO	PRGRM	PROGRAM NO. SEARCH → [N] → SEQUENCE NO. → [↓] (CURSOR)
	ADDRESS WORD SEARCH			EDIT	PRGRM	SEARCHING ADDRESS AND DATA INPUT → [↓] (CURSOR)
	OFFSET NO.			—	OFFSET	[P/Q] → OFFSET NO. → [INPUT]
PROGRAM EDITING	PROGRAM MEMORY USED			EDIT	PRGRM	[P] → [INPUT]
	DELETION OF ALL PROGRAM	○		EDIT	PRGRM	[0] → [9999] → [DELETE]
	DELETION OF A PROGRAM	○		EDIT	PRGRM	[0] → PROGRAM NO. → [DELETE]
	DELETION OF SEVERAL BLOCKS	○		EDIT	PRGRM	[N] → SEQUENCE NO. → [DELETE]
	DELETION OF A BLOCKS			EDIT	PRGRM	[EOB] → [DELETE]
	DELETION OF A WORD	○		EDIT	PRGRM	SEARCH THE WORD TO BE DELETED → [DELETE]
	ALTERNATION OF A WORD	○		EDIT	PRGRM	SEARCH THE WORD TO BE ALTERED → NEW DATA → [ALTER]
	INSERTION OF A WORD	○		EDIT / AUTO	PRGRM	SEARCH THE WORD TO BE INSERTED → NEW DATA → [INSERT]
COLLATION	COLLATION IN MEMORY WITH TAPE			EDIT / AUTO	PRGRM	[INPUT]
INPUT / OUTPUT WITH FANUC CASSETTE	PROGRAM INPUT	○		EDIT / AUTO	PRGRM	[N] → FILE NO. → [INPUT] → [INPUT]
	OUTPUT ALL PROGRAM			EDIT	PRGRM	[0] → -9999 → [START]
	OUTPUT ONE PROGRAM			EDIT	PRGRM	[0] → PROGRAM NO. → [INPUT]

	SEARCHING FOR A HEAD OF A FILE			EDIT / AUTO	PRGRM	[N] → FILE NO. , -9999 OR - 9998 → [INPUT]
	DELETION OF FILE	○		EDIT	PRGRM	[N] → FILE NO. → [START]
	COLLATION OF PROGRAM			EDIT / AUTO	PRGRM	[N] → FILE NO. → [INPUT] → [INPUT]
PLAYBACK				TEACHIN JOG / HANDLE	PRGRM	MOVE MACHINE → [X] , [Y] OR [Z] → [INSERT] → NC DATA [INSERT] → [EOB] → [INSERT]

FOR MORE INFORMATION PLEASE REFER TO FANUC OPERATOR'S
MANUAL

5.10.3 MDI KEYBOARD FUNCTIONS

NO.	NAME	FUNCTION
1	RESET KEY	PRESS THIS KEY TO RESET THE CNC, TO CANCEL AN ALARM, ETC.
2	START	PRESS THIS KEY TO START THE MDI COMMENDS, OR TO START THE AUTOMATIC OPERATION CYCLE.
3	ADDRESS AND NUMERICAL KEY	PRESS THIS KEYS TO INPUT ALPHABETIC, NUMERIC, AND OTHER CHARACTER.
4	INPUT KEY	WHEN AN ADDRESS OR A NUMERICAL KEY IS PRESSED, THE ALPHABET OR THE NUMERAL IS INPUT ONCE TO THE KEY INPUT BUFFER, AND IT IS DISPLAYED ON THE CRT SCREEN. TO SET THE DATA INPUT TO THE KEY INPUT BUFFER IN THE OFFSET REGISTER, ETC. , PRESS THE INPUT KEY. THIS KEY IS EQUIVALENT TO THE INPUT KEY OF THE SOFT KEYS, SO THE SAME RESULTS CAN BE OBTAINED BY PRESSING EITHER OF THEM.
5	CANCEL (CAN) KEY	PRESS THIS KEY TO CANCEL CHARACTER OR SIGN. (EXAMPLE) WHEN THE KEY INPUT BUFFER DISPLAY N0001, N0001 IS CANCELED WITH THIS KEY.
6	CURSOR SHIFT KEYS	THERE ARE TWO KINDS OF CURSOR SHIFT KEY DESCRIBED BELOW : ↑ : THIS KEY IS USED TO SHIFT THE CURSOR A SHOUT DISTANCE IN THE FORWARD DIRECTION. ↓ : THIS KEY IS USED TO SHIFT THE CURSOR A SHOUT DISTANCE IN THE REVERSE DIRECTION.
7	PAGE CHANGEOVER KEY	TWO KINDS OF PAGE CHANGEOVER KEYS ARE DESCRIBED BELOW : ↑ : THIS KEY IS USED TO CHANGEOVER THE PAGE ON THE CRT SCREEN IN THE FORWARD DIRECTION.

		↓ : THIS KEY IS USED TO CHANGEOVER THE PAGE ON THE CRT SCREEN IN THE REVERSE DIRECTION.
8	SOFT KEYS	<p>THE SOFT KEY HAVE VARIOUS FUNCTIONS, ACCORDING TO THE APPLICATIONS.</p> <p>THE SOFT KEY FUNCTIONS ARE DISPLAYED AT THE BOTTOM OF THE CRT SCREEN.</p> <p>LEFT-END SOFT KEY ←</p> <p>THIS KEY IS USED IN ODDER TO EXIT TO THE INITIAL STATES (CONDITION WHEN THE FUNCTION BUTTON IS DEPRESSED WHEN EACH FEATURE HAS BEEN OPERATED VIA SOFT KEYS)</p> <p>RIGHT-END SOFT KEY →</p> <p>THIS KEY IS USED WHEN OPERATE FUNCTIONS WHICH HAVE NOT YET BEEN DISPLAYED.</p>

5.11 M CODE LIST

M CODE	FUNCTION	DESCRIPTION	NOTE
M00	PROGRAM STOP	TO STOP THE PROGRAM (FEED HOLD). PUSH CYCLE START TO CONTINUE THE PROGRAM	
M01	OPTIONAL STOP	USE TOGETHER WITH THE OPTIONAL STOP BUTTON ON OPERATION PANEL TO HOLD THE PROGRAM (AS M00) PUSH CYCLE START TO CONTINUE THE PROGRAM	
M02	END OF PROGRAM	USED IN THE END OF PROGRAM AS FINISH. (THE CURSOR STAY IN THE END) USE M30 TO END THE PROGRAM AND MOVE THE CURSOR TO THE BEGINNING OF THE PROGRAM	
M03	SPINDLE CW	TURN ON THE SPINDLE CLOCKWISE	
M04	SPINDLE CCW	TURN ON THE SPINDLE COUNTERCLOCKWISE	
M05	SPINDLE STOP	STOP THE SPINDLE	
M06	AUTO TOOL CHANGE	CHANGE THE PREPARED TOOL AUTOMATICALLY	
M07	PARTS COUNT	PARTS COUNT	
M08	COOLANT PUMP ON	TURN ON THE COOLANT PUMP	
M09	COOLANT PUMP STOP	TURN OFF THE COOLANT PUMP	
M13	SPINDLE CW / COOLANT PUMP ON	TURN ON THE SPINDLE CLOCKWISE AND COOLANT PUMP	
M14	SPINDLE CCW / COOLANT PUMP ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND COOLANT PUMP	
M15	SPINDLE STOP / COOLANT PUMP OFF	STOP SPINDLE AND COOLANT PUMP	
M16	SPECIAL TOOL ASSIGNMENT	ASSIGN SPECIAL TOOL ON FIXING POT.	(OPTION)
M17	GUARD DOOR OPEN	GUARD DOOR OPEN	(OPTION)
M18	GUARD DOOR CLOSE	GUARD DOOR CLOSE	(OPTION)
M19	SPINDLE ORIENTATION	SPINDLE ORIENTATION FOR TOOL CHANGE	
M20	SPINDLE ORIENTATION RESET	RESET SPINDLE ORIENTATION	

M CODE	FUNCTION	DESCRIPTION	NOTE
M27	SKIP SIGNAL SWITCHING ON	SKIP SIGNAL SWITCHING ON	(OPTION)
M28	SKIP SIGNAL SWITCHING OFF	SKIP SIGNAL SWITCHING OFF	(OPTION)
M29	RIGID TAPPING	RIGID TAPPING MODE	
M30	PROGRAM END	USED IN THE END OF PROGRAM AS FINISH. (THE CURSOR MOVE TO THE BEGINNING OF THE PROGRAM) REFER TO M02 TO STAY THE CURSOR IN THE END.	
M31	MIRROR IMAGE X AXIS	TURN ON THE X AXIS MIRROR IMAGE FUNCTION	
M32	T MIRROR IMAGE Y AXIS	TURN ON THE Y AXIS MIRROR IMAGE FUNCTION	
M33	MIRROR IMAGE OFF	TURN OFF THE MIRROR IMAGE FUNCTION	
M36	AIR BLOW THROUGH SPINDLE ON	TURN ON AIR BLOW THROUGH SPINDLE	(OPTION)
M37	AIR BLOW THROUGH SPINDLE OFF	TURN OFF AIR BLOW THROUGH SPINDLE	(OPTION)
M38	SHOWER COOLANT ON	TURN ON THE SHOWER COOLANT	(OPTION)
M39	SHOWER COOLANT OFF	TURN OFF THE SHOWER COOLANT	(OPTION)
M40	SPINDLE CW / SHOWER COOLANT ON	TURN ON THE SPINDLE CLOCKWISE AND SHOWER COOLANT	(OPTION)
M41	SPINDLE CCW / SHOWER COOLANT ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND SHOWER COOLANT	(OPTION)
M42	SPINDLE STOP / SHOWER COOLANT OFF	STOP SPINDLE AND SHOWER COOLANT	(OPTION)
M43	COOLANT THROUGH SPINDLE ON	TURN ON THE COOLANT THROUGH SPINDLE SYSTEM	(OPTION)
M44	COOLANT THROUGH SPINDLE OFF	TURN OFF THE COOLANT THROUGH SPINDLE SYSTEM	(OPTION)
M45	SPINDLE CW / COOLANT THROUGH SPINDLE ON	TURN ON THE SPINDLE CLOCKWISE AND COOLANT THROUGH SPINDLE SYSTEM	(OPTION)
M46	SPINDLE CCW / COOLANT THROUGH SPINDLE ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND COOLANT THROUGH SPINDLE SYSTEM	(OPTION)
M47	SPINDLE STOP / COOLANT THROUGH SPINDLE OFF	STOP SPINDLE AND COOLANT THROUGH SPINDLE SYSTEM	(OPTION)
M48	CHIP FLUSH PUMP 1 ON	TURN ON THE CHIP FLUSH PUMP 1	

M CODE	FUNCTION	DESCRIPTION	NOTE
M49	CHIP FLUSH PUMP 1 OFF	TURN OFF THE CHIP FLUSH PUMP 1	
M50	SPINDLE CW / CHIP FLUSH PUMP 1 ON	TURN ON THE SPINDLE CLOCKWISE AND CHIP FLUSH PUMP 1	
M51	SPINDLE CCW / CHIP FLUSH PUMP 1 ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND CHIP FLUSH PUMP 1	
M52	SPINDLE STOP / CHIP FLUSH PUMP 1 OFF	STOP SPIDLE AND CHIP FLUSH PUMP 1	
M53	EXTERNAL AIR BLAST ON	TURN ON THE EXTERNAL AIR BLAST	(OPTION)
M54	EXTERNAL AIR BLAST OFF	STOP THE EXTERNAL AIR BLAST	(OPTION)
M55	SPINDLE CW / EXTERNAL BLAST ON	TURN ON THE SPINDLE CW AND EXTERNAL AIR BLAST	(OPTION)
M56	SPINDLE CCW / EXTERNAL BLAST ON	TURN ON THE SPINDLE CCW AND EXTERNAL AIR BLAST	(OPTION)
M57	SPINDLE STOP / EXTERNAL BLAST OFF	TURN OFF SPINDLE AND THE EXTERNAL AIR BLAST	(OPTION)
M58	CHIP CONVEYOR FORWARD	TURN ON THE CHIP CONVEYOR	(OPTION)
M59	CHIP CONVEYOR STOP	TURN OFF THE CHIP CONVEYOR	(OPTION)
M60	AUTO PALLET CHANGE	CHANGE PALLET	(OPTION)
M61	TOOL CHANGE / SPECIAL TOOL ASSIGNMENT	TOOL CHANGE FOR ASSIGNMENT OF SPECIAL TOOL	(OPTION)
M66	OIL MIST ON	TURN ON THE OIL MIST	(OPTION)
M67	OIL MIST OFF	TURN OFF THE OIL MIST	(OPTION)
M68	SPINDLE CW / OIL MIST ON	TURN ON THE SPINDLE CLOCKWISE AND OIL MIST	(OPTION)
M69	SPINDLE CCW / OIL MIST ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND OIL MIST	(OPTION)
M70	SPINDLE STOP / OIL MIST OFF	STOP SPINDLE AND OIL MIST	(OPTION)
M71	VACUUM DUST COLLECTOR ON	TURN ON VACUUM DUST COLLECTOR	(OPTION)
M72	VACUUM DUST COLLECTOR OFF	STOP VACUUM DUST COLLECTOR	(OPTION)
M73	WORKPIECE CHUCK UNCLAMP	UNCLAMP WORKPIECE CHUCK	(OPTION)
M74	WORKPIECE CHUCK CLAMP	CLAMP WORKPIECE CHUCK	(OPTION)
M75	CHIP FLUSH PUMP 2 ON	TURN ON THE CHIP FLUSH PUMP 2	(OPTION)
M76	CHIP FLUSH PUMP 2 OFF	TURN OFF THE CHIP FLUSH PUMP 2	(OPTION)

M CODE	FUNCTION	DESCRIPTION	NOTE
M77	SPINDLE CW / CHIP FLUSH PUMP 2 ON	TURN ON THE SPINDLE CLOCKWISE AND CHIP FLUSH PUMP 2	(OPTION)
M78	SPINDLE CCW / CHIP FLUSH PUMP 2 ON	TURN ON THE SPINDLE COUNTERCLOCKWISE AND CHIP FLUSH PUMP 2	(OPTION)
M79	SPINDLE STOP / CHIP FLUSH PUMP 2 OFF	STOP SPIDLE AND CHIP FLUSH PUMP 2	(OPTION)
M80	4TH AXIS UNCLAMP / B AXIS INDEX TABLE UNCLAMP	UNCLAMP 4TH AXIS	(OPTION)
M81	4TH AXIS CLAMP / B AXIS INDEX TABLE CLAMP	CLAMP 4TH AXIS	(OPTION)
M82	5TH AXIS UNCLAMP	UNCLAMP 5TH AXIS	(OPTION)
M83	5TH AXIS CLAMP	CLAMP 5TH AXIS	(OPTION)
M98	SUBPROGRAM CALL	SUBPROGRAM CALL	
M99	END OF SUBPROGRAM	END OF SUBPROGRAM	
MAINTENANCE M CODES FOR ATC			
M1000	TOOL POT V.	TOOL POT VERTICAL	
M1001	TOOL POT H.	TOOL POT HORIZONTAL	
M1004	ATC DOOR OPEN	OPEN ATC DOOR	(OPTION)
M1005	ATC DOOR CLOSE	CLOSE ATC DOOR	(OPTION)
M1006	TOOL CHANGE (MAINTENANCE MODE)	<p>FOR MAINTENANCE, TO CHANGE TOOL STEP BY STEP.</p> <ul style="list-style-type: none"> ● LET ATC IN NORMAL CONDITION, EXECUTE M19 / G91G30Z0. ● SET KEEP RELAY K6.6 = 1 ● IN MDI MODE REPEAT M1006 AND CYCLE START. THE MOVEMENT SEQUENCE WILL BE : <ol style="list-style-type: none"> 1. TOOL POT V. (M1000) 2. TOOL CHANGE (ARM 900 / TOOL UNCLAMP) (M1006) 3. TOOL CHANGE (ARM DOWN / ROTATE / UP) (M1006) 4. TOOL CHANGE (TOOL CLAMP / ARM RETURN) (M1006) 5. TOOL POT H. (M1001) 	
M1007	MAGAZINE FORWARD	MAGAZINE FORWARD MOVEMENT	(FOR ARMLESS TYPE ATC)
M1008	MAGAZINE BACKWARD	MAGAZINE BACKWARD MOVEMENT	

M CODE	FUNCTION	DESCRIPTION	NOTE
M1009	TOOL SHIFT CYLINDER1 IN	TOOL SHIFT CYLINDER1 MOVE IN	(FOR HORIZONTAL MACHINE MAGAZINE)
M1010	TOOL SHIFT CYLINDER1 OUT	TOOL SHIFT CYLINDER1 MOVE OUT	
M1011	TOOL SHIFT CYLINDER2 IN	TOOL SHIFT CYLINDER2 MOVE IN	
M1012	TOOL SHIFT CYLINDER2 OUT	TOOL SHIFT CYLINDER2 MOVE OUT	
M1013	TOOL SHIFT CYLINDER3 IN	TOOL SHIFT CYLINDER3 MOVE IN	
M1014	TOOL SHIFT CYLINDER3 OUT	TOOL SHIFT CYLINDER3 MOVE OUT	
M1015	TOOL LOCK CYLINDER4 IN	TOOL LOCK CYLINDER4 IN	
M1016	TOOL LOCK CYLINDER4 OUT	TOOL LOCK CYLINDER4 OUT	
M1017	TL HOLDER ROTATE CYLINDER5 IN	TL HOLDER ROTATE CYLINDER5 IN	
M1018	TL HOLDER ROTATE CYLINDER5 OUT	TL HOLDER ROTATE CYLINDER5 OUT	
M1019	TL HOLDER MOVING CYLINDER6 IN	TL HOLDER MOVING CYLINDER6 IN	
M1020	TL HOLDER MOVING CYLINDER6 OUT	TL HOLDER MOVING CYLINDER6 OUT	
M1021	PUT STANDBY TOOL ON TOOL HOLDER	PUT STANDBY TOOL ON TOOL HOLDER	
M1022	RETURN SPINDLE TOOL ON MG POCKET	RETURN SPINDLE TOOL ON MG POCKET	
MAINTENANCE M CODES FOR APC			
M1030	B AXIS TAPER CONE UNCLAMP	UNCLAMP B AXIS (TABLE)	(OPTION)
M1031	B AXIS TAPER CONE CLAMP	CLAMP B AXIS (TABLE)	(OPTION)
M1032	PALLET UP	PALLET UP	(OPTION)
M1033	PALLET DOWN	PALLET DOWN	(OPTION)
M1034	PALLET CW	PALLET TURN CLOCKWISE	(OPTION)
M1035	PALLET CCW	PALLET TURN COUNTERCLOCKWISE	(OPTION)
SPARE M CODES			
M1060	M FUNCTION 1 ON	SPARE M FUNCTION 1 ON	(OPTION)
M1061	M FUNCTION 1 OFF	SPARE M FUNCTION 1 OFF	(OPTION)
M1062	M FUNCTION 2 ON	SPARE M FUNCTION 2 ON	(OPTION)
M1063	M FUNCTION 2 OFF	SPARE M FUNCTION 2 OFF	(OPTION)

M CODE	FUNCTION	DESCRIPTION	NOTE
M1064	M FUNCTION 3 ON	SPARE M FUNCTION 3 ON	(OPTION)
M1065	M FUNCTION 3 OFF	SPARE M FUNCTION 3 OFF	(OPTION)
M1066	M FUNCTION 4 ON	SPARE M FUNCTION 4 ON	(OPTION)
M1067	M FUNCTION 4 OFF	SPARE M FUNCTION 4 OFF	(OPTION)
M1068	M FUNCTION 5 ON	SPARE M FUNCTION 5 ON	(OPTION)
M1069	M FUNCTION 5 OFF	SPARE M FUNCTION 5 OFF	(OPTION)
M1070	M FUNCTION 6 ON	SPARE M FUNCTION 6 ON	(OPTION)
M1071	M FUNCTION 6 OFF	SPARE M FUNCTION 6 OFF	(OPTION)
M1072	M FUNCTION 7 ON	SPARE M FUNCTION 7 ON	(OPTION)
M1073	M FUNCTION 7 OFF	SPARE M FUNCTION 7 OFF	(OPTION)
M1074	M FUNCTION 8 ON	SPARE M FUNCTION 8 ON	(OPTION)
M1075	M FUNCTION 8 OFF	SPARE M FUNCTION 8 OFF	(OPTION)
TOOL DATA TABLE INITIALIZATION			
M2000	POCKET DATA TABLE INITIAL SETTING COMMAND	RESET MAGAZINE DATA TABLE REQUEST, MAG TURN TO POCKET 1	24/32 TOOL'S USING

5.12 S (SPINDLE) FUNCTION

- A. THE S FUNCTION IS USED TO COMMAND SPINDLE SPEED.
- B. THE SPINDLE SPEED CAN BE DIRECTLY COMMANDED WITH ADDRESS S FOLLOWED BY 4 OR 5 DIGIT NUMERIC VALUE WITHIN A RANGE FROM 90 TO 3000 /min OR 180 TO 6000 /min . IF SPEED OUT OF THE RANGE IS COMMENDED, ALARM OCCURS.

(NOTE : 10,000 /min ABOVE CHOICE S 5 DIGIT)

- C. EXAMPLE:
- D. FOR SPEED OF 1234 /min, PROGRAM AS FOLLOW :
- E. S1234 (EOB)
- F. M03 OR M04 (EOB)

5.13 T (TOOL) FUNCTION

- A. THE T FUNCTION IS USED TO COMMAND THE NUMBER OF TOOL TO BE CHANGED.
- B. THE DESIRED TOOL CAN BE DIRECTLY COMMENDED WITH ADDRESS T FOLLOWED BY 2-DIGIT NUMERIC VALUE. TOOL FUNCTION IS AVAILABLE WITHIN A RANGE FROM T01 TO T20.24.32.40,

EXAMPLE :

- C. WHEN SPINDLE TOOL IS CHANGED TO NO. 2 TOOL, PROGRAM AS FOLLOW :

T02 (EOB)

M06 (EOB)

- NOW TOOL NO.2 WILL BE CHANGED TO SPINDLE.
- NOTE THAT THE COMMAND SHOULD BE TWO BLOCKS.

- D. WHEN SPINDLE TOOL IS CHANGED TO NO.2 TOOL AND CALL TOOL NO.3 AS THE PREPARED TOOL.

T02 (E0B)

M06 T03 (E0B)

- NOW TOOL NO.2 WILL BE CHANGED TO SPINDLE AND TOOL NO.3 WILL BE ROTATED TO STANDBY POSITION.

5.14 SPECIAL TOOL ASSIGNMENT STEPS (M16/M61)

5.14.1 DESCRIPTION

- A. THIS FUNCTION IS APPLIED TO SPECIAL TOOL (BIG DIAMETER).
- B. THE ASSIGNED SPECIAL TOOL WILL BE ON FIXED POCKER, BOTH SIDES OF THE SPECIAL TOOL WILL BE EMPTY.
- C. SUGGEST TO EXECUTE M2000 BEFORE ASSIGNMENT AND THERE IS NO TOOL ON THE MAGAZINE TO AVOID THE INTERFERENCE BETWEEN TOOLS.
- D. PLEASE REFER TO THE OPERATION MANUAL FOR THE MAX. TOOL WEIGHT.

5.14.2 EXAMPLE

- IN MDI MODE
- M16 T1005(EOB)
(ASSIGN TOOL NO.5 AS THE SPECIAL TOOL, LOCKED ON POCKET NO.5)
- CYCLE START (EXECUTE COMMAND)
MAGAZINE WILL ROTATE TO POCKET NO.5 AUTOMATICALLY
APPEAR MESSAGE 2121 LOAD THE SPECIAL TOOL INTO SPINDLE IN MANUAL MODE,.....
MAKE SURE THERE IS NO TOOL ON POCKET NO.4 AND POCKET NO.6.
- M61(EOB)
EXECUTE TOOL CHANGE
- CYCLE START (EXECUTE COMMAND)
THE ATC ARM WILL ROTATE AND PUT THE SPINDLE TOOL ON POCKET NO.5 AUTOMATICALLY
ORIGINAL TOOL ON POCKET NO.5 WILL BE PUT IN SPINDLE
APPEAR MESSAGE 2122 UNLOAD THE NORMAL TOOL FROM SPINDLE IN MANUAL MODE
CONFIRM THE ACTUAL TOOL NO. WITH TOOL DATA TABLE.
- FINISH
FOLLOW THE PREVIOUS PROCESS, M16 T1001 TO ASSIGN TOOL NO.1 AS THE SPECIAL TOOL, LOCKED ON POCKET NO.1
M16 T1020 TO ASSIGN TOOL NO.20 AS THE SPECIAL TOOL, LOCKED ON POCKET NO.20.
NOTE: DO NOT PRESS RESET OR EMG STOP DURING THE PROCESS,
OTHERWISE THE TOOL DATA WILL BE CONFUSED.
AFTER THE ASSIGNMENT IS FINISHED, CHECK THE TOOL DATA TABLE AND DO NOT CHANGE MANUALLY.

5.15 OTHER FUNCTION

- A. FOR OTHER FUNCTIONS AND DETAIL DESCRIPTION REGARDING TO CONTROL SYSTEM, PLEASE REFER TO FANUC OPERATOR'S MANUAL.


6. CHECKING AND MAINTENANCE OF MACHINE


WARINING: ORDER TO GUARANTEE TROUBLE FREE, LONG USE OF THE MACHINE, IT IS VERY IMPORTANT TO ELABORATELY CHECK EACH PART OF THE MACHINE PERIODICALLY . IF ANY TROUBLE OR SIGN IF TROUBLE IS FOUND DURING CHECKING, BE SURE TO IMMEDIATELY REMEDY IT, THE DAILY CHECKING AND MAINTENANCE SCHEDULE THAT SHOULD BE AT LEAST PERFORMED BEFORE STARTING DAILY WORK IS SHOWN BELOW.

6.1 DAILY CHECKING

6.1.1 SAFETY CIRCUIT AND DVICE CHECK

THE FAILURE OF SAFETY CIRCUIT AND DEVICE COULD CAUSE SERIOUS INJURY OR DEATH DURING OPERATION, CONTECT YOUR MACHINE AGENT TO SOVE THE PROBLEM BELOW.

A . BEFORE STARTING MACHINE	
1	CHECK IF THE FRONT DOOR AND TOOL MAGAZINE DOOR IS CLOSED, OTHERWISE CAN NOT TURN ON THE SYSTEM PROPERLY.
2	<p>IF THE FRONT DOOR OR TOOL MAGAZINE DOOR IS NOT COSED PROPERLY AND STILL CAN START THE SYSTEM THAT MEANS...</p> <ul style="list-style-type: none"> ● THE HARDWARE OF THE DOOR SWITCH IS MODIFIED OR DAMAGED. ● THE SOFTWARE HAVE BEEN MODIFIED. <p>FRONT DOOR SWITCH NO. Z30. Z301 TOOL MAGAZINE DOOR SWITCH NO. Z60, Z601</p>
B. AFTER STARTING MACHINE	
1	<p>WHEN THE SYSTEM IS READY AND THE MACHINE IS NOT RUNNING, PUSH  BUTTON THEN OPEN THE FRONT DOOR</p> <p>THE MACHINE SHOULD CAN NOT EXCUTE ANY CONTRAL (SUCH AS AXIS MOVEMENT, SPINDLE RUNNING, TOOL CHANGE, COOLANT PUMP, CHIP CONVEYOR OR OTHER OPTION DEVICE)</p> <p>IF THE MACHINE CAN EXCUTE ANY DEVICE FUNCTION MEANS..</p> <ul style="list-style-type: none"> ● THE HARDWARE OF THE DOOR SWITCH IS MODIFIED OR DAMAGED. ● THE SOFTWARE HAVE BEEN MODIFIED. <p>FRONT DOOR SWITCH NO. Z30. Z301</p>
2	<p>WHEN THE SYSTEM IS READY AND THE MACHINE IS NOT RUNNING, OPEN THE TOOL MAGAZINE DOOR.</p> <p>CHECK PROCEDURE AS ABOVE.</p> <p>TOOL MAGAZINE DOOR SWITCH NO. Z60, Z601</p>
3	<p>IN MANUAL MODE START THE SPINDLE RUNNING, PUSH ANY EMERGENCY STOP BUTTON (ON OPERATION PANEL SB46, TOOL MAGAZINE SB47, REMOVEABLE HANDWHEEL SB49, CHIP CONVEYOR SB48 OR ON OTHER OPERATIONAL DEVICE)</p> <p>SOULD STOP THE SPINDLE IMMEDIATELY, IF NOT, CHECK THE ELECTRIC CIRCUIT OR REPLACE THE SWITCH AND TEST AGAIN.</p>
C. PARTS REPLACEMENT	
1	<ul style="list-style-type: none"> ● TO REPLACE THE ELECTRICAL PARTS, REFER TO PARTS LIST IN THE ELECTRICAL DIAGRAM, FOR THE CORRECT SPECIFICATION OF PARTS. ● AFTER CHANGE PARTS, CONFIRM THE SAFETY CIRCUIT AND DEVICE CHECK AS ABOVE PROCEDURE A AND B. ● IF ANY QUESTION CONTECT YOUR MACHINE AGENT.



6.1.2 MACHINE DAILY CHECKING SCHEDULE

A . BEFORE STARTING MACHINE	
1	VISUALLY CHECK THE APPEARANCE OF THE MACHINE
2	CHECK IF ANY OBJECT IS LOCATED WITHIN THE MOVEABLE RANGE OF THE TABLE, SADDLE AND SPINDLE HEAD.
3	CLEAN THE SPINDLE BORE TAPER AND THE CIRCUMFERENCE OF THE SPINDLE
4	CHECK THE WIPERS FOR THE SPINDLE HEAD, SADDLE AND SADDLE SIDEWAYS.
5	CHECK THE GIBS USED IN X, Y AND Z AXIS.
6	CHECK THE SIDE WAYS FOR DAMAGE, SCORE OR DEFECTS. IF ANY DAMAGE OR SCORE IS FOUND, FLATTEN USING AN OIL STONE.
7	CHECK THE TOOL TAPER FOR CLEANLINESS AND CLEAN IF NECESSARY.
8	CHECK THE TOOL PULL STUD FOR LOOSENED. NOTICE THAT LOOSENED PULL STUD IS VERY DANGEROUS DAILY
9	CHECK LUBRICATION OIL IN THE LUBRICATION PUMP USING THE FURNISHED LEVEL GAUGE AND REPLENISH IF NECESSARY.
10	WHEN COOLANT UNIT (OPTION) IS USED, CHECK COOLANT LEVEL USING THE FURNISHED LEVEL GAUGE AND REPLENISH IF NECESSARY.
11	CHECK COMPRESSED AIR PRESSURE (TO BE 5.5 bar) THROUGH PRESSURE GAUGE INCORPORATED IN THE PNEUMATIC UNIT AND ADJUST IF NECESSARY.
B. AFTER STARTING MACHINE	
1	CHECK IF UNUSUAL SOUND, VIBRATION OR HEAT RISE OCCURS.
2	CHECK THAT LUBRICATING OIL IS SATISFACTORILY GIVEN TO EACH SIDE WAYS . DEPRESS THE INSTANT PUSH BUTTON OF THE LUBRICATION PUMP TO DELIVER OIL IF NECESSARY.
3	BEFORE STARTING THE OPERATION, LET RUN THE SPINDLE AT A LOW SPEED AND MOVE THE SPINDLE HEAD, SADDLE AND TABLE WITHIN THESE FULL STROKES WITHOUT LOAD FOR 10 - 20 min.
C. WHEN DAILY WORK ENDS	
1	WHEN DAILY WORK ENDS, BE SURE TO THOROUGHLY CLEAN THE MACHINE, PARTICULARLY SIDE WAYS. APPLY MACHINE OIL TO THE SPINDLE TAPER TO PREVENT CORROSION. WHEN DAILY WORK ENDS. DO NOT FAIL TO REMOVE THE OIL BEFORE STARTING THE MACHINE.
2	WHEN DAILY WORK ENDS, CHECK IF THE CUTTING CHIPS IS TOO MUCH THAT MAYBE EFFECT THE MOVEMENT OF X AND Y AXIS MOVEMENT, USE A EXHAUST (VACUUM) TO CLEAN IT FROM THE FRONT DOOR.

6.2 6 MONTH CHECKING

6 MONTH CHECKING SCHEDULE

	CHECK UP
1	ATC GREASE ON MAGAZINE ROTATION AND TOOL POT UP/DOWN PARTS. CHECK IF THE ROTATION AND MOVEMENT IS SMOOTHLY.
2	COUNTERWEIGHT ROLLER CHAIN (OPTION) CHECK IF THE ROLLER CHAIN IS IN GOOD CONDITION, GREASING TO COUNTERWEIGHT ROLLER CHAIN.
3	SPINDLE GEAR BOX (OPTION) REPLENISH IF OIL LEVEL IS FOUND BELOW THE SPECIFIED LEVEL CHECK IF THE GEAR BOX RUNNING SMOOTHLY.
4	SLIDEWAY GIB IN GENERAL PRACTICE, THE ADJUSTMENT SHOULD BE MADE IN 3 MONTHS AND 6 MONTHS AFTER INSTALLATION. AFTER THAT, CHECK SLIDE WAY LEVEL YEARLY AND ADJUST IT IF NECESSARY.

6.3 YEARLY CHECKING

YEARLY CHECKING SCHEDULE

	CHECK UP
1	ATC GEAR BOX REPLACE ATC GEAR BOX OIL EVERY YEAR.
2	SPINDLE BELT CHECK THE TENSION AND GENERAL CONDITION OF THE BELT. REPLACE WHEN NECESSARY.
3	Z AXIS MOTOR BELT CHECK THE TENSION AND GENERAL CONDITION OF THE BELT. REPLACE WHEN NECESSARY.
4	SLIDEWAY GIB IN GENERAL PRACTICE, THE ADJUSTMENT SHOULD BE MADE IN 3 MONTHS AND 6 MONTHS AFTER INSTALLATION. AFTER THAT, CHECK SLIDE WAY LEVEL YEARLY AND ADJUST IT IF NECESSARY.
5	SPINDLE CHILLER COOLANT OIL (OPTION) REPLACE THE COOLANT OIL YEARLY TO KEEP IN BETTER PERFORMANCE.
6	MACHINE ACCURACY ACCORDING TO "ACCURACY TEST RESULT" REPORT, CHECK MACHINE ACCURACY YEARLY. CALL YOUR MACHINE AGENT IF YOU CAN NOT SOLVE THE ACCURACY PROBLEM.

6.4 LUBRICATION OF MACHINE

6.4.1 LUBRICATION

- LUBRICATION IS VERY IMPORTANT AND NOT NEGLIGIBLE TO ASSURE LONG LIFE AND HIGH LEVEL OF ACCURACY OF THE MACHINE.
- SINCE THE MACHINE CENTER IS USUALLY OPERATED CONTINUOUSLY FOR LONG HOURS UNDER HEAVY DUTY AND THERE ARE MANY PARTS THAT REQUIRES LUBRICATION, THE MACHINE EMPLOYS THE LUBRICATION SYSTEM BEST SUITED FOR SUCH APPLICATION , REQUIRING ONLY MINIMUM CARE OF LUBRICATION TO OPERATOR.
- LUBRICATION TO EACH PART OF MACHINE IS AS FOLLOWS :
 - A. GREASE SEALED LUBRICATION IS EMPLOYED FOR SPINDLE BEARINGS.
(GREASE : KLUBER ISOFLEX NBU 15 (PA0040 - A26))
 - B. X,Y AND Z AXIS BALL SCREW AND SIDE WAYS ARE FORCIBLY OILED BY LUBRICATION PUMP.
 - C. GREASE IS APPLIED TO THE COUNTERWEIGHT CHAINS, AND CROSS ROLLER GUIDE WHICH IS INSTALLED FOR ATC CROSSWISE MOVEMENT.
 - D. FOR ALL OTHER BEARINGS, GREASE SEALED LUBRICATION IS EMPLOYED.

6.4.2 REOILING

IT IS MANDATORY TO MAINTAIN A SUITABLE AMOUNT OF OIL OR GREASE WHERE LUBRICATION IS REQUIRED TO ASSURE TROUBLE-FREE, LONG OPERATION OF THE MACHINE.

BE SURE TO REPLENISH THE HIGH QUALITY, PURE OIL OR GREASE SPECIFIED IN THE LUBRICATION TABLE, AS INSTRUCTED IN THE TABLE.

- A. REOILING TO LUBRICATION PUMP TANK
 - a. FOR DETAILS ABOUT LUBRICATION PUMP REFER 6.4.1 MAINTENANCE AND ADJUSTMENT OF LUBRICATION PUMP. THE LUBRICATION PUMP TANK (A) AS SHOWN IN FIG. 6.4.1 HAS A CAPACITY OF 4.6 L. WHEN THE POWER SOURCE IS TURNED ON, THE PUMP AUTOMATICALLY STARTS AND DELIVERS OIL TO THE SPEED REDUCTION GEARINGS. THE PUMP IS ADJUSTED BY US AT SHIPPING TO DELIVER OIL AT A RATE OF 6 cc FOR EVERY 15 min.
 - b. AS NECESSARY, ADJUST THE RATE IN ACCORDANCE WITH 6.4.1 MAINTENANCE AND ADJUSTMENT OF LUBRICATION PUMP.
 - c. WHEN THE PUMP IS LEFT OUT OF OPERATION FOR ANY LENGTH OF TIME, OIL LEVEL GO DOWN IN THE PIPING. THEREFOR, HOLD DOWN THE INSTANT PUSH BUTTON (B) OF THE PUMP BEFORE STARTING THE MACHINE OPERATION, UNTIL SUFFICIENT AMOUNT OF OIL IS DISTRIBUTED TO EACH SIDE WAY.

- d. REPLENISH OIL IN THE TANK TO THE SPECIFIED LEVEL THROUGH THE OIL FILLER HOLE (C) AT THE TOP OF THE TANK WITH A SUITABLE FREQUENCY (USUALLY ONCE TWO WEEKS) THAT DEPENDS ON THE SERVICE CONDITION.
- e. IF THE OIL LEVEL GOES DOWN TO ONE FOURTH OF THE SPECIFIED LEVEL, THE LAMP "LUBRICATION LEVEL" WILL LIGHTS, IMMEDIATELY REPLENISH OIL.




FIG. 6.4.1 REOILING LUBRICATION PUMP TANK

B. GREASING TO COUNTERWEIGHT ROLLER CHAIN (OPTION)

- a. IF YOUR MACHINE IS WITHOUT COUNTERWEIGHT, SKIP THIS SECTION.
- b. THE SPINDLE HEAD IS CONNECTED WITH THE COUNTERWEIGHT THROUGH THE ROLLER CHAIN A AS SHOWN IN FIG 6.4.2. ALTHOUGH SELECTED ROLLER CHAIN CAPABLE OF WITHSTANDING THE REQUIRED LOAD IS USED, BE SURE TO GREASE THE CHAIN ONCE EVERY 6 MONTHS.
- c. TO GREASE, REMOVE THE UPPER COVER OF COLUMN.




FIG. 6.4.2 GREASING TO COUNTERWEIGHT ROLLER CHAIN

C. REOILING TO LUBRICATOR OF PNEUMATIC UNIT

REMOVE THE BOWL GUARD AS SHOWN IN FIG 6.5.1 TO REPLENISH OIL IN THE LUBRICATOR OF PNEUMATIC UNIT. THE LUBRICATION SHOULD BE FILLED WITH OIL UP TO THE UPPER LIMIT OF THE LEVEL GAUGE (ABOUT 80 % OF LUBRICATOR CAPACITY).

NOTICE : TO MUCH OIL MAY CAUSE STANDSTILL TO THE LUBRICATOR. CHECK OIL LEVEL WEEKLY AND REPLENISH OIL IF NECESSARY.

D. GREASING TO CROSS ROLLER GUIDE

THE CROSS ROLLER GUIDE (A) AS SHOWN IN FIG 6.4.3 IS USED FOR ATC CROSSWISE MOVEMENT. TO GREASE, REMOVE ATC MAGAZINE COVER (B) . BE SURE TO GREASE THE CROSS ROLLER GUIDE ONCE EVERY 6 MONTHS




FIG. 6.4.3 GREASING TO CROSS ROLLER GUIDE

6.5 LUBRICATION TABLE

	PART TO BE OILED	FREQUENCY	Q'TY	LUBRICANT	REMARKS
A	LUBRICATION PUMP	1-2 WEEKS	4L	1	CHECK OIL LEVEL IN THE TANK AND REPLENISH IF NECESSARY.
B	COUNTERWEIGHT ROLLER CHAIN	6 MONTHS		3	BRUSH LUBRICANT.
C	LUBRICATOR OF PNEUMATIC	WEEKLY	0.17L	2	IMMEDIATELY REPLENISH IF OIL LEVEL IS FOUND BELOW THE SPECIFIED LEVEL
D	ATC GEAR OIL	EVERY YEAR	5.5 L	2	IMMEDIATELY REPLENISH IF OIL LEVEL IS FOUND BELOW THE SPECIFIED LEVEL
E	TOOL MAGAZINE	6 MONTHS		3	BRUSH LUBRICANT
F	SPINDLE GEAR BOX	6 MONTHS	25 L	2	IMMEDIATELY REPLENISH IF OIL LEVEL IS FOUND BELOW THE SPECIFIED LEVEL

6.5.1 APPLICABLE LUBRICANTS

LUBRICANT	SHELL	ESSO	MOBIL
1	SHELL TONNAOIL	FEBIS K68	MOBIL VACTRA OIL NO.2
2	SHELL TURBIN OIL T32	TERESSO 32	MOBIL DTE OIL LIGHT
3	SHELL ALVANIA GREASE 2	TENPCEX N2	MOBIL UX 2

6.5.2 CAUTIONS ON OILING

- THE FOLLOWING CAUTIONS ARE VERY IMPORTANT WHEN OILING.
 - A. USE ONLY SPECIFIED OIL OR GREASE WITH SPECIFIED QUANTITY.
THE USE OF OIL OR GREASE OTHER THEN SPECIFIED AND TO MUCH AMOUNT OF OIL OR GREASE MAY ADVERSELY AFFECT THE PERFORMANCE OF THE MACHINE.
 - B. CLEAN THE SIDE WAYS, OIL FILLER HOLES, OIL TANK, ETC. BEFORE POURING OIL AND USE CARE NOT TO POLLUTE OIL WHEN POURING OIL.
 - C. WHEN POURING OIL, PLACE A FILTER OVER OIL FILLER HOLE TO ELIMINATE DUST AND CONTAMINATOR. IF FILTER IS NOT AVAILABLE, USE A WIRE NET OF 150 MESH OR FINER.
 - D. SUCCESSIVELY USE THE IDENTICAL OIL OR GREASE. NOTICE THAT THE USE OF OIL HAVING DIFFERENT PROPERTIES MIGHT DEGRADE THE OIL.
 - E. EVEN WHEN NEW OIL IS DRAINED, AND USED AGAIN FOR REASSEMBLING, REPLACEMENT OF PART OR ANY OTHER REASON, BE SURE TO FILTER THE OIL WHEN POURING THE OIL AGAIN.
 - F. DO NOT FULLY USE OIL OF OIL CAN, BUT LEAVE A SMALL QUANTITY OF OIL IN THE CAN. THIS CAUTIONS SHOULD BE FOLLOWED TO ELIMINATE MOISTURE AND SEDIMENT FROM OIL

- G. LUBRICATION TANK SHOULD BE CLEAN EVERY 6 MONTH, CLEAN AND QUALIFY OIL IS CONCERNING MACHINE LIFE AND DISTRIBUTER OF OIL PIPING (MIGHT CAUSE STUCK AND SHORT THE MACHINE LIFE)

6.5.3 MAINTENANCE AND ADJUSTMENT OF LUBRICATION PUMP

- A. LUBRICATION PUMP WITH A PRESSURE GAUGE AND MANUAL SWITCH FOR MANUAL DISCHARGE. WHEN NECESSARY, THIS PUMP ARE CONTROL BY PLC 30 SECONDS OF RUNNING TIME AND 1000 SECOND OF INTERMITTENT TIME. THIS TIMER WAS BE PRESENTED INSIDE OF CNC PLC. PLEASE REFER TO YOUR LADDER DIAGRAM FOR DETAIL.
- B. AS A FLOAT SWITCH WAS EQUIPPED WHEN OIL LEVEL DROOPS. THE



LAMP WILL BE LIGHTED AND BUZZER SOUND AND SWITCH TO SINGLE BLOCK AUTOMATICALLY. PLEASE REPLENISH THE OIL FOR CONTINUE OPERATIONS.

6.6 MAINTENANCE AND ADJUSTMENT OF AIR SOURCE AND PNEUMATIC UNITS

THE FOLLOWING MOVEMENT AND FUNCTIONS ARE DRIVEN BY COMPRESSED AIR

- A * SPINDLE TOOL UNCLAMP.
- B * SPINDLE AIR BLOW.
- C * TOOL POT MOVEMENT (UP / DOWN)
- D * SPINDLE TURNING AIR BLOW.
- E * COOLANT THROUGH SPINDLE AIR BLOW. (OPTION)

6.6.1 AIR SOURCE

A. THE PNEUMATIC AIR SOURCE.

- a. THE PNEUMATIC ARE DESIGNED TO WORK WITH COMPRESSED AIR AT 5.5 bar THERE FOR, USE AN AIR SOURCE AT CONSTANT PRESSURE OF AT LEAST 6 bar.
- b. THE PNEUMATIC AIR SOURCE HAS BEEN SET UP BEFORE SHIPPING OUT THE MACHINE.
- c. TO ADJUST THE AIR PRESSURE (SEE FIG. 6.4.1) PULL THE STUD (B) ADJUST IT TO 6 bar . IF THE AIR PRESSURES STILL NOT ENOUGH, CHECK THE AIR SOURCE.
- d. ALTHOUGH AIR FILTER IS PROVIDED TO PROTECT THE PNEUMATIC LINE, THE AIR FREE FROM MOISTER OIL AND DUST SHOULD BE SUPPLIED, AND PURIFIED BY AIR FILTER OF 5 MICRONS.
- e. IT IS SUGGESTED TO ADD A EXTRA MIST SEPARATOR INFRONT OF THE PNEUMATIC AIR SOURCE IF FOUND THE QUATILY OF THE AIR SOURCE CONTANT MUCH MOISTURE.
- f. FOR DETAIL OF THE AIR LINE, REFER TO THE AIR CIRCUIT DIAGRAM FIG 6.4.1. .
- g. THE PNEUMATIC UNIT (THAT CONSISTS OF AIR FILTER, REDUCTION VALVE, PRESSURE GAUGE, LUBRICATOR, ETC.) MIST SEPARATOR REDUCTION VALVE AND PRESSURE SWITCH ARE INSTALLED AT THE BACK OF THE MACHINE.
- h. THE SOLENOID VALVES AND SPEED CONTROLLER AND EXHAUST CLEANER ARE INSTALLED ON THE TOP OF THE ATC.
- i. REFER TO PARTS LIST FOR DETAIL CONNECTION PARTS NO.

B. THE AIR PRESSURE DETECTOR

- a. IF THE AIR PRESSURE IS UNDER 6 bar , IT MAY CAUSE THE ERROR MOVEMENT OF THE MACHINE, THE AIR PRESSURE DETECTOR CAN MAKE SURE THE AIR PRESSURE ALWAYS HIGHER THEN 6 bar . IF THE AIR PRESSURE IS UNDER 4 bar , MACHINE ALARMS AND YOU HAVE TO CHECK THE AIR SOURCE.

- b. THE AIR PRESSURE DETECTOR HAVE BEEN SET UP BEFORE SHIPPING OUT THE MACHINE.
- c. TO ADJUST THE AIR PRESSURE DETECTOR, (SEE FIG. 6.6.1)
ADJUST (E) TO 0 (WITH DRIVE SCREW) AND ADJUST (F) TO 4 .

C. SPINDLE TOOL UNCLAMP

- a. AIR BLOW ACTIVE WHEN EXCUTE TOOL UNCLAMP.
- b. AS FIG 6.6.1 GAUGE (A) ADJUST THE AIR PRESSURE TO 6 bar ,
PULL THE STUD (B) TO ADJUST.

D. SPINDLE AIR BLOW

- a. AIR BLOW ACTIVE WHEN EXCUTE TOOL UNCLAMP..
- b. AS FIG 6.6.1 GAUGE (C) ADJUST THE AIR PRESSURE TO 2 bar ,
PULL THE STUD (D) TO ADJUST.

E. COOLANT THROUGH SPINDLE AIR BLOW

- a. AIR BLOW ACTIVE WHEN EXCUTE COOLANT THROUGH SPINDLE.
- b. AS FIG 6.6.1 GAUGE (G) ADJUST THE AIR PRESSURE TO 2 bar ,
PULL THE STUD (H) TO ADJUST.

F. SPINDLE TURNING AIR BLOW

- a. AIR BLOW ACTIVE WHEN SPINDLE TURNING.
- b. AS FIG 6.6.1 GAUGE (K) ADJUST THE AIR PRESSURE TO 2 bar ,
PULL THE STUD (L) TO ADJUST




FIG. 6.6.1 AIR SOURCE ADJUSTMENT




FIG. 6.6.2 AIR LINE LUBRICATOR

6.6.2 AIR LINE LUBRICATOR (FIG. 6.6.2)

THIS DEVICE SUPPLIES LUBRICATING OIL, NECESSARY TO OIL EACH CYLINDER AND CYLINDER VALVE FOR ATC CROSSWISE MOVEMENT, ATC MAGAZINE VERTICAL MOVEMENT, TOOL UNCLAMP FROM THE MIST INVOLVE IN THE COMPRESSED AIR

A. INSTALLATION :

INSTALL LUBRICATOR WITH BOWL VERTICAL IN PIPE LINE SO THAT AIR FLOWS IN THE DIRECTION OF THE ARROW LOCATED ON THE LUBRICATOR BODY.

THE LUBRICATOR CAN BE FILLED WHILE UNDER PRESSURE. JUST REMOVE THE OIL FILL PLUG AND FILL THE LUBRICATOR TO OIL LEVEL LIMIT LINE USING CLEAN AND PURE LUBRICANT.

B. OPERATION

OIL FEED RATE CAN BE ADJUSTED BY THE NEEDLE STUDDED. CLOCKWISE ROTATION OF THE NEEDLE STUD DECREASES OIL FEED RATE.

C. MAINTENANCE:

IF OIL DOES NOT FLOW FROM OIL DRIP TUBE.

- a. MAKE SURE THE AIR INSTALLED IN THE CORRECT DIRECTION. IF NOT, REINSTALL IT.
- b. CHECK THE OIL LEVEL. ADJUST OIL QUANTITY IF THE LEVEL EXCEED THE LIMIT LINE OR DOES NOT REACH THE END OF SIPHON TUBE.
- c. IF OIL LEAKS AROUND THE NEEDLE STUD CHECK IF THE NEEDLE STUD IS OPEN EXCESSIVELY, IF SO, CLOSE IT TO THE RIGHT POSITION.

- d. TAKE OFF BOWL GUARD AND CHECK O RING (ON THE TOP OF THE BOWL GUARD), IF THE O RING IS DAMAGED, REPLACE IT.

CAUTION : DO NOT USE THE LUBRICATOR NEAR OR IN CONTACT WITH SUCH ORGANIC SOLVENTS AS LACQUER THINNERS, ALCOHOL, ETC., AS THE MATERIALS WILL DAMAGE THE PLASTIC BOWL. IF NECESSARY TO CLEAN THE PLASTIC BOWL, USE NEUTRAL CLEANSER ONLY. TEMPERATURE AND OPERATING PRESSURE SHOULD NOT EXCEED THE MAXIMUM LIMITS MARKED ON THE LUBRICATOR BOWL

6.6.3 AIR TANK

RELEASE THE MOISTURE RELEASE VALVE IN THE BOTTOM OF THE TANK EVERY WEEK, IF FOUND MANY WATER COMEING OUT, CHECK THE QUALITY OF THE INCOMING AIR.

HIGHEST PRESSURE: 10 bar

6.6.4 . JOINT AND HOSE

A. AIR HOSE

MARKER: U - KHAN

MODEL: POLYURETHANE 5 X 8 O.D. X I.D. : 8 X 5 mm

MINIMUM BENDING DIAMETER: 55 R mm

TEMP. : - 40 °C - 100 °C

HIGHTEST PRESSURE: 7 bar

B. QUICK-FIT JOINT

MARKER: NIHON LEGRIS

MODEL: CONNECTOR 31750813 ELBOW 31090813

- a. EACH PNEUMATIC DEVICE IS CONNECTED WITH NYLON RESIN HOSE AND QUICK-FIT TYPE JOINT IS USED. THE QUICK-FIT TYPE JOINT PERMITS HOSE TO BE IMMEDIATELY CONNECTED ONLY BY INSERTING THE HOSE IN THE JOINT.
- b. AFTER THE CONNECTION, MAKE SURE THE CONNECTOR IS SECURELY HELD IN THE COUPLING AND NO LEAKAGE OCCURS.
- c. FOR DISCONNECTION OF HOSE, PRESS DOWN THE RING-LIKE PART AND PULL THE HOSE AS FIG. 6.6.3





FIG. 6.6.3 DISCONNECTING OF HOSE


6.6.5 CIRCUIT DIAGRAM OF AIR SYSTEM

A. #40 DIRECT DRIVE SPINDLE



#40 DIRECT DRIVE SPINDLE AIR SYSTEM PARTS LIST				
PARTS NO.		DESCRIPTION	REMARKS	
1	5541-3014-100	GAS TANK	儲氣桶	1
2	5541-3323-100	ONE TOUCH CONNECTOR	快速接頭	5
3	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	1
4	5541-3334-100	ONE TOUCH CONNECTOR	快速彎頭	1
5	5541-8180-200	ADJUSTABLE PRESSURE VALVE	調壓閥組	3
6	5541-3284-100	ONE TOUCH CONNECTOR	快速彎頭	1
7	5541-3283-100	ONE TOUCH CONNECTOR	快速彎頭	1
8	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	3
9	5541-3297-100	ONE TOUCH CONNECTOR	快速接頭	1
10	1500-1081-100	ONE TOUCH CONNECTOR	快速彎頭	2
11	1051-2601-100	ONE TOUCH CONNECTOR	快速接頭	1
12	5541-3328-100	ONE TOUCH CONNECTOR	快速彎頭	2
14	5541-3015-100	ONE TOUCH CONNECTOR	快速彎頭	1
15	5541-3262-100	ONE TOUCH CONNECTOR	快速彎頭	5
16	5541-8150-300	AIR UNIT SET	三點組合組	1
18	5511-3336-100	AIR COCK	小型拷克內外牙	1
19	5541-3261-100	ONE TOUCH CONNECTOR	快速接頭	1
20	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	2
21	5541-3320-200	SINGLE SOLENOID	電磁閥	1
22	2000-2293-100	CYLINDER	倍力氣壓缸	1
23		CONNECTOR	3/8" (9.5 mm)PT彎頭	1
24		CYLINDER	導刀氣壓缸	1
25	5541-3321-200	SINGLE SOLENOID	電磁閥	1
26	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	2
27		CYLINDER	鎖退刀油氣壓缸	1
28	5541-3341-100		手動閥	1


B. #40 SPINDLE



#40 SPINDLE AIR SYSTEM PARTS LIST

PARTS NO.		DESCRIPTION	REMARKS	
1	5541-3014-100	GAS TANK	儲氣桶	1
2	5541-3323-100	ONE TOUCH CONNECTOR	快速接頭	5
3	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	1
4	5541-3334-100	ONE TOUCH CONNECTOR	快速彎頭	1
5	5541-8180-200	ADJUSTABLE PRESSURE VALVE	調壓閥組	3
6	5541-3284-100	ONE TOUCH CONNECTOR	快速彎頭	1
7	5541-3283-100	ONE TOUCH CONNECTOR	快速彎頭	1
8	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	3
9	5541-3297-100	ONE TOUCH CONNECTOR	快速接頭	1
10	1500-1081-100	ONE TOUCH CONNECTOR	快速彎頭	2
11	1051-2601-100	ONE TOUCH CONNECTOR	快速接頭	1
12	5541-3328-100	ONE TOUCH CONNECTOR	快速彎頭	2
14	5541-3015-100	ONE TOUCH CONNECTOR	快速彎頭	1
15	5541-3262-100	ONE TOUCH CONNECTOR	快速彎頭	5
16	5541-8150-300	AIR UNIT SET	三點組合組	1
18	5511-3336-100	AIR COCK	小型拷克內外牙	1
19	5541-3261-100	ONE TOUCH CONNECTOR	快速接頭	1
20	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	2
21	5541-3320-200	SINGLE SOLENOID	電磁閥	1
22	1200-1157-400	CYLINDER	倍力氣壓缸	1
23		CONNECTOR	3/8" (9.5 mm)PT彎頭	1
24		CYLINDER	導刀氣壓缸	1
25	5541-3321-200	SINGLE SOLENOID	電磁閥	1
26	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	2
27	5541-3341-100		手動閥	1

C. #50 SPINDLE



#50 SPINDLE AIR SYSTEM PARTS LIST				
PARTS NO.		DESCRIPTION	REMARKS	
1	5541-3014-100	GAS TANK	儲氣桶	1
2	5541-3323-100	ONE TOUCH CONNECTOR	快速接頭	5
3	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	1
4	5541-3334-100	ONE TOUCH CONNECTOR	快速彎頭	1
5	5541-8180-200	ADJUSTABLE PRESSURE VALVE	調壓閥組	3

6	5541-3284-100	ONE TOUCH CONNECTOR	快速彎頭	1
7	5541-3283-100	ONE TOUCH CONNECTOR	快速彎頭	1
8	5541-3314-100	ONE TOUCH CONNECTOR	快速接頭	6
9	5541-3297-100	ONE TOUCH CONNECTOR	快速接頭	1
10	1500-1081-100	ONE TOUCH CONNECTOR	快速彎頭	2
11	1051-2601-100	ONE TOUCH CONNECTOR	快速接頭	1
12	5541-3328-100	ONE TOUCH CONNECTOR	快速彎頭	2
14	5541-3015-100	ONE TOUCH CONNECTOR	快速彎頭	1
15	5541-3262-100	ONE TOUCH CONNECTOR	快速彎頭	5
16	5541-8150-300	AIR UNIT SET	三點組合組	1
18	5511-3336-100	AIR COCK	小型拷克內外牙	1
19	5541-3261-100	ONE TOUCH CONNECTOR	快速接頭	1
20	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	2
21	5541-3320-200	SINGLE SOLENOID	電磁閥	1
22	1200-1157-500	CYLINDER	倍力氣壓缸	1
23		CONNECTOR	3/8" (9.5 mm)PT彎頭	1
24		CYLINDER	導刀氣壓缸	1
25	5541-3321-200	SINGLE SOLENOID	電磁閥	2
26	5541-3208-600	AIR NOISE ELIMINATOR	銅消音濾清器	4
27	1500-1169-100	HI-LOW SLIDING	高低檔氣壓缸	1
28	1500-1080-100	ANTI-BACK VALVE	空壓誘導止回閥	1
29	1500-2514-100	ONE TOUCH CONNECTOR	三通快速接頭	1
30	5541-3341-100		手動閥	1

6.7 PARAMETER FOR LUBRICATION

DGN TIMER SETTING ADDR'S	DESCRIPTION	DEFAULT SETTING
1	LUBRICATOIN ON TIME	19968 (ABOUT 20 sec)
2	LUBRICATION OFF TIME	999984 (ABOUT 17 min)

6.8 ADJUSTMENT OF SLIDEWAY GIBS

WITH TIME, THE SLIDE WAY WEAR AND THEREFORE MUST BE ADJUSTED THROUGH THE GIBS.

THE GIB ADJUSTING SCREW FOR X AXIS IS FOUND AT THE LEFT OF THE TABLE VIEWED FROM THE MACHINE FRONT, THE GIB ADJUSTING SCREW FOR Y AXIS AT THE FRONT OF THE SADDLE, AND THE GIB ADJUSTING SCREW FOR Z AXIS ON THE TOP OF THE COLUMN .

IN GENERAL PRACTICE, THE ADJUSTMENT SHOULD BE MADE IN 3 MONTHS AND 6 MONTHS AFTER INSTALLATION. AFTER THAT, CHECK SLIDE WAY LEVEL YEARLY AND ADJUST IT IF NECESSARY.

TO ADJUST SLIDE WAY LEVEL, PROCEED AS FOLLOWS : (AS SHOWN IN FIG. 6.8.1)

- A. LOOSEN 3 - 4 TURNS GIB LOCK SCREW.
- B. FULLY TIGHTEN GIB ADJUSTING SCREW.
- C. LOOSEN ONE TURN THE GIB ADJUSTING SCREW.
- D. TIGHTEN THE GIB LOCK SCREW.

NOTICE: THAT TOO TIGHTLY CLAMPED GIB MAY HINDER SMOOTH MOVEMENT, ACCELERATE WEAR AND, IN EXTREME CASE, RESULT IN SEIZURE. WHEN ADJUSTING SLIDE WAY GIBS. PLEASE INFORM OUR SERVICEMAN.




FIG.6.8.1 ADJUSTMENT OF SLIDE WAY GIBS

7. Trouble Shooting

Device	1. ATC									
Status	1.1 Wrong tool number (arm type)									
Reason 1	Contamination on magazine counter sensor									
Reason 2	Wrong operation									
Fix 1	1. Eliminate the contamination on magazine counter sensor. 2. Follow Fix 2 step.									
Fix 2	Reset the tool data table, "G.DATA" setting After you reset the tool data table, you also have to check the tool number on tool data table. a. Execute M2000 and cycle start to confirm b. The magazine will go reference to pot1 c. Check tool data table, "G.DATA" setting Refer to parameter list "DGN SETTING" for the correct tool number.									
Status	1.2 Wrong tool number (armless type)									
Reason 1	Contamination on magazine counter sensor									
Reason 2	Wrong operation									
Fix 1	a. Eliminate the contamination on magazine counter sensor. b. Follow Fix 2 step.									
Fix 2	Reset the tool data table, "G.DATA" setting After you reset the tool data table, you also have to check the tool number on tool data table. a. Execute M2000 and cycle start to confirm b. The magazine will go reference to pot1 c. Check tool data table, "G.DATA" setting Refer to parameter list "DGN SETTING" for the correct tool number.									
Status	1.3 ATC Arm not in position (arm type)									
Reason 1	Because emergency stop button Pushed.									
Reason 2	Arm is in position. But sensor failure (no signal).									
Reason 3	Sensor failure.									
Reason 4	Motor break failure.									
Fix 1	1. Push emergency stop button 2. Rotate the ATC arm manually (use allen key) upon the tool changer motor, until <table border="1"><tr><td>0iM</td><td>18iMB/21iMA</td></tr><tr><td>X10.2</td><td>X24.2</td></tr><tr><td>X10.3</td><td>X24.3</td></tr><tr><td>X10.1</td><td>X24.1</td></tr></table> 3. Let the ATC arm be on the original position 4. Check tool data table, "G.DATA" setting 5. Release emergency stop button		0iM	18iMB/21iMA	X10.2	X24.2	X10.3	X24.3	X10.1	X24.1
0iM	18iMB/21iMA									
X10.2	X24.2									
X10.3	X24.3									
X10.1	X24.1									



	Refer to parameter list "DGN SETTING" for the correct tool number.
Fix 2	Adjust the distance between sensor and DOG. <ol style="list-style-type: none"> 1. When arm is in position. 2. Release the lock screw of sensor. 3. Rotate the sensor clockwise slowly until touch the DOG. 4. Rotate the sensor anti-clockwise for 1 and 1/2 turn. 5. Secure the lock screw.
Fix 3	Change sensor
Fix 4	<ol style="list-style-type: none"> 1. Turn off the power. 2. Rotate the ATC arm motor on the top of ATC, until arm in position. 3. If happen very often, change break.
Status	1.4 ATC not in position (armless type)
Reason 1	Because emergency stop button Pushed.
Fix 1	<ol style="list-style-type: none"> a. Release emergency stop button b. Select Manual mode c. Set keep relay K7.0=1 d. (magazine forward) <div data-bbox="552 869 651 954" data-label="Image"> </div> press to go to spindle side(M19 first) (magazine backward) <div data-bbox="552 1055 651 1140" data-label="Image"> </div> press to move back magazine to initial position e. Let the ATC magazine be on the original position f. Set keep relay K7.0=0 g. Push power off/on h. Perform reference point return of all axes(ATC magazine also) i. Check tool data table, "G.DATA" setting Refer to parameter list "DGN SETTING" for the correct tool number.
Status	1.5 ATC home not in position (arm type)
Reason 1	Home DOG not in sensor detect position.
Fix 1	<ol style="list-style-type: none"> 1. Select zero return mode 2. Press magazine cw and cycle start together 3. Magazine go to reference automatically
Status	1.6 ATC magazine can not rotate or not smooth (armless type)
Reason 1	Motor breakdown
Reason 2	Foreign matter jammed in the CAM system.
Reason 3	Tool magazine twist.
Fix 1	Change motor
Fix 2	<ol style="list-style-type: none"> 1. Turn off the power 2. Eliminate the foreign matter.
Fix 3	Change tool magazine.

Device	2. Air system
Status	2.1 Air pressure low
Reason 1	Inlet of air pressure to low.
Reason 2	Air leaking
Reason 3	Air filter blocked.
Reason 4	Magnetic valve failure.
Fix 1	Check the inlet pressure.
Fix 2	1. Check the leaking 2. Replace the pipe or connector.
Fix 3	Clean the air filter
Fix 4	Replace the magnetic valve.

Device	3. Spindle coolant system
Status	3.1 Can not reach the setting temperature.
Reason 1	Wrong setting.
Reason 2	Filter blocked.
Reason 3	Cycling coolant oil not enough.
Reason 4	Refrigerative not enough.
Fix 1	Set the temperature difference to -2 (compare with room temperature)
Fix 2	Clean the filter.
Fix 3	1. Refill the coolant oil 2. Check if oil pipe leaking.
Fix 4	1. Refill Refrigerative. 2. This operation need to be done by certificate technical person. Warning!! Do not operate by yourself. 3. Call your machine agent for replacement.
Status	3.2 Function failed
Reason 1	Overload of motor protective switch
Reason 2	Motor defective
Reason 3	Wrong power inlet phase
Fix 1	1. Check motor protective switch 2. Check oil pipe 3. Check oil
Fix 2	Check motor power line isolation
Fix 3	Change power inlet phase

Device	4. Chip Flush and coolant
Status	4.1 Coolant flow rate to low
Reason 1	Coolant filter blocked.
Reason 2	Coolant pipe leaking or blocked
Fix 1	Clean the filter
Fix 2	Check if any leaking or blocked of the pipe.

Status	4.2 Function failed
Reason 1	Low coolant level
Reason 2	Overload of motor protective switch
Reason 3	Motor defective
Reason 4	Wrong power inlet phase
Fix 1	Refill the coolant.
Fix 2	1. Check motor protective switch 2. Chip jammed, clean the filter, remove the chip
Fix 3	Check motor power line isolation
Fix 4	Change power inlet phase

Device	5. Coolant through spindle
Status	5.1 Coolant flow rate to low
Reason 1	Coolant filter blocked.
Reason 2	Coolant pipe leaking or blocked
Reason 3	Shuttle Valve failed
Reason 4	C.T.S. connector failed
Fix 1	Clean the filter
Fix 2	Check if any leaking or blocked of the pipe.
Fix 3	 <ol style="list-style-type: none"> Shuttle valve is on the top of the spindle over the tool clamping cylinder. (check parts list for detail) there are two inlet on the top and one outlet on the side. test with air blow from one of the inlet and check if there is leaking from another inlet. if there is leaking replace the valve.
Fix 4	 <ol style="list-style-type: none"> C.T.S. connector is on the top of the spindle. (check parts list for detail) check if the connector breakdown. (bracken or change shape) change a new one. if the connector is dirt and stocked, clean it and reassemble. (in this case be ware to check the filter in the C.T.S. coolant tank)
Status	5.2 Function failed
Reason 1	Wrong tool shank and stud.
Reason 2	Low coolant level
Reason 3	Overload of motor protective switch

Reason 4	Motor defective
Reason 5	Wrong power inlet phase
Reason 6	level sensors fault
Fix 1	Must use tool shank and stud for coolant through spindle.
Fix 2	Refill the coolant.
Fix 3	<ol style="list-style-type: none"> 1. Check motor protective switch 2. Chip jammed, clean the filter, remove the chip 3. Check coolant pipe
Fix 4	Check motor power line isolation
Fix 5	Change power inlet phase
Fix 6	Check level sensors

Device	6. Chip conveyor
Status	6.1 Noise or running not smooth
Reason 1	Chip stock on the conveyor.
Reason 2	Conveyor screw change shape. (spiral type)
Fix 1	<ol style="list-style-type: none"> 1. Machine Power off. 2. Check and clean the chip stock in the conveyor.
Fix 2	<ol style="list-style-type: none"> 1. Machine power off 2. Take off the screw and try to recover the shape. 3. If screw can not recover, contact your machine agent.
Status	6.2 Function failed
Reason 1	Overload of motor protective switch
Reason 2	Motor defective
Reason 3	Wrong power inlet phase
Fix 1	<ol style="list-style-type: none"> 1. Check motor protective switch 2. Chip jammed, chip conveyor ccw to remove
Fix 2	Check motor power line isolation
Fix 3	Change power inlet phase

Device	7. Vacuum dust collector
Status	7.1 Weak vacuum power
Reason 1	Vacuum filter blocked.
Reason 2	Vacuum pipe leaking.
Fix 1	Clean the filter.
Fix 2	<ol style="list-style-type: none"> 1. Check the vacuum pipe. 2. Replace if necessary.
Status	7.2 Function failed
Reason 1	Overload of motor protective switch
Reason 2	Motor defective
Reason 3	Wrong power inlet phase
Fix 1	<ol style="list-style-type: none"> 1. Check motor protective switch 2. Powder jammed, clean the filter, remove the powder
Fix 2	Check motor power line isolation
Fix 3	Change power inlet phase

8. Alarm Message

- THE ALARM MESSAGE BELOW ARE REGARDING TO THE PLC MADE BY LONG CHANG MACHINERY.
- FOR THE ALARM MESSAGE REGARDING TO FANUC SYSTEM, PLEASE REFER TO FANUC OPERATOR'S MANUAL.

MESSAGE	1000 TOOL CLP/UCLP LIMIT SWITCH ERR (ADDRESS A0.0)
REASON & SOLUTION	1. CHECK TOOL CLAMP/UNCLAMP LIMIT SWITCH 2. ERROR CONDITION: TOOL CLAMP/UNCLAMP LIMIT SWITCH ON/ON OR OFF/OFF
MESSAGE	1001 TOOL CLP/UCLP OVERTIME ERROR (ADDRESS A0.1)
REASON & SOLUTION	1. CHECK TOOL CLAMP/UNCLAMP LIMIT SWITCH 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER
MESSAGE	1002 GEAR CHANGE ERROR (ADDRESS A0.2)
REASON & SOLUTION	1. CHECK GEAR LOW/HIGH SENSOR 2. ERROR CONDITION: GEAR LOW/HIGH SENSOR ON/ON OR OFF/OFF 3. CHECK AIR VALVE 4. CHECK AIR CYLINDER
MESSAGE	1003 SPINDLE TOOL NOT CLAMPED (ADDRESS A0.3)
REASON & SOLUTION	1. CHECK TOOL CLAMP/UNCLAMP LIMIT SWITCH 2. NORMAL CONDITION: TOOL CLAMP/UNCLAMP LIMIT SWITCH ON/OFF
MESSAGE	1004 GEAR CHANGE OVERTIME (ADDRESS A0.4)
REASON & SOLUTION	1. CHECK GEAR LOW/HIGH SENSOR 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER 4. CHECK TIMER SETTING
MESSAGE	1005 GEAR NOT IN-POSITION (ADDRESS A 0.5)
REASON & SOLUTION	1. CHECK GEAR LOW/HIGH SENSOR 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER 4. MAINTENANCE MODE: (1) SET K2.3=1 (2) POWER OFF (3) POWER ON (4) MANUAL MODE (5) PRESS SPINDLE CW PB. OR SPINDLE CCW PB. (6) SET K2.3=0
MESSAGE	1006 SPINDLE BEARING OVERHEAT (ADDRESS A0.6)
REASON & SOLUTION	

MESSAGE	1008 BEARING TEMP OUT OF RANGE (ADDRESS A1.0)
REASON & SOLUTION	
MESSAGE	1010 X AXIS OVER TRAVEL (ADDRESS A1.2)
REASON & SOLUTION	1. X AXIS OVER TRAVEL 2. CHECK X AXIS OVER TRAVEL LIMIT SWITCH 3. CHECK SIGNAL WIRE
MESSAGE	1011 Y AXIS OVER TRAVEL (ADDRESS A1.3)
REASON & SOLUTION	1. Y AXIS OVER TRAVEL 2. CHECK Y AXIS OVER TRAVEL LIMIT SWITCH 3. CHECK SIGNAL WIRE
MESSAGE	1012 Z AXIS OVER TRAVEL (ADDRESS A1.4)
REASON & SOLUTION	1. Z AXIS OVER TRAVEL 2. CHECK Z AXIS OVER TRAVEL LIMIT SWITCH 3. CHECK SIGNAL WIRE
MESSAGE	1020 TOOL CHANGER INVERTER ERROR (ADDRESS A2.4)
REASON & SOLUTION	1. CHECK MAGAZINE MOTOR 2. CHECK MAGAZINE FWD/BWD MOTOR 3. CHECK ATC ARM MOTOR 4. CHECK INVERTER
MESSAGE	1021 MAGAZINE ROTATING OVERTIME (ADDRESS A2.5)
REASON & SOLUTION	1. MAGAZINE MOTOR NOT ROTATE 2. CHECK MAGAZINE MOTOR 3. CHECK POWER LINE INLET PHASE
MESSAGE	1022 T CODE SEARCH ERROR (ADDRESS A2.6)
REASON & SOLUTION	1. T CODE OUT OF RANGE 2. CHECK TOOL DATA TABLE
MESSAGE	1023 POCKET V./H. SENSOR ERROR (ADDRESS A2.7)
REASON & SOLUTION	1. CHECK MAGAZINE POCKET VERTICAL/HORIZONTAL SENSOR 2. ERROR CONDITION: MAGAZINE POCKET VERTICAL/HORIZONTAL SENSOR ON/ON OR OFF/OFF
MESSAGE	1024 POCKET V./H. OVERTIME ERROR (ADDRESS A3.0)
REASON & SOLUTION	1. CHECK MAGAZINE POCKET VERTICAL/HORIZONTAL SENSOR 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER 4. CHECK MAGAZINE POCKET
MESSAGE	1025 ATC ARM POSITION ERROR (ADDRESS A3.1)
REASON & SOLUTION	1. ATC ARM NOT ON INITIAL POSITION 2. CHECK ATC ARM POSITION 3. CHECK ATC ARM SENSOR

MESSAGE	1026 TOOL CHANGE OVERTIME (ADDRESS A3.2)
REASON & SOLUTION	1. ATC ARM MOTOR NOT ROTATE 2. CHECK ATC ARM MOTOR 3. CHECK POWER LINE INLET PHASE
MESSAGE	1027 ATC ARM MOTOR OVERLOAD (ADDRESS A3.3)
REASON & SOLUTION	1. CHECK ATC ARM MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1028 MAGAZINE MOTOR OVERLOAD (ADDRESS A3.4)
REASON & SOLUTION	1. CHECK MAGAZINE MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1029 MAGAZINE FWD/BWD MOTOR OVERLOAD (ADDRESS A3.5)
REASON & SOLUTION	1. CHECK MAGAZINE FWD/BWD MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1040 CTS MOTOR OVERLOAD (ADDRESS A5.0)
REASON & SOLUTION	1. CHECK CTS MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1041 COOLANT MOTOR OVERLOAD (ADDRESS A5.1)
REASON & SOLUTION	1. CHECK COOLANT MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1042 CHIP FLUSH MOTOR1 OVERLOAD (ADDRESS A5.2)
REASON & SOLUTION	1. CHECK CHIP FLUSH MOTOR1 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1043 SHOWER COOLANT PUMP OVERLOAD (ADDRESS A5.3)
REASON & SOLUTION	1. CHECK SHOWER COOLANT PUMP 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1044 CHIP FLUSH MOTOR2 OVERLOAD (ADDRESS A5.4)
REASON & SOLUTION	1. CHECK CHIP FLUSH MOTOR2 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1050 LUBRICATION MOTOR OVERLOAD (ADDRESS A6.2)
REASON & SOLUTION	1. CHECK LUBRICATION MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1060 HYDRAULIC MOTOR OVERLOAD (ADDRESS A7.4)
REASON & SOLUTION	1. CHECK HYDRAULIC MOTOR 2. CHECK HYDRAULIC OIL 3. CHECK HYDRAULIC OIL PIPE 4. CHECK OVERCURRENT PROTECTOR

MESSAGE	1061 HYDRAULIC OIL LOW PRESSURE (ADDRESS A7.5)
REASON & SOLUTION	1. CHECK HYDRAULIC MOTOR 2. CHECK HYDRAULIC OIL 3. CHECK HYDRAULIC OIL PIPE 4. CHECK PRESSURE SWITCH SETTING
MESSAGE	1062 HYD OIL LOW LEVEL (ADDRESS A7.6)
REASON & SOLUTION	CHECK HYDRAULIC OIL LEVEL
MESSAGE	1063 HYD FILTER JAMMED (ADDRESS A7.7)
REASON & SOLUTION	1. CHECK HYDRAULIC UNIT FILTER 2. CHECK HYDRAULIC OIL 3. CHECK HYDRAULIC OIL PIPE
MESSAGE	1064 SP BEARING AIR PRE. LOW (ADDRESS A8.0)
REASON & SOLUTION	1. CHECK AIR SOURCE PRESSURE 2. CHECK AIR PRESSURE SWITCH SETTING 3. CHECK AIR PIPE
MESSAGE	1070 SPINDLE OIL COOLER ERROR (ADDRESS A8.6)
REASON & SOLUTION	1. CHECK SPINDLE OIL COOLER ERROR CODE
MESSAGE	1071 CHIP CONVEYOR MOTOR OVERLOAD (ADDRESS A8.7)
REASON & SOLUTION	1. CHECK CHIP CONVEYOR MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1072 VACUUM DUST COLLECTOR MOTOR O.L. (ADDRESS A9.0)
REASON & SOLUTION	1. CHECK VACUUM DUST COLLECTOR MOTOR 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1074 ABNORMAL VOLTAGE (ADDRESS A9.2)
REASON & SOLUTION	1. CHECK POWER INLET VOLTAGE
MESSAGE	1075 LINEAR MOTOR COIL COOLER O.L. (ADDRESS A9.3)
REASON & SOLUTION	1. CHECK LINEAR MOTOR COIL COOLER ERROR CODE
MESSAGE	1076 HEAT EXCHANGER OVERLOAD (ADDRESS A9.4)
REASON & SOLUTION	1. CHECK HEAT EXCHANGER 2. CHECK OVERCURRENT PROTECTOR
MESSAGE	1077 BUILD-IN SP COIL COOLER O.L. (ADDRESS A9.5)
REASON & SOLUTION	1. CHECK BUILD-IN SPINDLE COIL COOLER ERROR CODE

MESSAGE	1078 AIR DRYER UNIT OVERLOAD (ADDRESS A9.6)
REASON & SOLUTION	1. CHECK AIR DRYER UNIT
MESSAGE	1110 X AXIS BRAKE CYL. PRE. LOW (ADDRESS A13.6)
REASON & SOLUTION	1. CHECK X AXIS BRAKE CYLINDER PRESSURE 2. CHECK X AXIS BRAKE CYLINDER PRESSURE SWITCH SETTING
MESSAGE	1111 Y AXIS BRAKE CYL. PRE. LOW (ADDRESS A13.7)
REASON & SOLUTION	1. CHECK Y AXIS BRAKE CYLINDER PRESSURE 2. CHECK Y AXIS BRAKE CYLINDER PRESSURE SWITCH SETTING
MESSAGE	1112 Z AXIS BRAKE CYL. PRE. LOW (ADDRESS A14.0)
REASON & SOLUTION	1. CHECK Z AXIS BRAKE CYLINDER PRESSURE 2. CHECK Z AXIS BRAKE CYLINDER PRESSURE SWITCH SETTING
MESSAGE	1113 LINEAR MOTOR O.H. X-1 (ADDRESS A14.1)
REASON & SOLUTION	1. CHECK LINEAR MOTOR X-1 AXIS 2. CHECK LINEAR MOTOR O.H. X-1 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER
MESSAGE	1114 LINEAR MOTOR O.H. X-2 (ADDRESS A14.2)
REASON & SOLUTION	1. CHECK LINEAR MOTOR X-2 AXIS 2. CHECK LINEAR MOTOR O.H. X-2 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER
MESSAGE	1115 LINEAR MOTOR O.H. Y-1 (ADDRESS A14.3)
REASON & SOLUTION	1. CHECK LINEAR MOTOR Y-1 AXIS 2. CHECK LINEAR MOTOR O.H. Y-1 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER
MESSAGE	1116 LINEAR MOTOR O.H. Y-2 (ADDRESS A14.4)
REASON & SOLUTION	1. CHECK LINEAR MOTOR Y-2 AXIS 2. CHECK LINEAR MOTOR O.H. Y-2 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER
MESSAGE	1117 LINEAR MOTOR O.H. Z-1 (ADDRESS A14.5)
REASON & SOLUTION	1. CHECK LINEAR MOTOR Z-1 AXIS 2. CHECK LINEAR MOTOR O.H. Z-1 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER
MESSAGE	1118 LINEAR MOTOR O.H. Z-2 (ADDRESS A14.6)
REASON & SOLUTION	1. CHECK LINEAR MOTOR Z-2 AXIS 2. CHECK LINEAR MOTOR O.H. Z-2 AXIS WIRING 3. CHECK LINEAR MOTOR COIL COOLER

MESSAGE	1120 ATC CHECK POINT NOT REACHED (ADDRESS A15.0)
REASON & SOLUTION	1. NOT ON ATC CHECK POINT 2. CHECK ATC CHECK POINT DOG 3. CHECK ATC CHECK POINT LIMIT SWITCH 4. CHECK ATC CHECK POINT LIMIT SWITCH SIGNAL WIRE
MESSAGE	1121 POCKET NOT EMPTY (ADDRESS A15.1)
REASON & SOLUTION	1. SPINDLE TOOL POCKET NOT EMPTY 2. CHECK SPINDLE TOOL POCKET SENSOR 3. CHECK SPINDLE TOOL POCKET SENSOR SIGNAL WIRE
MESSAGE	1122 MAGAZINE LOCK PIN NOT OUT (ADDRESS A15.2)
REASON & SOLUTION	1. CHECK MAGAZINE LOCK PIN SENSOR 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER
MESSAGE	1123 POCKET NOT EMPTY FOR SPECIAL TL (ADDRESS A15.3)
REASON & SOLUTION	1. LEFT/RIGHT POCKET FOR SPECIAL TOOL NOT EMPTY 2. CHECK TOOLS ON MAGAZINE 3. CHECK TOOL DATA TABLE
MESSAGE	1124 MAGAZINE FWD/BWD MOVING OVERTIME (ADDRESS A15.4)
REASON & SOLUTION	1. MAGAZINE FWD/BWD MOTOR NOT ROTATE 2. CHECK MAGAZINE FWD/BWD MOTOR 3. CHECK POWER LINE INLET PHASE
MESSAGE	1125 TOOL HOLDER NOT EMPTY (ADDRESS A15.5)
REASON & SOLUTION	1. REMOVE TOOL FROM TOOL HOLDER 2. CHECK TOOL DETECTION SENSOR
MESSAGE	2000 FORCING GEAR LOW, K2.3=1 (ADDRESS A125.0)
REASON & SOLUTION	1. MAINTENANCE MODE K2.3=1 2. SET K2.3=0
MESSAGE	2001 GEAR BOX OIL LEVEL NOT OK (ADDRESS A125.1)
REASON & SOLUTION	1. CHECK GEAR BOX OIL LEVEL 2. FILL OR REDUCE OIL
MESSAGE	2002 TEMP COMPENSATION TEST ACTIVE (ADDRESS A125.2)
REASON & SOLUTION	
MESSAGE	2010 RELEASE AXES INTERLOCK, K0.7=1 (ADDRESS A126.2)
REASON & SOLUTION	1. MAINTENANCE MODE K0.7=1 2. SET K0.7=0

MESSAGE	2011 4TH/B AXIS CLAMP/UNCLAMP ERROR (ADDRESS A126.3)
REASON & SOLUTION	1. CHECK 4TH/B AXIS CLAMP/UNCLAMP SENSOR 2. CHECK AIR VALVE 3. CHECK 4TH/B AXIS CLAMP/UNCLAMP SENSOR SIGNAL WIRE
MESSAGE	2012 M03/M04 NECESSARY ! (ADDRESS A126.4)
REASON & SOLUTION	1. SPINDLE NOT RUNNING 2. LET SPINDLE RUN
MESSAGE	2013 FEED OVERRIDE = 0 ! (ADDRESS A126.5)
REASON & SOLUTION	1. FEED OVERRIDE = 0 2. TURN THE FEED OVERRIDE ROTARY SWITCH
MESSAGE	2014 4TH/B AXIS NOT UNCLAMP ! (ADDRESS A126.6)
REASON & SOLUTION	1. 4TH/B AXIS NOT UNCLAMP 2. EXECUTE M80, 4TH AXIS UNCLAMP
MESSAGE	2020 FORCING ATC ARM ROTATING, K6.7=1 (ADDRESS A127.4)
REASON & SOLUTION	1. MAINTENANCE MODE K6.7=1 2. SET K6.7=0
MESSAGE	2021 MAGAZINE NOT REFERENCED (ADDRESS A127.5)
REASON & SOLUTION	1. MAGAZINE NOT REFERENCED 2. DO MAGAZINE REFERENCE
MESSAGE	2022 MAGAZINE COUNTER1 NOT EQUAL TO COUNTER2 (ADDRESS A127.6)
REASON & SOLUTION	1. DO MAGAZINE REFERENCE 2. CHECK TOOL DATA TABLE 3. CHECK MAGAZINE COUNTER SENSOR 4. CHECK MAGAZINE COUNTER SENSOR SIGNAL WIRE
MESSAGE	2023 MAGAZINE NOT IN-POSITION (ADDRESS A127.7)
REASON & SOLUTION	1. DO MAGAZINE REFERENCE 2. CHECK TOOL DATA TABLE 3. CHECK MAGAZINE COUNTER SENSOR 4. CHECK MAGAZINE COUNTER SENSOR SIGNAL WIRE 5. CHECK MAGAZINE PLATE/MOTOR/MOTOR BRAKE
MESSAGE	2024 TOOL CHANGE (MAINTENANCE MODE), K6.6=1 (ADDRESS A128.0)
REASON & SOLUTION	1. MAINTENANCE MODE K6.6=1 2. SET K6.6=0
MESSAGE	2025 ATC DOOR OPEN/CLOSE ERROR (ADDRESS A128.1)
REASON & SOLUTION	1. CHECK ATC DOOR OPEN/CLOSE SENSOR 2. CHECK AIR VALVE 3. CHECK AIR CYLINDER

	4. CHECK ATC DOOR OPEN/CLOSE SENSOR SIGNAL WIRE
MESSAGE	2026 FORCING MAG FORWARD/BACKWARD, K7.0=1 (ADDRESS A128.2)
REASON & SOLUTION	1. MAINTENANCE MODE K7.0=1 2. SET K7.0=0
MESSAGE	2027 MAGAZINE NOT ON BASIC POSITION (ADDRESS A128.3)
REASON & SOLUTION	1. MAGAZINE NOT ON BASIC POSITION 2. CHECK MAGAZINE BACKWARD LIMIT SWITCH 3. CHECK MAGAZINE BACKWARD LIMIT SWITCH SIGNAL WIRE
MESSAGE	2028 M1006 ACTIVE AFTER ESP RELEASE, K7.4=1 (ADDRESS A128.4)
REASON & SOLUTION	1. SET K7.4=0
MESSAGE	2029 DO NOT PRESS RESET DURING TOOL CHANGE. 1. PUSH EMG STOP TO CLEAR 2. EXECUTE M2000 (POCKET DATA TABLE INITIAL SETTING) 3. CHECK POCKET DATA TABLE AND TOOL NO. (ADDRESS A128.5)
REASON & SOLUTION	1. DO NOT PRESS RESET DURING TOOL CHANGE. 2. PUSH EMG STOP TO CLEAR 3. EXECUTE M2000 (POCKET DATA TABLE INITIAL SETTING) 4. CHECK POCKET DATA TABLE AND TOOL NO.
MESSAGE	2030 WORKPIECE LOADING STATION NOT ON ORIGIN (ADDRESS A128.6)
REASON & SOLUTION	1. MOVE WORKPIECE LOADING STATION TO ORIGIN 2. CHECK WORKPIECE LOADING STATION ORIGIN LIMIT SWITCH
MESSAGE	2031 M60, PALLET NOT ON INITIAL STATE (ADDRESS A128.7)
REASON & SOLUTION	1. RECOVER PALLET TO INITIAL STATE 2. CHECK SENSORS OF PALLET CHANGER
MESSAGE	2032 PALLET CW/CCW NOT IN-POSITION (ADDRESS A129.0)
REASON & SOLUTION	1. RECOVER PALLET TO INITIAL STATE 2. CHECK SENSORS OF PALLET CHANGER
MESSAGE	2033 APC SOLENOID OR SENSOR ERROR (ADDRESS A129.1)
REASON & SOLUTION	1. CHECK PALLET CHANGER SOLENOID OR SENSOR 2. CHECK PALLET CHANGER HYDRAULIC SYSTEM
MESSAGE	2034 B AXIS NOT ON REFERENCE POINT (ADDRESS A129.2)
REASON & SOLUTION	1. DO REFERENCE POINT RETURN FOR B AXIS

MESSAGE	2035 PALLET CW/CCW POSITION ERROR (ADDRESS A129.3)
REASON & SOLUTION	1. CHECK PALLET CW/CCW POSITION SENSORS
MESSAGE	2040 COOLANT TANK OVERFLOW (ADDRESS A130.0)
REASON & SOLUTION	1. COOLANT TANK OVERFLOW 2. REDUCE COOLANT WATER 3. CHECK COOLANT TANK HIGH LEVEL SENSOR
MESSAGE	2041 COOLANT LEVEL LOW (ADDRESS A130.1)
REASON & SOLUTION	1. COOLANT LEVEL LOW 2. ADD COOLANT WATER 3. CHECK COOLANT TANK LOW LEVEL SENSOR
MESSAGE	2042 COOLANT SYSTEM FAULT (ADDRESS A130.2)
REASON & SOLUTION	1. CHECK COOLANT TANK HIGH/LOW LEVEL SENSOR 2. ERROR CONDITION: COOLANT TANK HIGH/LOW LEVEL SENSOR OFF/OFF
MESSAGE	2043 CTS FILTER PRESSURE HIGH (ADDRESS A130.3)
REASON & SOLUTION	1. CTS FILTER JAMMED 2. CLEAN OR CHANGE CTS FILTER 3. CHECK CTS FILTER PRESSURE SENSOR
MESSAGE	2050 LUBRICATING PRESSURE ERROR (ADDRESS A131.2)
REASON & SOLUTION	1. LUBRICATING OIL PIPE BROKEN 2. CHECK LUBRICATING OIL PIPE 3. CHECK LUBRICATING UNIT
MESSAGE	2051 LUB OIL LOW LEVEL ERROR (ADDRESS A131.3)
REASON & SOLUTION	1. CHECK LUBRICATING OIL 2. ADD LUBRICATING OIL
MESSAGE	2052 LUB OIL LOW LEVEL INACTIVE, K22.5=1 CHECK LUB OIL LEVEL AND SET K22.5=0 (ADDRESS A131.4)
REASON & SOLUTION	1. FOLLOW THIS INSTRUCTION
MESSAGE	2060 AIR PRESSURE LOW (ADDRESS A132.4)
REASON & SOLUTION	1. AIR PRESSURE LOW 2. CHECK AIR SOURCE PRESSURE 3. CHECK AIR PRESSURE PIPE
MESSAGE	2076 WATER COOLANT UNIT ERROR (ADDRESS A134.4)
REASON & SOLUTION	1. CHECK WATER COOLANT UNIT ERROR CODE 2. CHECK COOLANT WATER TEMPERATURE

MESSAGE	2077 SPINDLE OIL-AIR PRESSURE LOW (ADDRESS A134.5)
REASON & SOLUTION	1. CHECK SPINDLE OIL-AIR UNIT PRESSURE
MESSAGE	2078 SPINDLE OIL-AIR LEVEL LOW (ADDRESS A134.6)
REASON & SOLUTION	1. CHECK SPINDLE OIL-AIR UNIT OIL LEVEL
MESSAGE	2080 PLEASE TURN OFF MODE ENABLE KEY SWITCH (ADDRESS A135.0)
REASON & SOLUTION	1. TURN OFF MODE ENABLE KEY SWITCH
MESSAGE	2081 M03/M04 WITHOUT S CODE (ADDRESS A135.1)
REASON & SOLUTION	1. EXECUTE S CODE AFTER POWER ON
MESSAGE	2090 MACHINE GUARD OPENED (ADDRESS A136.2)
REASON & SOLUTION	1. INFORM THE MACHINE GUARD OPENED
MESSAGE	2091 MAGAZINE GUARD OPENED (ADDRESS A136.3)
REASON & SOLUTION	1. INFORM THE MAGAZINE GUARD OPENED
MESSAGE	2092 ALL AXES REFERENCE NECESSARY ! (ADDRESS A136.4)
REASON & SOLUTION	1. DO THE AXES REFERENCE
MESSAGE	2093 CHECK SPINDLE TOOL NO. ! THEN PRESS "FEED HOLD" BUTTON (ADDRESS A136.5)
REASON & SOLUTION	1. CHECK TOOL DATA TABLE 2. CHECK SPINDLE TOOL NO
MESSAGE	2094 MANUAL HANDLE INTERRUPTION ACTIVE ! (ADDRESS A136.6)
REASON & SOLUTION	1. INFORM MANUAL HANDLE INTERRUPTION ACTIVE 2. TURN OFF FUNCTION ON SOFTWARE OPERATOR'S PANEL
MESSAGE	2095 GUARD SIDE DOOR OPENED (ADDRESS A136.7)
REASON & SOLUTION	1. INFORM THE GUARD SIDE DOOR OPENED
MESSAGE	2096 OPEN MACHINE GUARD DOOR (ADDRESS A137.0)
REASON & SOLUTION	1. OPEN MACHINE GUARD DOOR
MESSAGE	2097 TOOL LIFE ENDS (ADDRESS A137.1)

REASON & SOLUTION	1. INFORM THE LIFE OF THE LAST TOOL OF A GROUP ENDS
MESSAGE	2120 POCKET DATA TABLE INITIAL SETTING YES --> PRESS CYCLE START BUTTON NO --> PRESS FEED HOLD BUTTON (ADDRESS A140.0)
REASON & SOLUTION	1. INFORM THE POCKET DATA TABLE INITIAL SETTING FUNCTION
MESSAGE	2121 LOAD THE SPECIAL TOOL INTO SPINDLE IN MANUAL MODE, AND THEN EXECUTE M61 TO LOAD THE SPECIAL TOOL ON MAGAZINE OR RESET TO CANCEL [FOR EXAMPLE] T1001 --> POCKET01 = T1001 POCKET02 = 00 (EMPTY) POCKET24 = 00 (EMPTY) (ADDRESS A140.1)
REASON & SOLUTION	1. INFORM THE SPECIAL TOOL ASSIGNMENT FUNCTION
MESSAGE	2122 UNLOAD THE NORMAL TOOL FROM SPINDLE IN MANUAL MODE (ADDRESS A140.2)
REASON & SOLUTION	1. INFORM THE SPECIAL TOOL ASSIGNMENT FUNCTION
MESSAGE	2123 EMPTY POCKET ALREADY ASSIGNED, CHECK POCKET DATA TABLE (ADDRESS A140.3)
REASON & SOLUTION	1. EMPTY POCKET ALREADY ASSIGNED, CHECK POCKET DATA TABLE
MESSAGE	2124 SPECIAL TOOL NO. MUST > 1000 (ADDRESS A140.4)
REASON & SOLUTION	1. SPECIAL TOOL NO. MUST > 1000
MESSAGE	2125 DUPLICATE SPECIAL TOOL, CHECK POCKET DATA TABLE (ADDRESS A140.5)
REASON & SOLUTION	1. DUPLICATE SPECIAL TOOL ASSIGNMENT
MESSAGE	2126 ATC DOOR INACTIVE, K7.3=1 SELECT MANUAL MODE, PUSH CYCLE START TO CONFIRM (ADDRESS A140.6)
REASON & SOLUTION	1. CONFIRM ATC DOOR INACTIVE
MESSAGE	2127 EXECUTE M06 TO RETURN SPINDLE TOOL (ADDRESS A140.7)
REASON & SOLUTION	1. INFORM THE STEP AFTER T00 COMMAND

MESSAGE	2128 FORCING ATC SEQUENCE ACTIVE, K26.7=1 (ADDRESS A141.0)
REASON & SOLUTION	1. INFORM TOOL HOLDER EMPTY DETECT INACTIVE
MESSAGE	2129 TOOL HOLDER EMPTY DETECT INACTIVE, K27.6=1 (ADDRESS A141.1)
REASON & SOLUTION	1. INFORM TOOL HOLDER EMPTY DETECT INACTIVE
MESSAGE	2130 FORCING APC SEQUENCE ACTIVE, K8.7=1 (ADDRESS A141.2)
REASON & SOLUTION	1. INFORM FORCING APC SEQUENCE ACTIVE
MESSAGE	2131 PALLET READY PB. INACTIVE, K8.0=1 (ADDRESS A141.3)
REASON & SOLUTION	1. INFORM PALLET READY PB. INACTIVE
MESSAGE	2132 PALLET POS CONFIRM INACTIVE, K8.1=1 (ADDRESS A141.4)
REASON & SOLUTION	1. INFORM PALLET POS CONFIRM INACTIVE
MESSAGE	2133 TAPER CONE POS BY F1, K8.6=1 (ADDRESS A141.5)
REASON & SOLUTION	1. ONLY FOR TESTING
MESSAGE	2150 1. LUB PRESSURE ERROR INACTIVE, K20.4=1 CHECK LUBRICATING SYSTEM AND SET K20.4=0 2. LUB PRESSURE ERROR INACTIVE PERMANENT, K20.4=1 SELECT MANUAL MODE, PUSH CYCLE START TO CONFIRM (ADDRESS A143.6)
REASON & SOLUTION	1. FOLLOW THIS INSTRUCTION
MESSAGE	2170 1. SPINDLE COOLER MOTOR O.L INACTIVE, K12.4=1 CHECK SPINDLE COOLER SYSTEM AND SET K12.4=0 2. SPINDLE COOLER MOTOR O.L INACTIVE PERMANENT, K12.4=1 SELECT MANUAL MODE, PUSH CYCLE START TO CONFIRM (ADDRESS A146.2)
REASON & SOLUTION	1. FOLLOW THIS INSTRUCTION
MESSAGE	2190 MAGAZINE MOVING FORWARD (ADDRESS A148.6)
REASON & SOLUTION	1. INFORM MAGAZINE MOVING FORWARD

MESSAGE	2191 MAGAZINE MOVING BACKWARD (ADDRESS A148.7)
REASON & SOLUTION	1. INFORM MAGAZINE MOVING BACKWARD
MESSAGE	2192 ATC TEST BIT ACTIVE, K15.7=1 DANGER! (ADDRESS A149.0)
REASON & SOLUTION	1. INFORM ATC TEST BIT ACTIVE