VERTICAL BED TYPE MILLING & BORING MACHINE

KMA-5, KMA-5H Operation & Parts Manual



MODEL KMA-5H (WITH OPTIONAL FEATURES)



C O N T E N T S

1. Outline of Machine	
1-1 Specifications	1
1-2 Main Dimension	2
1-3 Name of Main Parts	4
2. Installation of the Machine	
2-1 Transportation	6
2-2 Loosening the clamping units of machine	6
2-3 Leveling and foundation	7
2-4 Cleaning the machine	7
2-5 Removal of pad-bond coating agent	7
3. Lubrication	10
4. Cutting Fluid Pump Device	14
5. Operation	
5-1 Preparation for Operation	16
5-2 Operation of Vertical Spindle	16
5-3 Operation of Table and Saddle	17
5-4 Operation of Horizontal Spindle	19
6. Clamping Devices	
6-1 Vertical Spindle Head Clamping	23
6-2 Table Clamping	23
6-3 Saddle Clamping	24
7. Adjustment	
7-1 The Level Adjustment of the Machine	24
7-2 Adjustment of Vertical Spindle	24
7-3 Adjustment of Sliding Surfaces of Gib	24
8. Electric System	

Page

1. Outline of machine

1-1 Specifications (Model: KMA-5H)

CAPACITY	
Working surface of table(length x width)	2700 x 750mm
Travel longitudinal x cross	2000 x 800mm
Vertical spindle head travel(vertical)	700mm
Horizontal spindle head travel(vertical)	650mm
Vertical spindle nose to table top	70-770mm
Vertical spindle center to column front	800mm
Horizontal spindle center to vertical spindle center distance	610mm
TABLE	
T-slot (Wide x No. x Pitch)	18mm x 5 x 150mm
Table top to floor	900mm
SPINDLE HEAD	
Spindle Nose	ISO R297 No.50
Vertical spindle speeds	45-1500RPM (60Hz)
	Infinitely variable
Horizontal spindle speeds	40-1450RPM (60Hz)
	34-1210RPM (50Hz)
Change of vertical spindle speed	Infinitely variable
Change of horizontal spindle speed	12 steps
Automatic Feeds (vertical spindle)	3~300mm/min
Feed	
Rapid traverse (longitudinal & cross)	3100mm/min
Feed rates (longitudinal & cross) (Infinitely variable)	28-1000mm/min
Change of feed	Infinitely variable
Rapid feed of horizontal spindle	3800mm/min
Auto feed of horizontal spindle (Infinitely variable)	28-1000mm/min
MOTORS	
Vertical spindle	AC11KW (15HP)-4P
Horizontal spindle	AC5.5KW (7.5HP)-6P
X & Y Axes feed (servo motor)	AC3.5kW
Z Axis feed (servo motor) (vertical spindle)	AC1.3kW
W Axis feed (servo motor)	AC0.85kW
Lubrication	AC3.5W-2P
Cutting fluid	AC0.12kW(1/6HP)-2P
Machine size	
Floor space (longitudinal x cross)	5712 x 3075mm
Machine height	3198mm
Net weight (Approx.)	13000kgs
Standard color	Gray

Standard Accessories:

Optional Accessories:

1. Cutting fluid supply mechanism	1 unit	1. Digital scale
2. Tools and box	1 set	2. Power draw bar
3. Leveling blocks	10 pcs	
4. Leveling bolts and nuts	10 pcs	
5. Draw bar	1 pce	

1. Outline of machine

1-1 Specifications (Model: KMA-5H)

CAPACITY	
Working surface of table(length x width)	3200 x 750mm
Travel longitudinal x cross	2500 x 800mm
Vertical spindle head travel(vertical)	700mm
Horizontal spindle head travel(vertical)	650mm
Vertical spindle nose to table top	70-770mm
Vertical spindle center to column front	800mm
Horizontal spindle center to vertical spindle center distance	610mm
TABLE	
T-slot (Wide x No. x Pitch)	18mm x 5 x 150mm
Table top to floor	900mm
SPINDLE HEAD	
Spindle Nose	ISO R297 No.50
Vertical spindle speeds	45-1500RPM (60Hz)
	Infinitely variable
Horizontal spindle speeds	40-1450RPM (60Hz)
	34-1210RPM (50Hz)
Change of vertical spindle speed	Infinitely variable
Change of horizontal spindle speed	12 steps
Automatic Feeds (vertical spindle)	3~300mm/min
Feed	
Rapid traverse (longitudinal & cross)	3100mm/min
Feed rates (longitudinal & cross) (Infinitely variable)	28-1000mm/min
Change of feed	Infinitely variable
Rapid feed of horizontal spindle	3800mm/min
Auto feed of horizontal spindle (Infinitely variable)	28-1000mm/min
MOTORS	
Vertical spindle	AC11KW (15HP)-4P
Horizontal spindle	AC5.5KW (7.5HP)-6F
X & Y Axes feed (servo motor)	AC3.5kW
Z Axis feed (servo motor) (vertical spindle)	AC1.3kW
WAxis feed (servo motor)	AC0.85kW
Lubrication	AC3.5W-2P
Cutting fluid	AC0.12kW(1/6HP)-21
Machine size	
Floor space (longitudinal x cross)	6962 x 3075mm
Machine height	3198mm
Net weight (Approx.)	13700kgs
Standard color	Grav

Standard Accessories:

Optional Accessories:

Digital scale
Power draw bar

1. Cutting fluid supply mechanism	1 unit
2. Tools and box	1 set
3. Leveling blocks	10 pcs
4. Leveling bolts and nuts	10 pcs
5. Draw bar	1 pce









1-3 Name of Main Parts (Fig. 5)

- 1. Column
- 2. Vertical spindle head
- 3. High-low speed change lever for vertical spindle head
- 4. Operator's box
- 5. Table
- 6. Feeding hand wheel of saddle
- 7. Feeding hand wheel of table
- 8. Bed
- 9. Cutting fluid pump
- 10. Change lever for manual or auto feed of vertical spindle head
- 11. Rapid feed hand wheel for vertical spindle head
- 12. Lubrication pump for vertical spindle head sliding surface
- 13. Clamping device for vertical spindle head
- 14. Limit switch for saddle feed stop
- 15. Saddle
- 16. Lubrication pump for table and saddle sliding surface
- 17. Horizontal spindle head
- 18. Horizontal spindle speed selection lever
- 19. Horizontal spindle speed range selection lever



2. Installation of the machine

2-1 Transportation (Fig. 6)

Fix every part of the machine before hanging it. Especially pay attention to the fixation of spindle head and balancing weight (1).Put the both balancing weight at the position of side of column by using the hand wheel for vertical spindle head rapid feed (2), and rotate MPG (Fig.15,S18) for horizontal spindle head. Insert 2 shaft (8) for fixing balance weight.

Then use bolts (3) to fix balancing weight.

Place the table to the middle position of machine , and move saddle close to the side of column. Move vertical spindle head upward, then insert the support bar (4) between table and move horizontal spindle head upward, then insert the support bar (4) between column and horizontal spindle head, hence the chain (6) is at loose condition.

Both end of support bar should be cushioned with cloth or rubber to avoid damage of machine.

Use steel rope to lift the machine shown on (Fig 6).

Cloth or rubber should be cushioned between the rope and machine surface.

Steel rope should not be touched the weak parts of the machine.

2-2 Loosening the clamping units of machine (Fig. 6)

After the transportation is completed. Loosen the clamping units of the machine and be careful to remove the support bar and to stretch the chain (6) slowly. At this time, check the chain whether contact the sprocket (7) tightly or not due to transportation.

Before removal of support bar and the chain in good condition.

Move the spindle head upward for removing the support bar.

Then move the spindle head downward slowly and smoothly until the chain is properly stretched.

NOTE: The chain can not stand impact load or it would be broken.

Examine the chain in good condition once more, then loosen and remove the bolts (side window of column) for fixed balancing weight. But remember during spindle head Downward before chain is stretched, the bolts of fixed balancing weight is absolutely not allowed to take out.

2-3 Leveling and Foundation (Fig. 7)

The machine can be located at 200mm thick concrete floor or set on 600mm thick concrete foundation, to ensure the accuracy of the machine and prevent cutting vibration.

Shown on (Fig. 7) move the table to the middle position and clamp spindle head at the middle position of the column, then put the precision level (accuracy 0.02-0.05mm/1000mm) on the table to adjust the leveling of machine. After finishing the leveling.

Pour the concrete into the anchor bolt holes, tighten the bolt after the concrete is completed rigid, check the machine leveling once more, clean the machine base (sands & scraps etc.) then pour concrete between machine base and floor.

2-4 Cleaning the machine

The machine is protected by grease or antirust oil before shipment. But the machine should be cleaned with gasoline before putting the protecting oil.

2-5 Removal of pad-bond coating agent.

The covers should be applied with pad-bond coating agent if need be. During taking them apart and putting them together again, you should remove all of the used pad-bond coating agent and replace with new ones.

0078 XAM

3. Lubrication

3-1 Refer to (Fig.8) and table 3 & 4, check all of the lubricating portions of the machine which should be applied with suitable amount of oil in compliance with the regulation.When the machine is in operation, inspect again all of the moving parts in good lubricating condition in order to ensure the superior function.

		TABLE 3 Ir	istruction for c	orrect lubria	cant		
	Application Finds	Dronartiae	Symbol and	Kinemn	tic Viscosity(4	0°C)	
	Application rieas		v Iscority Grade	Menn.	min.	max.	
	Enclosed moderately	Refined mineral oils	CB 32	32	28.8	35.2	Pinion speeds(motor output)
	loaded gear	with good wxidation	CB 68	68	61.2	74.8	2000-2000 rpm(within 3./Kw) 1000-2000 rnm(within 7.5km)
L C	(spur gear,bevel gear)	stability	CB 150	150	135	165	-1000 rpm(within 15kw)
0 2 2 2 2	Enclosed heavily	Refined oils with good	CC 150	150	135	165	Worm speeds
	loaded gears	oxidation stability and with improved had-	CC 320	320	288	352	2000- rpm 1000- rpm
	(worm and wheel)	carrying ability	CC 460	460	414	506	
	Spindles bearings	Refined mineral oils with superior	FC 2	2.2	1.98	2.42	Shaft speeds(shaft dia.)
BEARJNGS	and associated	anticorrosion and	FC 10	10	9.00	11.0	10,000- rpm(-30mm) 2000-10 000 rsm(30-150mm)
	clutches	anti-oxidation performces.	FC 22	22	19.8	24.2	-2000 rpm(150- mm)
		Refined mineral oils with improved lubricity	G68	68	61.2	74.8	Slide way(surface pressure)
SLIDE WAYS	Slide ways	and tackiness perfromance preventing stickslip	G220	220	198	242	Horizonte(under 4kgf/cm²) Vertical(under 4kgf/cm²)
		Refined mineral oils with superior	HL32	32	28.8	35.2	0il perature(Rated pressure)
	Hurdhon lin suchame	anti-corrosion and anti-oxidation performance	HL68	68	61.2	74.8	u-ou u(undersokyr/am) 15-65°C(under140kgf/am²)
HYDRAULIC		Refined moneral oils with superior	HM32	32	28.8	32.2	Oil temperature(Reted pressure)
SYSTEMS		anti-corrosion, anti-oxidation and antiwear performances.	HM68	68	61.2	74.8	u-50'C(under14Ukgf/cm²) 15-65°C(under140kgf/cm²)
	Hydraulic and	Refined mineral oils of	HG 32	32	28.8	32.2	Oil temperature(Reted pressure)
	Slide ways	stick-slip propertics.	HG 68	68	61.2	74.8	15-65 c(under70kgf/cm ²)
		Premlum quality	4 N 1	Viscosity (;	25°C) SSU		
CREASE		greuses with superior anti-oxidation and	T MV	310 - 34	0		Lentaized systems
		anti-corrosion pronertics.	XM 2	265 - 29	95		Cup or hand gun

	Table 4 The General Lubricants For Machine Tool						bl	
Sy	ymbol		CPC	Esso/Esson	Shl	Moil Daphne		
	C332		R32	Teresso 32	Te11us Oil C32	Dte Oil Light	Mechanic Oil 32	
	СЗ	868	R63	Teresso 68	Tellus Oil C68	Dte Oil Heavy Medium	Mechanic Oil 63	
	СЗ	150	R150	Teresso 150	Te11us Oil C150	Dte Oil Extra Heavy	Mechanic Oil 150	
	сс	150	R150	Spartan EP 150	Omala Oil 150	Gear 629	CE Compound 150S	
Geo	сс	320	R320	Spartan EP 320	Omala Oil 320	Gear 632	CE Compound 320S	
	сс	460	R460	Spartan EP 460	Omala Oil 460	Gear 634	CE Compound 460S	
0	FC	2			High Spin Oil C2	Velocite Oil No. 3	Mechanic Oil 2	
Bearing	FC	210	R12	Spinesso 10	Tellus Oil C10	Velocite Oil No. 6	Mechanic Oil 10	
	FC	22	R22	Spinesso 22	Tellus Oil C22	Velocite Oil No. 10	Mechanic Oil 22	
Ways	G	63	G68	Febis K63	Tonna T63	Vactra Oil No. 2	Multiway 63C	
Side	G2	220	G220	Febis K220	Tonna T220	Vactra Oil No. 4	Multiway 220C	
	HL	32	R32	Teresso 32	Tellus Oil C32	Dte Oil Light	Hydraulic Fluid 32	
tem	HL	68	R68	Teresso 68	Tellus Oil C68	Dte Oil Heavy Medium	Hydraulic Fluid 68	
c Sys	НМ	32	32AW	Auto HP32	Tellus Oil 32	Ste 24	Super Hydraulic Fluid 32	
ydrauli	НМ	68	68AW	Auto HP68	Tellus Oil 68	Dte 26	Super Hydraulic Fluid 68	
T	НG	HG 32		Powerex DP 32	Tonna Oil T32	Vacuoline Oil 1405	Multiway 32	
	HG 68			Poweex DP 68	Tonna Oil T68	Vacuoling Oil 1408	Multiway 68	
Grease	XM1		Culfc- Rown Grease E.P. NO.1	Listan 1	Alvania Grease 1	Mobilux EP 1	Cornex Grease No.1	
	XM2		Culfc- rown Grease E.P.	Listan 2	Alvania Grease 2	Mobilux 2	Cornex Grease No.2	

4. Cutting Fluid Pump Device (Fig. 9)

Cutting fluid pump (P1) located on the right side of the machine is operated by switch buttons (P3) on the operation panel. It will rotate in left position together with spindle, or rotate in right position by itself. Volume of cutting fluid is about 12 Gal, injected from pan (P4) until the gauge (P5) reaches the upper limit. Release the rotary plug to change the cutting fluid.

Cutting fluid nozzle (P7) is located on the right side of spindle head, held by nozzle clamper (P8). The nozzle direction is adjustable and easy to take apart.

The injection quantity is controlled by a valve (P9), increased in counter-clockwise, and decreased in clockwise.

5. Operation

5-1. Preparation For Operation

Before operating the machine, check and prepare the following items.

Items (1) and (2) are belonged to regular maintenance items.

- (1) Clean the dust or cutting scraps on each sliding surface and circumference and bore of spindle.
- (2) Inject oil to each sliding part according to the oil recommendation (Fig. 8, Table 3 & 4), especially when the machine turned off for a long period.
- (3) Connect the power source (380V, 50HZ) to R.S.T terminals board of electrical cabinet according to the wiring diagram.
- (4) Turn on the no-fuse breaker. The pilot lamps of operation panel will be lit up when the current is conducted.
- 5-2. Operation Of Vertical Spindle (Fig. 10)

Before operating the spindle, check the clamp of the spindle head switch (S11), and rotate to unclamp position (Fig. 10).

(A) Rapid Feed Of Spindle Head (by hand)

Engage the vertical spindle head manual or automatic feed change lever (H6) in "A" position for manual feed, then turn the hand wheel (H7) of spindle head rapid feed to clockwise to move spindle head downward and to counter clockwise to move it upward. The spindle head will move 30mm in each revolution.

(B) The Start And Stop Of Spindle

The spindle will be started or stopped by switches (S4), (S5) and (S6). (S4) is starting switch, (S6) is inching switch, and (S5) is stopping switch.

Starting switch (S4) can only be operated when everything go right. Operate (S5) to stop the spindle. In emergency case, it is also possible to operate the emergency switch (S9) on operation panel to stop the machine.

(C) Rotating Speed Change of Vertical Spindle

Spindle rotation speed can be changed by operating high-low change lever (H3). Then turn the knob (S29) increase or decrease spindle speed.

There are infinitely variable change speed as shown in specification.

Do not operate the lever when the spindle is in rotation.

It can be operated only when the spindle is stopped.

If the spindle is rotated manually, the high-low change lever should be placed in the middle position.

(D) Automatic Feed Of Vertical Spindle Head

The spindle head automatically feed can be operate spindle head manual or automatic feed change lever (H6). Lever(H6) will set "A" direction for manual feed and push lever to "B" direction for automatic feed.

Turn the knob (S27) increase or decrease spindle head (Z axis) feed.

5-3. Operation Of Table And Saddle (Fig. 11)

Before operation, rotate the table clamping switch (Fig.11) (S12), saddle clamping switch (Fig. 11) (S10) on the operation panel to unclamp position.

(A) Hand Feed Of Table And Saddle

Push the table feed hand wheel (E1) to mesh clutch for rotation. It will move the table to right in clockwise, and left in counterclockwise.

Push the saddle feed hand wheel (E2) to match clutch for rotation. It will move the saddle to backward in clockwise, and forward in counterclockwise.

Hand wheel will move forward or backward 6mm in each revolution. Each hand wheel has 0.025mm scale knob (E7), (E8) When scale knob is calibrated to the positive zero and the set screw is fixed, the reading represents the displacement.

(B) Starting And Stopping Operation Of Table Automatic Feed

Check the proper operation of the table feed stop block (D3), (D4) and table feed limit switches (L11), (L12) and saddle feed stop block (D5), (D6) and saddle feed limit switches (L13), (L14). Adjust and fix the feed stop block (D3), (D4) or (D5), (D6) on the desired position. When starting switch (S8) on the operation panel moving to right, left, forward or backward, the table will move to right, left, forward or backward.

If the starting switch (S8) is in neutral position, the table will stop feeding.

Besides, the table will be stopped also by table feed stop block (D3), (D4) contact limit switch (L11) (L12), and saddle feed stop block (D5), (D6) contact the limit switches (L13), (L14).

In case of emergency , press the emergency stop switch (S9), all of the power are shut down.

(C) Automatic Feed Speed Change Of Table

Automatic feed speed of table can be adjusted by control knob (S7), increase feeding in clockwise, and decrease feeding in counterclockwise.

Operator can adjust the knob to a satisfied feed speed based on the actual situation. The knob is scaled in mm/min.

(D) Automatic Feed Direction of Table

Automatic feed of table in this machine is controlled by switch (S8). Its feed direction is the same as switch direction, right, left, forward, backward.

(E) Table Rapid Feeding

Table rapid feeding is also controlled by switch (S8) press the button and push to operate in the direction based on actual requirements. Rapid feed speed is 3100mm/min.

(F) Automatic Feed Stop

Left-right direction elbow (D3), (D4) and back-forth direction elbow block (D5), (D6) must fixed exact position.

F-1. Stop The Feed Of Table Moving Toward To Left Side

When the elbow block (D3) devices on the right side in front of table touch the limited switch (Li1), the electrical circuit of feed motor will be interrupted, and the movement of table will stop at once. At this time, if the switch (S8) is operated to "B" direction the motor will be started in reverse direction.

F-2. Stop The Feed Of Table Moving Toward To Right Side

When the elbow block (D4) devices on the left side in front of table touch the limited switch (Li2), the electrical circuit of feed motor will be interrupted, and the movement of table will stop at once. At this time, if the switch (S8) is operated to "A" direction the motor will be started in reverse direction.

F-3. Stop The Feed Of Saddle Moving Toward to Forward

When the elbow block (D6) devices on the rear side in right side of saddle touch the limited switch (Li4) the electrical circuit of feed motor will be interrupted, and the movement of saddle will stop at once. At this time, if the switch (S8) is operated to "C" direction, the motor will be started in reverse direction.

F-4. Stop The Feed Of Saddle Moving Toward To Backward

When the elbow block (D5) devices on the front side in right side of saddle touch the limited switch (Li3) the electrical circuit of feed motor will be interrupted, and the movement of saddle will stop at once. At this time, if the switch (S8) is operated to "D" direction, the motor will be started in reverse direction.

(G) Identification On Automatic Feed Stop

After the feed is stopped in each direction, if it is necessary to restart the feed at the same direction, please process in manual operation.

Automatic feed stop in each direction will be effective either on cutting feeding or rapid feeding. If the elbow block and limit switch are under the following status, the switch (S8) has no action at all. So the motor in speed change box will be not started.

- (1) (D3), (L11) and (D5), (L13) operating same time.
- (2) (D4), (L12) and (D6), (L14) operating same time.

In above function, the elbow block and limit switch will be released by hand feed. When automatic feed is stopped, the switch (S8) must be place in neutral position.

When it is turned on again or power turned on and signal processed, the motor must be started according to the switch (S8) direction .

- 5-4. Operation Of Horizontal Spindle (Fig. 12)
- (A) Rapid Feed Of Horizontal Spindle Head

Turn the select switch (S22) on the "Jog" position and move the spindle head upward or downward direction lever (S24) and depress the rapid button (S25) in the same time.

(B) Cutting Feed Of Horizontal Head

Turn the select switch (S22) on the "Jog" position and move the spindle head upward or downward direction lever (S24). It is depending upon required to adjustment the "Feed Override" button (S23).

(C) Manual Feed Of Horizontal Head

Turn the select switch (S22) on the "Handle" position and turn the multiple button (S16) to rotate and move the spindle to upward & downward by hand wheel "M.P.G." (S18).

(D) Starting And Stopping Of Spindle

The spindle will be started or stopped by switches (S13),(S14), (S15),and (S13) is starting switch, (S15) is inching switch and (S14) is stopping. Starting switch (S13) can only be operated when everything goes right operate (S14) to stop the machine.

(E) Change Of Horizontal Spindle Speed

Move lever (H2) to position \searrow . \downarrow or \swarrow depending upon the spindle speed range required, and move lever (H1) the position of the particular speed required. Speed change must be made while the motor is stop.

6. Clamping Devices

In order to maintain better finishing and accurate surface, the following portions should be clamped tightly before cutting operation.

6-1. Vertical Spindle Head Clamping (Fig. 10)

The clamping of spindle head should turn the clamping switch (S11) to right for clamping and turn to left side for unclamping.

6-2. Table clamping (Fig. 10)

The clamping of table should turn the clamping switch (S12) (In the case of boring or drilling operation) to right for clamping and turn to left side for unclamping.

6-3. Saddle Clamping (Fig. 10)

The clamping operation of spindle should turn the clamping switch (S10) to right side for clamping and turn to left side for unclamping.

7. Adjustment:

After installation of the machine or in operation, you find the condition of the machine is abnormal. The following steps should be taken. (Inspection or adjustment).

- 7-1. The level adjustment of the machine (Fig. 12)
- 1. Place the two levels of 0.02-0.05mm/1000mm accuracy on the table perpendicular to each other.
- 2. Loosen the nuts (A1) of anchor bolts (A2).
- 3. Loosen the leveling fixed nuts (L3).
- 4. Loosen the leveling bolts (L2) and adjust the level (10 leveling bolts to be adjusted) .Until the leveling is accurate.
- 5. Looking the leveling and fixed nuts (L3) (don't rotate the leveling bolts).
- 6. Lock the anchor bolts with nuts (A1).
- 7. Recheck the air bubbles displacement on the level
- 7-2. Adjustment Of vertical Spindle (Fig. 13)

If you find loose spindle or temperature rise of spindle bearing. The readjustment should be taken carefully.

- 1. Take apart the cover of spindle head (HC1).
- 2. Loosen the fixed bolts (B1).
- 3. Screwing the adjustable nuts (N1) not so loose, not so tight (because of temperature rise of bearing).
- 4. Screwing the fixed bolts (B1), (Preventing the adjusted nuts (N1) loose).
- 5. Reassembling the spindle head cover.
- 7-3. Adjustment Of Sliding Surfaces Of Gib. (Fig. 14, Fig. 15)When sliding surfaces are loose, make a suitable adjustment.
- A. Adjustment of side gib of vertical spindle head (Fig. 14)
- 1. Screw the bolts (K2) to adjust the inside gibs (K1).
- 2. Try to ascend and descend the spindle head and observe the tightness.
- B. Adjustment of gib inside of vertical spindle head (Fig. 14)
- 1. Tighten the locking bolts (K6).
- 2. Screw the bolts (K4) to adjust the inside gibs (K3).
- 3. Try to ascend and descend the spindle head and observe the tightness.
- C. Adjustment of gibs for table (Fig. 15)
- 1. Loosen the locking nuts (KT3).
- 2. Screw the lock bolts (KT2) to adjust the gibs (KT1)
- 3. Tighten the lock nuts (KT3).

- 4. Try to swing the table and observe the tightness.
- D. Adjustment of gib for saddle (Fig. 15)
- 1. Loosen the locking nuts (KT7).
- 2. Screw the locking bolts (KT6) to adjust the gibs (KT5)
- 3. Tighten all of the locking nuts (KT7).
- 4. Try to swing the saddle and observe the tightness.

TABLE 6									
Milling Cutter	Work	Feed Amount Per Tooth MM.							
	Materials	Brinell hardness HB	Face milling Cutter	Plane mill cutter helical teeth	Slotting saw and slide milling cutter	End mill	Formed cutter	Saw blade milling cutter	
	Special steel	Hard tough anneal –ed	300–400 220–300 180–22	0.1 0.13 0.2	0.075 0.125 0.175	0.075 0.1 0.125	0.05 0.075 0.1	0.05 0.05 0.025	0.025 0.05 0.05
Cutters	Low- carbon steel	Mallea- ble cuts well	152–197 150–180	0.25 0.3	0.2 0.25	0.13 0.175	0.125 0.13	0.075 0.1	0.075 0.035
eel Milling	Cast iron	Hard medium hard soft	220–300 150–250 150–180	0.27 0.325 0.4	0.2 0.25 0.325	0.13 0.175 0.225	0.13 0.175 0.2	0.1 0.1 0.125	0.075 0.075 0.1
h-Speed S	Brass and bronze	Hard medium hard soft	150-250 100-150 80-100	0.225 0.35 0.55	0.225 0.35 0.55	0.13 0.2 0.325	0.125 0.175 0.27	0.075 0.1 0.175	0.05 0.075 0.125
High	Magnesium and its alloys			0.55	0.45	0.325	0.27	0.175	0.125
	Aluminum and alloys			0.55	0.45	0.325	0.27	0.175	0.125
	Plastic			0.375	0.3	0.225	0.175	0.125	0.1
	Special steel	Hard tough annealed	300-400 220-300 180-220	0.25 0.3 0.35	0.2 0.25 0.27	0.13 0.175 0.2	0.125 0.13 0.175	0.075 0.1 0.1	0.075 0.075 0.1
ter	Low carbon steel	Mallea- ble cuts well	152–197 150–180	0.35 0.4	0.27 0.325	0.2 0.225	0.175 0.2	0.1 0.125	0.1 0.1
Super-Hard Aloy Milling Cut	Cast iron	Hard medium hard soft	220–300 180–220 150–180	0.3 0.4 0.5	0.25 0.325 0.4	0.175 0.25 0.3	0.13 0.2 0.25	0.1 0.125 0.13	0.075 0.1 0.125
	Brass and Hard bronze hard cuts we		150-250 100-150 80-100	0.25 0.3 0.5	0.2 0.25 0.4	0.13 0.175 0.3	0.125 0.13 0.25	0.075 0.1 0.13	0.075 0.075 0.125
	Magnesium and its alloys			0.5	0.4	0.3	0.25	0.13	0.125
	Aluminum and its alloys			0.5	0.3	0.3	0.25	0.13	0.125
	Plastic			0.57	0.3	0.225	0.175	0.125	0.1

Sharp Industries, Inc.

3501 Challenger Street Torrance, CA 90503 Tel 310-370-5990 Fax 310-542-6162 Email: info@sharp-industries.com Parts: parts@sharp-industries.com Sales: sales@sharp-industries.com Support: support@sharp-industries.com www.sharp-industries.com

